



# AS/NZS 4777.2:2020 Technical Information

---

STP 12-50, STP 15-50, STP 20-50, STP 25-50

# Contents

1	Disclaimer.....	4
2	Scope .....	5
3	Connecting to the inverter .....	6
	3.1.1 Required equipment.....	6
	3.1.2 Connection.....	6
	3.1.2.1 Connecting via Wi-Fi.....	6
	3.1.2.2 Connecting via Ethernet.....	7
4	Commissioning Inverter .....	9
4.1	Via Web Browser .....	10
	4.1.1 Commissioning Wizard .....	10
	4.1.2 Changing grid protection & power quality response modes.....	14
5	Firmware update.....	15
5.1	Procedure.....	15
	5.1.1 Required equipment.....	15
	5.1.2 Connection.....	15
	5.1.2.1 Updating Firmware.....	16
6	Checking of Parameters .....	18
6.1	Country Standard & Firmware .....	18
6.2	Grid Protection and Power Quality Settings.....	19
	6.2.1 Volt-Watt .....	19
	6.2.2 Volt-Var .....	19
	6.2.3 Frequency Protection .....	20
	6.2.4 Voltage Protection.....	20
	6.2.5 Over/Under Frequency.....	20
	6.2.6 Fixed Power Factor .....	20
	6.2.7 Fixed Reactive Power.....	20
	6.2.8 Ramp Rate .....	20

7	Export Limiting.....	22
8	Earth Fault Alarm .....	23
8.1	Sunny Portal Remote Alarm Setup .....	23
9	DRED / DRM .....	26
9.1	Connection to a DRED .....	26
9.2	DRM Modes .....	28
9.3	DRM Labelling .....	28
10	Startup and Shut Down Procedure .....	29
10.1	Startup Procedure.....	29
10.2	Shut Down Procedure.....	30

# 1 Disclaimer

Every attempt has been made to make this document complete, accurate and up-to-date. Readers are cautioned, however, that changes to local regulations or product improvements may cause SMA Australia to make changes to this document without advance notice. SMA Australia shall not be responsible for any damages, including indirect, incidental or consequential damages, caused by reliance on the material presented, including, but not limited to, omissions, typographical errors, arithmetical errors or listing errors in the content material.

It is therefore recommended that you always check for the latest version prior to following the instructions in this document.

## 2 Scope

This document is intended to cover the following SMA models:

Inverter model
STP 12-50
STP 15-50
STP 20-50
STP 25-50

**Table 1:** *In scope inverters*

As of December 18<sup>th</sup>, 2021 all inverters installed in Australia must comply with one of the pre-set region setting sets described in AS/NZS 4777.2:2020.

1. Australia A
2. Australia B
3. Australia C

All three regions contain the default Power Quality, Volt-Watt, Volt-Var, Frequency/Voltage Response and grid protection settings. Should you require advice or changes to protection settings please reach out to the SMA technical support for assistance.

The following inverters have not been tested to AS/NZS 4777.2:2020 for multiple inverter combinations: STP 12-50, STP 15-50, STP 20-50, STP 25-50

## 3 Connecting to the inverter

### 3.1.1 Required equipment


- a. Laptop with WiFi and/or Ethernet port with a Web Browser eg. Chrome, Firefox, Edge.
  - i. Due to file size it is recommended to download the firmware prior to site visit.

### 3.1.2 Connection

- a. Via WiFi connection – refer to **3.1.2.1**
- b. Via Ethernet – refer to **3.1.2.2**

#### 3.1.2.1 Connecting via Wi-Fi

- a. Search for the WLAN of the inverter.  
The name will follow the format **SMA [serial number]**.
- b. Use the device specific **WPA2-PSK password**. The WPA2-PSK password can be found on the type label on the side of the inverter.



*Image 1: Example of WPA password*

- c. Open a web browser and enter in the IP address **192.168.12.3**.




Image 2: Wi-Fi Login Menu

### 3.1.2.2 Connecting via Ethernet

- a. Connect your laptop to the inverters ethernet port.





Image 3: Ethernet connection

- b. Open a web browser and enter in the IP address **169.254.12.3**.



**Image 4:** Ethernet Login Menu



## 4 Commissioning Inverter

**NOTE: First production of STP X inverters does not come with minimum firmware required. To update the firmware commissioning of the inverter needs to be completed first.**

Commissioning the inverter can be done by:

- a. Web Browser on a laptop – Mac and Windows.

DNSP	Country Standard
Ausgrid Ausnet Citipower Endeavour Energy Energex Ergon Essential Energy Evoenergy Jemena SA Power Networks Ausgrid PowerCor United Energy	[AU] AS/NZS 4777.2:2020 Generator Region A
Western Power	[AU] AS/NZS 4777.2:2020 Generator Region B
Horizon Power TasNetworks	[AU] AS/NZS 4777.2:2020 Generator Region C
New Zealand DNSP	[AU] AS/NZS 4777.2:2020 Generator Region NZ

**Table 2:** AS/NZS4777 Standard by DNSP

## 4.1 Via Web Browser

Please refer to section 3.1.2 for connection via Wi-Fi or Ethernet.

### 4.1.1 Commissioning Wizard

**NOTE:** The commissioning wizard is only shown upon first connection, after successful commissioning a factory reset needs to be performed before the wizard will be shown again. Adjustments to parameters etc. do not require a factory reset.

1. Check the firmware version, internet connection and continue.




Image 5: Commissioning Wizard Step 1

2. Setup a user account, make note of the username and password as this cannot be reset without performing a user account factory reset.

**SMA** SUNNY TRIPOWER X 15

0% Commissioning Welcome

### Administrator registration ⓘ

Language  
English US

Salutation\*

First name\* Last name\*

User name\*

Password\*

Repeat password\*

**Password guidelines** ⓘ

- At least 1 lower-case letter
- At least 1 upper-case letter
- At least 1 number
- At least 1 special character
- 10-50 characters
- Only permitted symbols

**Image 6:** Admin account

3. Create a device name and select system manager, then continue.




Image 7: Device config

4. Tick all boxes and continue.




Image 8: Automatic updates

- 5. For this technical document addition of 3<sup>rd</sup> party, extra devices will not be covered.
- 6. If firmware is up to date as per table 3, then select the right country standard from the list.




Image 9: Selection of Country Standard

- 7. After step 6, the remaining steps are only for export limiting which is not covered in this document.
- 8. Once the initial setup is complete, and the firmware is not up to date then you can continue to section 5 to perform the firmware update.

### Configuration has been completed successfully



Your Sunny Tripower X 1.5 was successfully configured. In order to be able to make full use of your Data Manager's functions, create your system in [Sunny Portal powered by ennexOS](#).

**Tip:** As soon as all devices are in operation and your system is optimally configured, SMA recommends creating a backup file. If you replace your communication device or reset your existing communication device to default settings, the backup file is used to transfer configuration information. The backup file includes system and device configuration data of your communication device (see manual of communication device).

Go to system

Image 10: Commissioning Complete

## **4.1.2 Changing grid protection & power quality response modes**

To change the settings associated with power quality and grid protection, please reach out to the service team on +61 2 9491 4200 between 8am to 6pm Monday to Friday AEDT or via email on [service@sma-australia.com.au](mailto:service@sma-australia.com.au).

## 5 Firmware update

Please refer to **Table 1** for applicable devices and minimum firmware versions. We recommend using the latest firmware from the [website](#) if it is newer than the one listed below.

Inverter model	Minimum firmware
STP 12-50 STP 15-50 STP 20-50 STP 25-50	2.06.04.R

**Table 3:** Minimum Firmware Requirements

### 5.1 Procedure

#### 5.1.1 Required equipment

- a. Laptop with WiFi and/or Ethernet port with a Web Browser eg. Chrome, Firefox, Edge.
  - i. Due to file size it is recommended to download the firmware prior to site visit.

#### 5.1.2 Connection

- a. Via WiFi connection – refer to **3.1.2.1**
- b. Via Ethernet – refer to **3.1.2.2**

### 5.1.2.1 Updating Firmware

- a. Enter the **Username** as configured during initial commissioning.
- b. Once logged in navigate to the **Configuration > Update and backup** via the menu.




Image 11: Update the Firmware

- c. Click on **Select the file...** locate the appropriate firmware update on your device and click **Start Update**.

#### Note:

Depending on the firmware, the update process will take some time to complete. During this time, the file will be uploaded from your smart device to the inverter. Once this upload process reaches 100%, the inverter will install the new firmware. During which, you will lose connection between your smart device and the inverter. Wait 5 minutes after losing connection, before reconnecting to the inverter's WebUI.

When the update is complete, you will be able to verify this by navigating to **Events** and finding an entry **Update completed**.



## Update and backup

### Automatic updates

- Enable function and security updates for this communication device
- Enable function and security updates for all updateable SMA products of the system via this communication device

### Backup

Here you can create and save a backup file of your device. The backup file can be used to restore important configurations.

[Creating a backup file](#)

### Manual update

Select an update file to be transferred to the device.

[Select the file.](#)

[Start update](#)

**Image 12:** Firmware Update selection

## 6 Checking of Parameters


To verify that the Firmware and Country Standard are correct, it can be done via the following method.

- a. WebUI of the inverter

### 6.1 Country Standard & Firmware


1. Login to the inverter via methods in section 3.1.2.
2. Select the inverter name or SN in the webUI.

#### Dashboard My plant



**Image 13:** Selecting device

3. Click on Configuration > Parameters.



**Image 14:** Parameter adjustment

4. Enter in the search term "grid monitoring".

### Parameter

Q

Group	Name	Value
Grid Monitoring	Country standard set	[AU] AS/NZS 4777.2:2020 Generator Region A

Image 15: Country Standard

5. To check firmware, under the same menu type in "firmware".

### Parameter

Q

Group	Name	Value	Channel
Device Components	Firmware version of the communication assembly	1.6.5.R	Parameter.Nameplate.CmpCom.SwRev
Device Components	Firmware version of the main processor	02.16.03.R	Parameter.Nameplate.CmpMain.SwRev
Device Components	Firmware version of the operating system	1.2.0.R	Parameter.Nameplate.CmpOS.SwRev
Type Label	Firmware version	03.02.05.R	Parameter.Nameplate.PkgRev

Image 16: Checking Firmware

## 6.2 Grid Protection and Power Quality Settings

### 6.2.1 Volt-Watt

To verify Volt-Watt settings search for **P(V)** and click on download as shown in image 17. The downloaded settings will be in a CSV format.

### 6.2.2 Volt-Var

To verify Volt-Var settings search for **Q(V)** and click on download as shown in image 17. The downloaded settings will be in a CSV format.

### 6.2.3 Frequency Protection

To verify Frequency Protection settings search for **Frequency Monitoring** and click on download as shown in image 17. The downloaded settings will be in a CSV format.

### 6.2.4 Voltage Protection

To verify Voltage Protection settings search for **Voltage Monitoring** and click on download as shown in image 17. The downloaded settings will be in a CSV format.

### 6.2.5 Over/Under Frequency

To verify Over/Under Frequency Protection settings search for **P(F)** and click on download as shown in image 17. The downloaded settings will be in a CSV format.

### 6.2.6 Fixed Power Factor

To verify Fixed Power Factor settings search for **Manual cos  $\phi$  setting** and click on download as shown in image 17. The downloaded settings will be in a CSV format.

### 6.2.7 Fixed Reactive Power

To verify Fixed Reactive Power settings search for **Manual reactive power** and click on download as shown in image 17. The downloaded settings will be in a CSV format.

### 6.2.8 Ramp Rate

To verify Ramp Rate settings search for **WGra** and click on download as shown in image 17. The downloaded settings will be in a CSV format.

### Parameter




Image 17: Grid quality settings download

Group	Name	Value	Translated Unit	Channel
System and device control	P(V), tripping delay	0	0 s	Parameter.Inverter.WModCfg.WCtIVolCfg.ActTms
System and device control	P(V), number of points used	2	2	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.NumPt
System and device control	P(V), max. number of support points	8	8	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.NumPtMax
System and device control	P(V), voltage value	1.1	1.1 p.u.	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.XVal[0]
System and device control	P(V), voltage value	1.13	1.13 p.u.	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.XVal[1]
System and device control	P(V), voltage value	2	2 p.u.	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.XVal[2]
System and device control	P(V), voltage value	2	2 p.u.	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.XVal[3]
System and device control	P(V), voltage value	2	2 p.u.	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.XVal[4]
System and device control	P(V), voltage value	2	2 p.u.	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.XVal[5]
System and device control	P(V), voltage value	2	2 p.u.	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.XVal[6]
System and device control	P(V), voltage value	2	2 p.u.	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.XVal[7]
System and device control	P(V), active power value	100	100 %	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.YVal[0]
System and device control	P(V), active power value	20	20 %	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.YVal[1]
System and device control	P(V), active power value	0	0 %	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.YVal[2]
System and device control	P(V), active power value	0	0 %	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.YVal[3]
System and device control	P(V), active power value	0	0 %	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.YVal[4]
System and device control	P(V), active power value	0	0 %	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.YVal[5]
System and device control	P(V), active power value	0	0 %	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.YVal[6]
System and device control	P(V), active power value	0	0 %	Parameter.Inverter.WModCfg.WCtIVolCfg.Crv.YVal[7]
System and device control	P(V), activation	308	On	Parameter.Inverter.WModCfg.WCtIVolCfg.Ena
System and device control	P(V), type of reference voltage	4520	Mean value of phase	Parameter.Inverter.WModCfg.WCtIVolCfg.VRefMod
System and device control	P(V), limitation of change rate	303	Off	Parameter.Inverter.WModCfg.WCtIVolCfg.WGraEna
System and device control	P(V), decrease rate	20	20 %/s	Parameter.Inverter.WModCfg.WCtIVolCfg.WGraNeg
System and device control	P(V), increase rate	20	20 %/s	Parameter.Inverter.WModCfg.WCtIVolCfg.WGraPos
System and device control	P(V), type of reference active power	4405	Maximum active power	Parameter.Inverter.WModCfg.WCtIVolCfg.WRefMod
System and device control	P(V), nominal value filter	308	On	Parameter.Inverter.WModCfg.WCtIVolCfg.WTmEna
System and device control	P(V), setting time, nominal value filter	3	3 s	Parameter.Inverter.WModCfg.WCtIVolCfg.WTms

Image 18: P(V) settings CSV

## 7 Export Limiting

The STP X currently does not support Export limiting as per AS/NZS4777.2:2020, this section will be updated in the future when this is tested.

## 8 Earth Fault Alarm

The inverter detects earth faults by the measurement of insulation resistance between the DC side and ground prior to operation, and residual current during operation. Earth faults (and other faults) trigger the inverter's earth fault alarm. The following is a summary of these alarms.

Inverter model	Visual LED on Inverter	Audible alarm	Remote Alarm
STP 12-50 STP 15-50 STP 20-50 STP 25-50	Yes	No	Optional via Sunny Portal

*Table 4: Earth Fault Alarm*

### 8.1 Sunny Portal Remote Alarm Setup

The inverter's Earth Fault Alarm can be configured once the plant is registered in Sunny Portal. In the event of an earth fault, a report with the corresponding events will be emailed to nominated addresses. A report will then be sent every hour until the earth fault is acknowledged in Sunny Portal or cleared.

For instructions on how to register your plant in Sunny Portal, please refer to the respective Sunny Portal User Manual for your plant:

- Webconnect (no communication devices): [User Manual - SUNNY PORTAL powered by ennexOS \(sma.de\)](#)

Once your plant is registered in Sunny Portal, continue to set up the Earth Fault Alarm using the following instructions:

1. Login to your Sunny Portal account on [ennexos.sunnyportal.com](http://ennexos.sunnyportal.com).




Image 19: EnnexOS Login

2. Expand the **Configuration** tab and select **Notifications**.





Image 20: Notification



- Expand the drop-down menu at the top of the page and select the option **Event report for errors in accordance with the standard**.



**Image 21:** Event Report Selection

- Once selected the report is automatically created with the email used to login to Sunny Portal as the default address.

**Notifications**

Type	Designation	Configuration	Level	Systems	E-mail	Cycle	Active	
	Alarm AS 5033				your email	Immediately	<input checked="" type="checkbox"/>	

**Image 22:** Earth Fault alarm


- You have now set up the Earth Fault Alarm for your inverter.

## 9 DRED / DRM

### 9.1 Connection to a DRED

Inverter connection to a demand response enable device (DRED) is possible with an approved modbus Demand Response controller (DRC) such as provided by Olivance:

[Olivance Powerlink - Olivance](#)



The modbus TCP parameter must be enabled on the inverter.

1. Login to the inverter's WebUI as an installer, refer to section **3.1.2** or **4.1** depending on different connection methods.
2. Navigate to **Configuration > External Communication > Carry out initial configuration** and **check Enable Modbus server**.





Image 23: External Communication

## External communication

### Modbus server

The Modbus protocol is an industrial data communication protocol for use in the PV system communication, for example.



### FTP Push

The FTP Push function can be used to upload collected system data cyclically to a freely selectable external FTP server. Here, the system data is exported in an unchangeable XML format.




Image 24: Modbus Configuration

### Modbus server

The Modbus protocol is an industrial data communication protocol for use in the PV system communication, for example.



**Information**  
 Activate the Modbus server only if it is used by other devices or applications. Secure your network against unauthorized access.

You can change the standard port address of the Modbus server if required. Only use free ports.

Port\*  
 502

### Sensor assignment

Here you may assign the sensors provided by the Modbus server to your system.

[Read more](#)

Function	Device	Input



Image 25: Enabling Modbus


## 9.2 DRM Modes

Currently DRM0 is the only DRM mode available for the following inverter models:

STP 12-50, STP 15-50, STP 20-50, STP 25-50

## 9.3 DRM Labelling

The DRC must be labelled with the DRM mode and the RJ45 with the DRM Port.



Example DRM Model Label



Example DRM Port Label

## 10 Startup and Shut Down Procedure

Incorrect startup/shut down procedure can damage the inverter, make sure to follow the instructions below.

Please consult with a qualified person before performing the below steps.

### 10.1 Startup Procedure

1. If the DC load-break switch has been protected with a padlock, open and remove the padlock on the DC load-break switch.
2. Switch on the **DC load-break switch**.




Image 26: DC isolator on

3. Switch on the **Main Switch - Inverter Supply**, marked in the switchboard.
4. Inverter LEDs should all turn on during initial startup, wait 60 seconds before checking.
5. If the green LED is still flashing, the conditions for activating feed-in operation are not yet met. As soon as the conditions for feed-in operation are met, the inverter starts with feed-in operation and, depending on the available power, the green LED will light up continuously or it will pulse.

## 10.2 Shut Down Procedure

1. Switch off the **Main Switch – Inverter Supply**, marked in the switchboard.
2. Switch off the **DC load-break switch**.




Image 27: DC isolator off

3. When required lock the **DC load-break switch**.




Image 28: Locking DC isolator

This concludes the document, if you have any questions you can reach out to [Solaracademy@sma-australia.com.au](mailto:Solaracademy@sma-australia.com.au) for pre-sales/installation questions or [service@sma-australia.com.au](mailto:service@sma-australia.com.au) for after sales support.

