

SMA HYBRID CONTROLLER

Legal Provisions

The information contained in these documents is the property of SMA Solar Technology AG. No part of this document may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, be it electronic, mechanical, photographic, magnetic or otherwise, without the prior written permission of SMA Solar Technology AG. Internal reproduction used solely for the purpose of product evaluation or other proper use is allowed and does not require prior approval.

SMA Solar Technology AG makes no representations or warranties, express or implied, with respect to this documentation or any of the equipment and/or software it may describe, including (with no limitation) any implied warranties of utility, merchantability, or fitness for any particular purpose. All such representations or warranties are expressly disclaimed. Neither SMA Solar Technology AG nor its distributors or dealers shall be liable for any indirect, incidental, or consequential damages under any circumstances.

The exclusion of implied warranties may not apply in all cases under some statutes, and thus the above exclusion may not apply.

Specifications are subject to change without notice. Every attempt has been made to make this document complete, accurate and up-to-date. Readers are cautioned, however, that product improvements and field usage experience may cause SMA Solar Technology AG to make changes to these specifications without advance notice or per contract provisions. SMA Solar Technology AG shall not be responsible for any damages, including indirect, incidental or consequential damages, caused by reliance on the material presented, including, but not limited to, omissions, typographical errors, arithmetical errors or listing errors in the content material.

SMA Warranty

You can download the current warranty conditions from the Internet at www.SMA-Solar.com.

Software licenses

You will find the software licenses for the installed software modules (open source) on the Internet at www.SMA-Solar.com.

Trademarks

All trademarks are recognized, even if not explicitly identified as such. Missing designations do not mean that a product or brand is not a registered trademark.

SMA Solar Technology AG

Sonnenallee 1

34266 Niestetal

Germany

Tel. +49 561 9522-0

www.SMA.de

E-mail: info@SMA.de

Status: Friday, December 19, 2025

Copyright © 2025 SMA Solar Technology AG. All rights reserved.

Table of Contents

1	Information on this Document.....	6
1.1	Validity	6
1.2	Target Group.....	6
1.3	Content and Structure of this Document	6
1.4	Levels of Warning Messages	6
1.5	Symbols in the Document	7
1.6	Typographies in the document.....	7
1.7	Designations in the Document.....	7
1.8	Explanation of Used Terms.....	8
1.9	Additional Information	8
2	Safety	10
2.1	Intended Use	10
2.2	IMPORTANT SAFETY INFORMATION.....	11
3	User Interface	14
3.1	Requirements for the user interface display	14
3.2	Design of the User Interface	15
3.3	Buttons in the header	16
3.4	User Groups and User Rights.....	17
3.5	Home Page for User Group "User".....	18
3.6	Home Page for User Group "Installer".....	19
3.7	Configuration Wizard.....	20
3.7.1	Structure of the Configuration Wizard	20
3.7.2	Buttons in the Configuration Wizard	21
4	Operation	23
4.1	Setting the User Interface Language	23
4.2	Logging Into the User Interface	23
4.2.1	Protection from unauthorized access.....	23
4.2.2	Maximum number of logins	23
4.2.3	Automatic logout.....	23
4.2.4	Example: allocation of IP addresses.....	23
4.2.5	Only during commissioning: log in with the standard password.....	24
4.2.6	Logging in with secure password	24
4.2.7	Logout.....	25
4.2.8	Disable lock screen.....	25
4.3	Changing the Password	25
4.4	Setting the System Time and Location.....	25

4.5	Access from the Internet	26
4.5.1	Access to operating data by SMA Service	26
4.5.2	Secure VPN connection	26
4.5.3	Setting up access via the Internet	27
4.6	Internal Communication Network	27
4.6.1	IP address of programmable logic controller in Hybrid Controller	27
4.6.2	Assigning IP Addresses for Internal Communication Network	27
4.6.3	Recommendation for station numbers	28
4.6.4	Recommendations for device numbers	28
4.6.5	Example for allocation of IP addresses	29
4.6.6	Setting the IP addresses on the Hybrid Controller	29
4.7	Setting up communication with the SCADA system	30
4.8	Retrieving Display Values	30
4.9	Configuring the Operating Mode	30
4.10	Setting Parameters for System Control	31
4.11	Black start	33
4.11.1	Safety during black start	33
4.11.2	Sequence of a black start with Hybrid Controller	33
4.11.3	Requirements for black start	34
4.11.4	Preparing for black start	34
4.11.5	Running black start	35
4.12	Handling System Settings	36
4.12.1	Information on configuration files	36
4.12.2	Functions for configuration files	36
4.12.3	Download configuration file	37
4.12.4	Adjusting the System Settings	37
4.12.5	Ending System Settings	39
4.12.6	Saving System Settings	39
4.12.7	Restart with saved system settings	40
4.12.7.1	Restoring system settings after a software update	40
4.12.7.2	Restart with a configuration file	40
4.12.7.3	Restart with saved parameters	41
4.12.8	Deleting System Settings	41
4.13	Device Administration	42
4.13.1	Activating device	42
4.13.2	Disabling a device	42
4.14	System History	43
4.14.1	Overview of the Data Structure	43
4.14.2	Maximum Availability of System History	43
4.14.3	Viewing System History Data	44
4.14.4	Setting storage intervals	44
4.15	Time planning	44
4.15.1	Principle of time planning	44

4.15.2	Setting the system time	45
4.15.3	Requirements for XML files for time planning.....	45
4.15.3.1	Specifications for XML file names.....	45
4.15.3.2	Specifications on file structure and on file elements.....	47
4.15.3.3	Valid function types in XML files.....	48
4.15.4	Creating time plans.....	51
4.15.4.1	Requirements for creating time plans	51
4.15.4.2	Data to add the Hybrid Controller as new host in the FTPS software	52
4.15.4.3	Creating time plans	52
4.15.5	Activating/deactivating time plans.....	53
4.15.5.1	Active time plans	53
4.15.5.2	Example for deleting an XML file	53
4.15.5.3	Activating/deactivating time plans	53
4.16	Reset.....	54
4.16.1	Modes for resetting the product	54
4.16.2	Resetting the Product	54
5	Starting and Stopping the System	56
5.1	Safety when starting and stopping	56
5.2	Starting the product.....	56
5.3	Stopping the product	57
5.4	Performing restart	57
6	Troubleshooting	59
6.1	Event messages	59
6.1.1	Using the scrollbar	59
6.1.2	Filter function	59
6.1.3	Overview of event messages	59
6.1.4	Processing Event Messages	59
6.2	Errors in the Hybrid Controller	60
7	Contact	62

1 Information on this Document

1.1 Validity

This document is valid for:

- HYBRID CONTROLLER (SMA Hybrid Controller integrated in the SMA Power Plant Manager) as of firmware version 02.22.xx.R
- HYBRID CONTROLLER (SMA Hybrid Controller as assembly unit on DIN rail) as of firmware version 02.22.xx.R

1.2 Target Group

The tasks described in this document must only be performed by qualified persons. Qualified persons must have the following skills:

- Training in the installation and configuration of IT systems
- Knowledge of how the product works and is operated
- Training in how to deal with the dangers and risks associated with installing, repairing and using electrical devices and installations
- Training in the installation and commissioning of electrical devices and installations
- Knowledge of all applicable laws, standards and directives
- Knowledge of and compliance with this document and all safety information

1.3 Content and Structure of this Document

This document includes the configuration, operation and troubleshooting of the product.

You will find the latest version of this document and further information on the product in PDF format at www.SMA-Solar.com.

Illustrations in this document are reduced to the essential information and may deviate from the real product.

1.4 Levels of Warning Messages

The following levels of warning messages may occur when handling the product.

DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates a situation which, if not avoided, can result in property damage.

1.5 Symbols in the Document

Symbol	Explanation
	Information that is important for a specific topic or goal, but is not safety-relevant
<input type="checkbox"/>	Indicates a requirement for meeting a specific goal
<input checked="" type="checkbox"/>	Required result
	Example

1.6 Typographies in the document

Typography	Use	Example
bold	<ul style="list-style-type: none"> Messages Terminals Elements on a user interface Elements to be selected Elements to be entered 	<ul style="list-style-type: none"> Connect the insulated conductors to the terminals X703:1 to X703:6. Enter 10 in the field Minutes.
>	<ul style="list-style-type: none"> Connects several elements to be selected 	<ul style="list-style-type: none"> Go to Settings > Date.
[Button] [Key]	<ul style="list-style-type: none"> Button or key to be selected or pressed 	<ul style="list-style-type: none"> Select [Enter].
#	<ul style="list-style-type: none"> Placeholder for variable components (e.g., parameter names) 	<ul style="list-style-type: none"> Parameter WCtHz.Hz#

1.7 Designations in the Document

Complete designation	Designation in this document
SMA Hybrid Controller	Hybrid Controller, product
SMA Hybrid Controller as assembly unit on DIN rail	Assembly unit
SMA Power Plant Manager	Power Plant Manager, PPM
SMA Solar Technology AG	SMA
Sunny Tripower, Sunny Central	PV inverter
Sunny Tripower Storage, Sunny Central Storage	Battery inverter

1.8 Explanation of Used Terms

Term	Explanation
Plant router	Router in the local network of the system operator with access to the Internet
Genset	Electric generator with combustion engine
Genset controller	System for the regulation and control of electric generators with combustion engine
Electrolyzer	An electrolyzer is a technical system that splits water into its components hydrogen and oxygen. This splitting takes place using an electric current that is passed through the water.
Hybrid System	System for the control of energy flows based on a programmable logic controller (e.g. SMA Hybrid Controller or Power Plant Manager) Various energy sources can be integrated into a hybrid system (e.g. PV power plant, genset or battery-storage system).
Root Mean Square Value (RMS)	Mean square value of a time-varying physical quantity, e.g. an alternating voltage (root-mean-square value)

1.9 Additional Information

The following table provides some important additional information. Additional documents and language versions are available at www.SMA-Solar.com.

Title and information content	Type of information	Hyperlinks
"PUBLIC CYBER SECURITY - Guidelines for a Secure System Communication"	Technical Information	CyberSecurity-TI-en-xx.pdf
"SMA HYBRID CONTROLLER - Parameters and Display Values"	Technical Information	Parameter-HyCon-TI-en-xx
Device-specific overview of all parameters and measured values and their setting options	Technical Information	
"Use of Gensets in hybrid systems with SMA Hybrid Controller"	Technical Information	HyCon-Gensets-TI-en-xx
Communication interface requirements and Genset Controller configuration	Technical Information	

Title and information content	Type of information	Hyperlinks
SMA POWER PLANT MANAGER (PPM-10)	Installation Manual	PPM-10-IA-en-18
Description regarding installation, commissioning and decommissioning		
SMA POWER PLANT MANAGER (PPM-11)	Installation Manual	PPM-11-IA-en-10
Description regarding installation, commissioning and decommissioning		

2 Safety

2.1 Intended Use

Together with SMA inverters, the SMA Hybrid Controller forms a system solution for setting up hybrid systems with PV power plants, battery storage systems and, if required, with gensets or utility grid. The Hybrid Controller continuously monitors the power output of the SMA inverters as well as the operating state of all gensets and loads in the local utility grid. On this basis, the Hybrid Controller controls the SMA inverters and adjusts its output power, where necessary.

In the product option with Power-to-Gas function, the power converters of the Electrolyze Converter UP [EC UP] type connected to the Hybrid Controller, generate the direct current from the medium-voltage grid required for electrolysis.

Only use gensets that adhere to the reverse-power and overload limits of the Hybrid Controller.

The power management and communication interface of the gensets must be compatible with the Hybrid Controller for optimal operation. Therefore, the combined use of the Hybrid Controller and the gensets must be coordinated with SMA (see technical information "Use of Gensets in hybrid systems with SMA Hybrid Controller").

The inverter data must only be retrieved via the Hybrid Controller. During commissioning, the correct setup of the system network is documented. Unauthorized configuration changes of the system network after commissioning will result in any warranty or warranty claims becoming null and void.

The inputs for current and voltage measuring are designed for four-conductor grids with three line conductors and one neutral conductor as well as for three-conductor grids with three line conductors. If another grid type is used, the connection of the measuring device must be coordinated with SMA Solar Technology AG.

The Hybrid Controller has a Modbus/TCP and CAN interface for communicating with peripheral devices. Ensure that all communication between the Hybrid Controller and the gensets takes place via either the Modbus/TCP interface or the CAN interface.

The products by SMA Solar Technology AG are not suitable for use in

- Medical devices, in particular products for supplying life-support systems and machines,
- Aircraft, the operation of aircraft, the supply of critical airport infrastructure and airport systems,
- Rail vehicles, the operation and supply of rail vehicles and their critical infrastructure.

The above list is not exhaustive. Contact us if you are unsure whether products by SMA Solar Technology AG are suitable for your application.

Use SMA products only in accordance with the information provided in the enclosed documentation and with the locally applicable laws, regulations, standards and directives. Any other application may cause personal injury or property damage.

The documentation must be strictly followed. Deviations from the described actions and the use of materials, tools, and aids other than those specified by SMA Solar Technology AG are expressly forbidden.

Alterations to the SMA products, e.g., changes or modifications, are only permitted with the express written permission of SMA Solar Technology AG. Unauthorized alterations as well as failure to observe the documentation will void guarantee and warranty claims and in most cases terminate the operating license. SMA Solar Technology AG shall not be held liable for any damage caused by such changes.

Any use of the product other than that described in the Intended Use section does not qualify as appropriate.

The documentation supplied is an integral part of SMA products. Keep the documentation in a convenient, dry place for future reference and observe all instructions contained therein.

This document does not replace any regional, state, provincial, federal or national laws, regulations or standards that apply to the installation, electrical safety and use of the product. SMA Solar Technology AG assumes no responsibility for the compliance or non-compliance with such laws or codes in connection with the installation of the product.

The type label must remain permanently attached to the product.

2.2 IMPORTANT SAFETY INFORMATION

Keep the manual for future reference.

This section contains safety information that must be observed at all times when working.

The product has been designed and tested in accordance with international safety requirements. As with all electrical or electronical devices, some residual risks remain despite careful construction. To prevent personal injury and property damage and to ensure long-term operation of the product, read this section carefully and observe all safety information at all times.

DANGER

Danger to life due to electric shock when live components or cables are touched

High voltages are present in the conductive components or cables of the product. Touching live parts and cables results in death or lethal injuries due to electric shock.

- Do not touch non-insulated parts or cables.
- Before performing any work or opening the product, short-circuit the secondary circuits of the current transformers using an external short-circuiting device, externally disconnect the connection cables of the measurement systems, and disconnect the supply voltage of the product.
- Observe all safety information on components associated with the product.
- Wear suitable personal protective equipment for all work on the product.
- Always perform all work in accordance with the locally applicable standards, directives and laws.

⚠ WARNING**Danger to life due to electric shock when supposedly de-energized components or cables are touched after a black start**

If a black start is triggered by the product, switched-off energy sources, such as battery inverters or gensets, can be switched on again. By switching energy sources on again, supposedly de-energized parts or cables may be live. Touching live parts and cables results in death or lethal injuries due to electric shock.

- Disconnect the energy sources in the system from voltage sources and make sure it cannot be reconnected before working on the device.
- Observe the safety information in terms of energy sources during all work on the system (see manufacturer documentation).

⚠ WARNING**California Proposition 65**

The product can expose you to hazardous substances including antimony trioxide and diethylhexyl phthalate (DEHP). These chemicals are known to the State of California to cause cancer and birth defects or other reproductive harm.

- For more information, visit <https://www.P65warnings.ca.gov>.

NOTICE**Damage to the product due to sand, dust and moisture ingress**

Sand, dust and moisture penetration can damage the product and impair its functionality.

- Only open the product if the humidity is within the thresholds and the environment is free of sand and dust.
- The product must not be opened in case of splashing water (e.g. from an irrigation system).
- Do not open the product during a dust storm or precipitation.
- Close the product in case of interruption of work or after finishing work.
- Only operate the product with the doors closed.
- Only operate the product when it is closed.
- Only use the supplied cable glands when inserting cables.

NOTICE**Damage to the product due to condensation**

If the product is moved from a cold environment to a warm environment, condensation may form in the product. This can damage the product or impair its functionality.

- When there are large temperature differences, wait until the product has reached room temperature to connect the voltage supply.
- Make sure the product is dry.

NOTICE

Damage of gensets due to overload of the system network

The system network can be overloaded due to direct communication with individual system components. As a result, control commands from the product can no longer be sent correctly to the system components. This may lead to reverse currents and damage to the gensets.

- Only operate the system network as documented in the acceptance test during commissioning.
- Only retrieve system data from individual system components via the product or system controller.
- Do not communicate directly with the individual system components.

3 User Interface

3.1 Requirements for the user interface display

- A computer for displaying the user interface must be available.
- The computer must be connected to the Hybrid Controller via Ethernet.
- A web browser must be installed on the computer.
- JavaScript must be enabled in the web browser.
- In the operating system and in the web browser, anti-aliasing must be activated.
- The IP address of the Hybrid Controller sent from the DHCP server to the local network of the PV system operator must be known.
- The respective latest version of one of the following web browsers must be installed on the smart terminal device: Chrome, Edge, Firefox or Safari.
- Minimum display resolution: 800 x 600 pixels
- Recommended display resolution: from 1280 x 1024 pixels

3.2 Design of the User Interface




Figure 1: User interface (example)

Position	Designation	Explanation
A	Header	Allows access to the main functions of the user interface. Indicates the current path, e.g. Home > Settings > Network Settings .
B	Content area	Depending on the selected page, display values, adjustable parameters or a combination of display values and adjustable parameters are shown in the content area. Additional buttons are available on individual pages.

Position	Designation	Explanation
C	Status bar	<p>Displays the following information:</p> <ul style="list-style-type: none"> • Display of the operating state via Status: <ul style="list-style-type: none"> - BOOT: The product is starting. - INIT: The product is initializing. - WAIT: The product is establishing communication with the other devices. In this operating state, no setpoints for active and reactive power are transferred. - STANDBY: The product is in standby mode. - MANUAL: The product is in manual mode. The setpoint values for the active and reactive power of the PV power plant are set via the user interface. - OPERATE: The product is in automatic mode and specifies the setpoints for the active and reactive power of the PV power plant. If the product is connected to a SCADA system, it will use the setpoints from the SCADA system in automatic mode. - SAFETY: The product has switched to a safe state following an error. The PV power can be reduced compared with operation in automatic mode. - ERROR: There is an error in the product. Automatic operation is interrupted. • Access level: User group that you are logged in with • Software version: Current software version of the product • Serial Number: serial number of the device • Date and time
D	Page and menu selection	Access to the various pages and menus of the user interface

3.3 Buttons in the header

Symbol	Designation	Description
	Home	Use this symbol to access the home page.
	Return	Use this symbol to go back to the previous page.
	Plausibility checks	Use this symbol to directly access the page Plausibility Checks . The symbol displays the number of messages.

Symbol	Designation	Description
	Plant ¹⁾	An overview of the display values can be shown via this symbol (for additional information on the display values, see Technical Information "Parameters and Measured Values").
	Control ¹⁾	Use this symbol to set various parameters relating to system control (for additional information on the parameters, see Technical Information "Parameters and Measured Values").
	Wizard ¹⁾	Use this symbol to select the configuration wizard and edit the system settings (for additional information on the parameters, see Technical Information "Parameters and Measured Values").
	Export ¹⁾	Use this symbol to select the following functions: <ul style="list-style-type: none"> Save current system settings Load saved system settings Delete saved system settings
	Events	Use this symbol to directly access the event messages.
	Logout	Use this symbol to log out of the system.

3.4 User Groups and User Rights

User rights	User group	User	Installer
Retrieve display values of the entire system and its subsystems, e.g. the gensets, the PV power plant or the load controller		✓	✓
Setting the parameters of the entire system and subsystems		-	✓
Ending system settings		-	✓
Saving System Settings		-	✓
Loading System Settings		-	✓
Deleting System Settings		-	✓
Activating or deactivating devices		-	✓
Setting the control functions of the entire system and subsystems		-	✓
Retrieving data for acquisition of measured values		✓	✓
Retrieving event and error messages		-	✓

¹⁾ To use this button you must be logged in as an Installer.

3.5 Home Page for User Group "User"




Figure 2: Home page for user group **User** (example)

The home page shows an overview of the display values for the user group User (for additional information on the display values, see Technical Information "SMA HYBRID CONTROLLER - Parameters and Display Values").

3.6 Home Page for User Group "Installer"




Figure 3: Home page for user group **Installer** (example)

Button	Description
System overview	Access to the display values (see Technical Information "SMA HYBRID CONTROLLER - Parameters and Display Values")
Control Functions	Access to the control system (see Technical Information "SMA HYBRID CONTROLLER - Parameters and Display Values")
Configuration Wizard	Access to the system settings (see Technical Information "SMA HYBRID CONTROLLER - Parameters and Display Values")
Parameter Files	Saving the current system settings and loading/deleting saved system settings
Schedules	Access to temporary settings of different functions and parameters from system control

Also see:

- Handling System Settings ⇒ page 36
- Time planning ⇒ page 44

3.7 Configuration Wizard

3.7.1 Structure of the Configuration Wizard

To use the configuration wizard you must be logged in as an **Installer**.




Figure 4: Home page of the configuration wizard (example)

Position	Designation	Explanation
A	Automatic configuration	The automatic configuration wizard guides you through the configuration of the entire system. During initial commissioning, the automatic configuration wizard must be run completely. In the Manual configuration area the completion status for each subsystem is displayed in %. Once the completion status has reached 100% for all subsystems, automatic configuration is completed.
B	Manual configuration	<p>After commissioning, use the manual configuration wizard to carry out settings on individual subsystems (for additional information on the parameters, see Technical Information "SMA HYBRID CONTROLLER - Parameters and Display Values"):</p> <ul style="list-style-type: none"> • System: Entire system • UtilityGrid: Utility grid • Genset system: Gensets • PV system: PV power plant • Battery system: Storage system • Measurement system: Measurement devices • Meteorological data: Temperature and irradiation sensors • Digital input/output: Digital inputs and outputs

3.7.2 Buttons in the Configuration Wizard

To use the configuration wizard you must be logged in as an **Installer**.

Button	Description
Add new item	Add device type, e.g. a type of inverter
Adjust	Adjust configuration of a subsystem
Apply	<p>Save system settings</p> <p>This saves all system settings in the active dialog. If you exit the active dialog without saving the system settings, any system settings made since the last save will be discarded.</p>
Continue Wizard	Continue to the next dialog
Delete config.	Delete configuration of a subsystem
Discard	<p>Discard system settings</p> <p>Any system settings made in the active dialog and not saved by pressing the Apply button will be discarded.</p>
Done	Close the active dialog and switch to the overview of current system settings

Button	Description
Remove item	Remove device type, e.g. a type of inverter
Start	Start automatic configuration wizard

4 Operation

4.1 Setting the User Interface Language

1. Enter the IP address of the Hybrid Controller (e.g. **172.16.1.21**) in the address bar of the web browser and press Enter.
2. Select your language in the **Language** area from the **Select** drop-down list.
3. Select the **[Apply]** button.
4. Log into the user interface.

4.2 Logging Into the User Interface

4.2.1 Protection from unauthorized access

NOTICE

Property damage due to unauthorized access to adjustable parameters

All adjustable parameters are protected by the password of the user group **Installer**. Providing the password to unauthorized persons can lead to incorrect parameters being input, resulting in damage to devices and system malfunctions.

- Only give the password for the user group **Installer** to qualified persons.

i Lock time if the password is entered incorrectly

When the password is entered incorrectly the first time, a lock time takes effect, which increases with each additional wrong entry. The password can only be entered again after the lock time has expired.

- Enter the correct password after the lock time has expired.

4.2.2 Maximum number of logins

A maximum of 5 **Users** and 1 **Installer** can be logged into the user interface simultaneously. Users are not automatically logged out by closing the web browser. Therefore we recommend always logging out of the user interface prior to closing the web browser.

4.2.3 Automatic logout

If a user has not shown any activity on the user interface for more than 30 minutes, this user will be warned that he is about to be logged out automatically. If this warning is not acknowledged within 10 seconds, the user is automatically logged out.

4.2.4 Example: allocation of IP addresses

If the IP address of the Hybrid Controller is set to **172.16.1.21** (default setting), the IP address for the computer with the user interface could be e.g. **172.16.1.200**. It is important that the network portion of both IP addresses matches (in this case **172.16**). The subnet mask is **255.255.0.0**.

4.2.5 Only during commissioning: log in with the standard password

To protect your product from unauthorized access, immediately change your standard password to a secure password.

Requirements:

- The IP address of the Hybrid Controller and the subnet mask must be known.
- The computer used to display the user interface must have an IP address located in the same subnet as the IP address of the Hybrid Controller.

Procedure:

1. Enter the IP address of the Hybrid Controller (e.g. **172.16.1.21**) in the address bar of the web browser and press Enter.
2. Select the **Installer** user group from the **Access Level** drop-down list in the **Login** area.
3. Enter the standard password **1111** and press Enter.
4. Select the button [**Login**].
 - The prompt for changing the standard password for the **Installer** user group is displayed.
5. Enter a password of your choice for the **Installer** user group and press Enter.
6. Repeat the entry of the password you chose yourself and press Enter.
7. Press the button [**Change password**].
 - The prompt for changing the standard password for the **User** user group is displayed.
8. Enter the standard password **0000** and press Enter.
9. Enter a password of your choice for the **User** user group and press Enter.
10. Repeat the entry of the password you chose yourself and press Enter.
11. Press the button [**Change password**].

4.2.6 Logging in with secure password

Requirements:

- The IP address of the Hybrid Controller and the subnet mask must be known.
- The computer used to display the user interface must have an IP address located in the same subnet as the IP address of the Hybrid Controller.

Procedure:

1. Enter the IP address of the Hybrid Controller (e.g. **172.16.1.21**) in the address bar of the web browser and press Enter.
2. Select the **User** or **Installer** user group from the **Access Level** drop-down list in the **Login** area.
3. Enter the secure password for the **User** or **Installer** user group and press Enter.
4. Select the button [**Login**].

5. If the message **Login error - Maximum user sessions reached** appears, the maximum number of logins for the selected user group has been reached. To resume the login, answer the question **Would you like to send a force log in request?** with **Yes**. This notifies users that are already logged in of your request. You will then receive a message regarding the success or failure of your request.
6. If the message **Login error - User level or password incorrect** appears, the password entry was not correct.
7. Enter the secure password after the lock time specified by the product has expired
8. If you do not remember the secure password, contact Service.

4.2.7 Logout

- Click the logout link in the header.

4.2.8 Disable lock screen

If a user has not shown any activity on the user interface for more than 10 minutes, a lock screen will be activated. The lock screen shows current performance diagrams of the hybrid system.

Procedure:

- To disable the lock screen, move the cursor over the screen and select button.
 The page of the user interface last selected is displayed.

4.3 Changing the Password

Requirements:

- To change the password for the user group **User**, you must be logged in as **User**.
- To change the password for the user group **Installer**, you must be logged in as **Installer**.

Procedure:

1. Only if you are logged in as Installer, select the **System overview** menu via the page and menu selection.
2. Go to **Home > Settings > Password settings** via the page and menu selection. To do this, select the down arrow button on the scroll bar next to the page and menu selection.
3. Type the current password in the **Current password:** input field and press the Enter key.
4. Type the new password in the **New password:** input field and press the Enter key.
5. Enter the current password in the **Please repeat new password:** input field and press the Enter key.
6. Select the **[Apply]** button.

4.4 Setting the System Time and Location

1. Only if you are logged in as **Installer**, select the **System Overview** menu via the page and menu selection.

2. Go to **Home > Settings > Time and geographical location** via the page and menu selection (for further information on the parameters, see Technical Information "Parameters and Measured Values").
3. Enable the **Use SNTP client** checkbox in the **Time** area. Set the **Address of SNTP server** and **Time interval** parameters to the preferred values also.
4. To set the system time manually, disable the **Use SNTP client** checkbox and set the **Date** and **Time** parameters to the preferred values.
5. In order to set use as an SNTP server for other devices, activate the **Start SNTP server** checkbox.
6. Select the **[Apply]** button.
7. Set the **GeoCoordLat** and **GeoCoordlong** parameters to the preferred values in the **Geographical location** area.

4.5 Access from the Internet

4.5.1 Access to operating data by SMA Service

In order to provide quick assistance in the event of a disturbance, SMA Service requires access to the operating data of the Hybrid Controller. Access to the operating data enables a detailed analysis of the existing error and therefore speeds up troubleshooting.

4.5.2 Secure VPN connection

Ensure data security in networks

When accessing via the Internet, there is a risk that unauthorized users may access and manipulate the data or devices in your system. Appropriate protective measures can include the following:

- Set up a firewall.
- Close unnecessary network ports.
- Only enable remote access via VPN tunnel.
- Do not set up port forwarding at the communication port in use.

The product is prepared to establish a secure VPN connection to Service. The VPN connection is based on the IPsec protocol and is established by the product-internal router. To allow smooth operation, access from the local network of the system operator to the product is only permitted via the following data channels:

- FTPS interface to the product via port 22 of the TCP protocol
- Interface of the product to the SCADA system via port 502 of the TCP protocol
- Web browser for the user interface via port 443 of the TCP protocol

The product-internal router enables the use of these data channels by means of port forwarding via the system router.

Also see:

- [Setting up access via the Internet ⇒ page 27](#)

4.5.3 Setting up access via the Internet

Requirements:

- The system router must enable exclusive access for the product-internal router via ports 500 and 4500 of the UDP protocol for IP address 194.176.121.155 of the SMA Solar Technology AG.

Procedure:

1. Configure the system router in such a way that the secure VPN connection is enabled for Service.
2. Make sure that the product-internal router has established an Internet connection.
3. Inform Service.

Service will check whether the product-internal router has established a VPN connection.

Also see:

- Access to operating data by SMA Service ⇒ page 26
- Secure VPN connection ⇒ page 26

4.6 Internal Communication Network

4.6.1 IP address of programmable logic controller in Hybrid Controller

The IP address of the first LAN interface (**ETH 1**) of the programmable logic controller in the Hybrid Controller is factory-set to **172.16.1.21** and the subnet mask to **255.255.0.0**. The IP address of the second LAN interface (**ETH 2**) of the programmable logic controller in the Hybrid Controller is factory-set to **192.168.100.21** and the subnet mask to **255.255.255.0**. The IP address of the optional router in the Hybrid Controller is **172.16.1.11**. All IP addresses proposed in this section are based on these settings.

- If the IP addresses of the Hybrid Controller are changed, check all other IP addresses in the internal communication network.
- Ensure that the IP addresses of the Hybrid Controller and all other devices are in the same subnet.

4.6.2 Assigning IP Addresses for Internal Communication Network

The Hybrid Controller controls and monitors the connected devices, such as gensets and inverters, via the internal communication network. The IP addresses must be assigned statically to ensure efficient communication. The recommendations of this section should be taken into account.

Block of IP address	Recommendation
A	Block A of the IP address is a prefix. It must be set to 172 .

A Block A of the IP address is a prefix. It must be set to **172**.

Block of IP address	Recommendation
B	Block B of the IP address is the system number. It must be set to 16 . If 16 is not available for Block B in local network of the system operator, the setting of the system number must be changed in the Hybrid Controller.
C	Block C of the IP address contains the station number. Stations summarize the devices at a single location and enable you to see at a glance where each device is to be found.
D	Block D of the IP address contains the device number.

4.6.3 Recommendation for station numbers

Number	Designation
1	Hybrid Controller
3	Genset controller
10 to 19	Measuring points that are not assigned to a station
100 to 120	Sunny Central Storage
200 to 240	PV inverters (Sunny Tripower, Sunny Central CP XT)
xxx	Devices that are assigned to any station

4.6.4 Recommendations for device numbers

Station Number	Designation	Device Number	Designation
1	Hybrid Controller	11	Router in the Hybrid Controller
		21	Programmable logic controller in the Hybrid Controller
3	Genset controller	1 to 70	Genset controller
10 to 19	Measuring points that are not assigned to a station	71 to 79	Power analyzers (e.g. Data Acquisition Module)
100 to 120	Sunny Central Storage	51	Communication unit SC-COM for the first Sunny Central Storage
		52	Communication unit SC-COM for the second Sunny Central Storage
		111	Communication interface of the Battery System Controller

Station		Device	
Number	Designation	Number	Designation
200 to 240	PV inverters (Sunny Tripower, Sunny Central CP XT)	1 to 70	String inverter
		41 to 50	SMA Inverter Manager Sunny Central Storage
		51 to 52	Central inverter
xxx	Devices that are assigned to any station	71 to 79	Power analyzers (e.g. Data Acquisition Module)
		81 to 89	Temperature and irradiation sensors
		91 to 99	Managed switches
		250 to 254	Communication devices (e.g. SMA Data Manager M or SMA Data Manager L)

4.6.5 Example for allocation of IP addresses

The following example illustrates the allocation of IP addresses in the internal communication network of the hybrid system:

Station	Device	IP address
Hybrid Controller	Router in the Hybrid Controller	172.16.1.11
	Programmable logic controller in the Hybrid Controller	172.16.1.21
Genset controller	1. Genset Controller	172.16.3.1
	2. Genset Controller	172.16.3.2
PV inverter	1. PV inverter (e.g. Sunny Tripower)	172.16.200.1
	2. PV inverter (e.g. Sunny Tripower)	172.16.200.2

4.6.6 Setting the IP addresses on the Hybrid Controller

Requirements:

- You must be logged in as **Installer**.

Procedure:

1. Choose the menu **System overview** via the page and menu selection.
2. Go to **Home > Settings > Network settings** via the page and menu selection.
3. Set the IP addresses at **Ethernet adapter 1** for the internal communication network of the hybrid system.

4. Optionally for the additional internal communication network of the hybrid system, set the IP address under **Ethernet adapter 2**.
5. Set the IP addresses at **IP address DNS server** and **IP address gateway** for the external communication network.

4.7 Setting up communication with the SCADA system

1. Only if you are logged in as **Installer**, select the **System overview** menu via the page and menu selection.
2. Go to **Home > Settings > SCADA settings** via the page and menu selection.
3. Set the parameters how you would like them (for additional information on the parameters, see Technical Information "SMA HYBRID CONTROLLER - Communication with SCADA System").
4. Select the **[Apply]** button.

4.8 Retrieving Display Values

1. Only if you are logged in as **Installer**, select the **System overview** menu via the page and menu selection.
2. Choose the path via the page and menu selection, e.g. **Home > Stations > PV system** for the display values of the PV inverters (for further information on the display values, see Technical Information "SMA HYBRID CONTROLLER - Parameters and Display Values").

4.9 Configuring the Operating Mode

NOTICE

Damage to the PV inverters, gensets, or loads caused by the input of incorrect setpoints

In **Manual** mode, the setpoints for the PV inverters and the reserve power to be kept by the gensets are specified via the user interface. If the specifications are incorrect, the technical thresholds of the PV inverters, gensets, or loads can be exceeded. An exceeding of technical thresholds can lead to damage of the PV power plant, gensets or loads.

- For continuous operation of the Hybrid Controller, always use the **Automatic** operating mode.
- Only activate the **Manual** operating mode in temporary and exceptional situations (e.g., when carrying out maintenance).
- Verify that when **Manual** operating mode is active that at least two persons are monitoring the technical thresholds for PV inverters, gensets, and loads.

If the Hybrid Controller remains in the operating mode **Manual** for five minutes and no user is logged in, the Hybrid Controller switches automatically to the operating state **Standby** via the **SLOW STOP** mode.

Requirements:

- You must be logged in as **Installer**.

Procedure:

1. Choose the menu **System overview** via the page and menu selection.
2. Go to **Home > Operations > Control Mode** via the page and menu selection.
3. Select the **[Activate]** button in the **Activate automatic mode** bar to activate **Automatic** mode.
4. To activate **Manual** mode, select the **[Activate]** button in the **Activate manual mode** bar.
5. To deactivate **Manual** mode, activate **Automatic** mode or select the logout button in the header.

4.10 Setting Parameters for System Control

NOTICE**Property damage due to power supply failure caused by unexpected stop of a genset due to reverse power protection**

To ensure that a genset is protected from backfeed damage, reverse power protection must be enabled and configured in the Hybrid Controller and the genset. The parameters on the Hybrid Controller and the genset must be configured so that the reverse power protection is always triggered at the Hybrid Controller first. If the reverse power protection first triggers in the genset, this results in an unexpected stop of the genset which cannot be foreseen by the Hybrid Controller. Unexpected stop of a genset can lead to a total power supply failure.

- Only use gensets with reverse power protection which fulfill the reverse power limits of the Hybrid Controller (see installation manual of the product).
- Ensure that the reverse power protection of the gensets is always active during operation.
- Adjust the reverse power protection parameters to ensure that reverse power protection always triggers first at the Hybrid Controller and only then at the genset.

NOTICE**Destruction of gensets due to overload caused by insufficient reserve power**

If the current reserve power of the gensets is insufficient, switch off the loads or connect additional gensets. This increases the reserve power of the gensets.

- Prior to stopping the Hybrid Controller, always check whether the current reserve power of the gensets is sufficient to cover the requirement of the loads.
- If the power management and the communication interface of the genset are not compatible with the Hybrid Controller, power management must be deactivated on the Hybrid Controller. In this case, the gensets must be monitored to ensure that sufficient genset reserve power is retained.
- Make sure that the setpoints for power management on the Hybrid Controller and the gensets are set to the same value.

NOTICE

Property damage due to power outage caused by power fluctuations in the PV power plant

If the communication between the Hybrid Controller and the inverters is interrupted, the inverters will operate according to their fallback settings. When communication is restored, power fluctuations may occur if the fallback settings of the inverters deviate from the fallback settings of the Hybrid Controller. These power fluctuations can result in failure of the power supply.

- Ensure that the fallback settings of the inverters match the fallback settings of the Hybrid Controller.

Requirements:

- You must be logged in as **Installer**.

Procedure:

1. Select the path via the page and menu selection, e.g. for controlling the grid feed-in **Home > Control Functions > Utility grid > Feed-in protection**.
2. To change parameters with an entry field, enter new values and press Enter after each entry. By pressing Enter, the entered value is adopted in the user interface.
3. To change parameters with a checkbox, activate the required checkbox.
4. To change parameters with a drop-down list, select the desired value in the appropriate drop-down list.
5. If the border of the input field flashes red, check the input and set the parameter to a valid value. To do this, repeat the previous step.
6. To discard current parameter settings, select the [**Discard**] button.
7. To adopt current parameter settings in the control, select the [**Apply**] button.
8. Only applies for settings regarding MPP estimate for PV power plants: Ensure that the settings of the **MppNormOpCellTemp** and **MppPwrTempCoeff** parameters of the **MPP Estimation** function corresponds to the technical data of the PV modules (for further information see Technical Information "SMA HYBRID CONTROLLER - Parameters and Display Values").

4.11 Black start

4.11.1 Safety during black start

NOTICE

Damage to equipment and electrical loads through high compensating currents

Unplanned electrical loads and energy sources switching on and off can occur during a black start. These switching processes can cause high compensating currents. Equipment and loads can become damaged due to these compensating currents.

- Disconnect the energy sources and loads from the utility grid before the black start.
- When doing any work involving a black start, follow the local guidelines on turning on low- and medium-voltage and the system-specific start-up sequence.

Also see:

- Preparing for black start ⇒ [page 34](#)
- Running black start ⇒ [page 35](#)

4.11.2 Sequence of a black start with Hybrid Controller

A black start is the process of ramping up a power plant without existing power supply and restoring the power supply. This is of particular relevance during a total blackout or in case of stand-alone grids.




Figure 5: Sequence of a black start with Hybrid Controller

Time period	Explanation
A	All energy sources and loads in the stand-alone grid are switched off. All medium-voltage components (medium-voltage transformers and medium-voltage switchgear) are connected to the stand-alone grid in a de-energized state. Hybrid Controller receives the command for a black start.

Time period	Explanation
B	The Hybrid Controller checks whether all energy sources in the system are switched off and if the hybrid system is in a de-energized state. Once the de-energized state has been confirmed, the Hybrid Controller starts the first battery inverter capable of black start. Initially, the battery inverter provides a start AC voltage for the stand-alone grid. This start AC voltage can be configured, but usually is 20 percent of the nominal output voltage of the battery inverter.
C	At this voltage level, the Hybrid Controller connects all other battery inverters capable of black start.
D	The Hybrid Controller then controls all battery inverters capable of black start in such a way that the inverters raise their output voltage evenly to 100% of the nominal voltage. The time of the voltage ramp can also be configured. If the start AC voltage has already been set to 100%, no voltage ramp becomes effective during period D.
E	All battery inverters capable of black start feed in with 100% of their nominal voltage. The black start is complete. The Hybrid Controller can relay the message of the black start completion via a digital output. Other energy sources and loads can now be connected one by one.

4.11.3 Requirements for black start

- At least one battery inverter must be capable of doing a black start. The battery inverter must include the options "External auxiliary power supply" and "Grid-forming inverter with DC pre-charge" to be able to do this (see the inverter's manual).
- The black start function must be activated in the Hybrid Controller's firmware (optional software).

Also see:

- [Preparing for black start ⇒ page 34](#)
- [Running black start ⇒ page 35](#)

4.11.4 Preparing for black start

1. Ensure that the gensets and all other grid-forming energy sources are switched off and that they cannot be reconnected. This should prevent accidental feed-in by a genset or another energy source.
2. If a utility grid or other neighboring utility grids are present, disconnect all grid connections and secure them against being switched back on. This should prevent accidental feed-in by another utility grid.
3. Ensure that all loads that react sensitively to low grid voltage are disconnected from the grid.
4. Open the Hybrid Controller user interface and log in as "Installer".
5. Follow the path **Home > Control Functions > Battery Isolated Operation > Black start** and set the parameters for the black start.

6. Check whether the grid voltage is 0 V. If the grid voltage is not 0 V, check the status of all energy sources. Power down and shut off all energy sources that are still active.
7. If the Hybrid Controller is in the **ERROR** operating state, check whether error messages are displayed.
8. If error messages are displayed, find the cause of the error and fix it. Now confirm the error messages.
9. Wait until Hybrid Controller is in operating state **SAFETY**.
 Hybrid Controller is able to run the black start.
10. If the Hybrid Controller does not go into operating state **SAFETY**, contact Service.

Also see:

- [Safety during black start ⇒ page 33](#)
- [Requirements for black start ⇒ page 34](#)

4.11.5 Running black start

Requirements:

- The preparation for the black start has been completed.

Procedure:

1. Switch on the transformers on the inverter and the gensets. This enables a slow magnetization of the transformers during the black start. This prevents voltage fluctuations which could lead to a disruption to the black start.
2. Open the path **Home > Visualization > Battery Isolated Operation** and select the **[Initiate black start]** button.
 - Hybrid Controller runs the black start and, in the process, automatically starts the black start-capable battery inverter. This can take up to 30 seconds.
 - If the message **An error occurred during the black-start process** appears, the black start will cancel automatically.
3. If the black start was interrupted automatically, ensure that the preparations for the black start were made correctly.
4. If the black start has been correctly prepared, confirm the **An error occurred during the black start process** message.
5. If this black start is cancelled again, contact Service.
6. To cancel the black start manually, click on the **[Abort black start]** button.
7. Ensure that all loads that were disconnected from the grid before the black start have been switched back on.
8. Ensure that all grid areas that were disconnected before the black start have been switched back on.
9. Ensure that the gensets and all other grid-forming energy sources are switched back on.

Also see:

- [Safety during black start ⇒ page 33](#)

- Requirements for black start ⇒ page 34

4.12 Handling System Settings

4.12.1 Information on configuration files

The system settings are saved in configuration files. You can overwrite the current configuration file or create a new configuration file.

i Maximum number of configuration files


It is possible to save up to 10 different configuration files with different system settings.

- Once this number has been reached, delete configuration files you no longer need.

Also see:

- Saving System Settings ⇒ page 39
- Deleting System Settings ⇒ page 41

4.12.2 Functions for configuration files



Position	Description
A	<p>Saving the current system settings:</p> <ul style="list-style-type: none"> • Current file: Overwriting an existing configuration file with the current system settings • New file: Creating an additional configuration file with the current system settings

Position	Description
B	<p>Deleting the current system settings or restart with saved system settings</p> <ul style="list-style-type: none"> • Reboot from retained parameters: Restart with saved system settings • Configuration file: Selecting an existing configuration file for restart (Reboot with selected file) or for deletion (Delete selected file)
C	<p>Downloading a configuration file</p> <p>The user interface of the Hybrid Controller provides different configuration files. Each configuration file contains the basic system settings for a specific application.</p>

Also see:

- Saving System Settings ⇒ [page 39](#)
- Restart with a configuration file ⇒ [page 40](#)
- Restart with saved parameters ⇒ [page 41](#)
- Deleting System Settings ⇒ [page 41](#)
- Download configuration file ⇒ [page 37](#)

4.12.3 Download configuration file

The system settings can only be changed in operating state **STANDBY** or **ERROR**. The operating state **STANDBY** can be reached by stopping the system.

Requirements:

- You must be logged in as **Installer**.

Procedure:

1. Choose the path **Home > Parameter files > Load/Save configuration files** via page and menu selection.
2. Choose the parameter file with the required system settings via the drop-down list **File database** in the **Download configuration file** area.
3. Select the **[Download selected file]** button.

4.12.4 Adjusting the System Settings

NOTICE

Property damage due to unauthorized access to adjustable parameters

All adjustable parameters are protected by the password of the user group **Installer**. Providing the password to unauthorized persons can lead to incorrect parameters being input, resulting in damage to devices and system malfunctions.

- Only give the password for the user group **Installer** to qualified persons.

NOTICE

Destruction of gensets due to overload caused by insufficient reserve power

If the current reserve power of the gensets is insufficient, switch off the loads or connect additional gensets. This increases the reserve power of the gensets.

- Prior to stopping the Hybrid Controller, always check whether the current reserve power of the gensets is sufficient to cover the requirement of the loads.
- If the power management and the communication interface of the genset are not compatible with the Hybrid Controller, power management must be deactivated on the Hybrid Controller. In this case, the gensets must be monitored to ensure that sufficient genset reserve power is retained.
- Make sure that the setpoints for power management on the Hybrid Controller and the gensets are set to the same value.

NOTICE

System disruption due to faulty or missing support from the gensets

To successfully operate Hybrid Controller and the gensets, the parameter settings on the gensets and in Hybrid Controller must be adjusted to one another. If parameter settings contradict one another, the gensets may no longer be able to be correctly controlled during operation, and might also no longer start. Faulty or missing support from the gensets can cause a system failure.

- Always follow the specifications in this document when setting parameters for the gensets in Hybrid Controller.
- Always follow the specifications from the manufacturer's documentation when setting parameters for the gensets in the genset controllers.
- Have all the parameter settings for the genset checked during commissioning: By SMA Solar Technology AG Service employees or by qualified persons who were trained in the commissioning of PV diesel hybrid systems by SMA Solar Technology AG.

Requirements:

- You must be logged in as **Installer**.

Procedure:

1. Select the configuration wizard via the page and menu selection.
2. In the bar with the desired sub-system, select the **[Adjust]** button.
3. To change parameters with an entry field, enter new values and press Enter after each entry.
By pressing Enter, the entered value is adopted in the user interface.
4. To change parameters with a checkbox, activate the required checkbox.
5. To change parameters with a drop-down list, select the desired value in the appropriate drop-down list.
6. If the border of the input field flashes red, check the input and set the parameter to a valid value. To do this, repeat the previous step.
7. To discard current parameter settings, select the **[Discard]** button.
8. To adopt current parameter settings in the control, select the **[Apply]** button.

9. If the selected page has a **[Continue wizard]** button, select this button. This opens another page with detailed settings.
10. Select the **[Done]** button.
11. If a storage system is installed, select the path **Home > Control Functions > PV & Battery > State of charge** and activate monitoring for the state of charge limits **Upper SOC operating limit** and **Lower SOC operating limit** (for additional information, see Technical Information "SMA HYBRID CONTROLLER - Parameters and Display Values").
12. End the system settings.

4.12.5 Ending System Settings

The system settings can only be changed in operating state **STANDBY** or **ERROR**. The operating state **STANDBY** can be reached by stopping the system.

Requirements:

- You must be logged in as **Installer**.
- All the setting desired settings regarding the parameters must be finished and confirmed with the **[Done]** button.

Procedure:

1. Save the current settings in a configuration file.
2. Restart the Hybrid Controller with the saved configuration file. This accepts the current settings for ongoing operation. The restart process takes approx. 2 minutes.

Also see:

- [Saving System Settings ⇒ page 39](#)
- [Performing restart ⇒ page 57](#)

4.12.6 Saving System Settings

The system settings can only be changed in operating state **STANDBY** or **ERROR**. The operating state **STANDBY** can be reached by stopping the system.

Requirements:

- You must be logged in as **Installer**.

Procedure:

1. Once the maximum number of 10 configuration files has been reached, delete configuration files you no longer need.
2. Choose the path **Home > Parameter files > Load/Save configuration files** via page and menu selection.
3. To overwrite the current configuration file, select the **[Overwrite]** button in the **Current file** bar.

4. To add a new configuration file, enter the preferred file name in the **New file** bar and press Enter.
 By pressing Enter, the entered value is adopted in the user interface.
5. Select the **[Save]** button.

Also see:

- [Information on configuration files](#) ⇒ page 36

4.12.7 Restart with saved system settings

4.12.7.1 Restoring system settings after a software update

After a software update, the Hybrid Controller restores automatically the system settings from the file that has been saved last. Due to the newly added parameters in the new software version, the Hybrid Controller remains in the operating state **ERROR** and signals the error **2069** until the system settings are saved again and the system has been restarted.

The new parameters, which have been added through an update, can be found in the respective release notes that are included in the software update package.

4.12.7.2 Restart with a configuration file

NOTICE

Power supply failure when the Hybrid Controller is restarted

Before restarting the Hybrid Controller, the Hybrid Controller and PV power plant must be stopped. It can take a few minutes for the Hybrid Controller and PV power plant to stop because the PV inverters have to reduce their output power slowly. If the PV inverters are still feeding energy to the grid when the Hybrid Controller is restarted, this may cause failure of the power supply.

- Once the Hybrid Controller has stopped, wait until the PV inverters have reduced their output power to zero. This can take several minutes.

The system settings can only be changed in operating state **STANDBY** or **ERROR**. The operating state **STANDBY** can be reached by stopping the system.

Requirements:

- You must be logged in as **Installer**.
- The Hybrid Controller and PV power plant must have been stopped (see Section 5, page 56).

Procedure:

1. Choose the path **Home > Parameter files > Load/Save configuration files** via page and menu selection.
2. In the drop-down list **Configuration file** in the area **Delete configuration file or load configuration from configuration file and reboot** select a configuration file.
3. Click on the **[Reboot with selected file]** button.

4.12.7.3 Restart with saved parameters

NOTICE

Power supply failure when the Hybrid Controller is restarted

Before restarting the Hybrid Controller, the Hybrid Controller and PV power plant must be stopped. It can take a few minutes for the Hybrid Controller and PV power plant to stop because the PV inverters have to reduce their output power slowly. If the PV inverters are still feeding energy to the grid when the Hybrid Controller is restarted, this may cause failure of the power supply.

- Once the Hybrid Controller has stopped, wait until the PV inverters have reduced their output power to zero. This can take several minutes.

The system settings can only be changed in operating state **STANDBY** or **ERROR**. The operating state **STANDBY** can be reached by stopping the system.

Requirements:

- You must be logged in as **Installer**.
- The Hybrid Controller and PV power plant must have been stopped.

Procedure:

1. Choose the path **Home > Parameter files > Load/Save configuration files** via page and menu selection.
2. Click on the **[Reboot from retained parameters]** button.

Also see:

- [Starting and Stopping the System](#) ⇒ page 56

4.12.8 Deleting System Settings

The system settings can only be changed in operating state **STANDBY** or **ERROR**. The operating state **STANDBY** can be reached by stopping the system.

Requirements:

- You must be logged in as **Installer**.

Procedure:

1. Choose the path **Home > Parameter files > Load/Save configuration files** via page and menu selection.
2. In the drop-down list **Configuration file** in the area **Delete configuration file or load configuration from configuration file and reboot** select a configuration file.
3. In the bar **Delete selected file**, press **[Delete]**.

4.13 Device Administration

4.13.1 Activating device

The system settings can only be changed in operating state **STANDBY** or **ERROR**. The operating state **STANDBY** can be reached by stopping the system.

Requirements:

- You must be logged in as **Installer**.

Procedure:

1. Select the menu **Configuration Wizard** via the page and menu selection.
2. In the **Measurement System** bar, click on the button **[Adjust]**.
3. In the menu **Measurement devices general configuration**, first click on the button **[Apply]** and then on the button **[Continue wizard]**. This opens the menu **Measurement devices detailed configuration**.
4. In the **Assign measurement points** bar, click on the button **[Show devices]**.
5. Select the appropriate subsystem via **Select a subsystem**.
6. To select one available device, enable the checkbox for this device in the **Select a measurement point** area.
7. To select all available devices, enable the **Select all** checkbox in the **Select a measurement point** area.
8. Click on the **[Add >>]** button.
9. Click on the **[Apply and close]** button.

4.13.2 Disabling a device

The system settings can only be changed in operating state **STANDBY** or **ERROR**. The operating state **STANDBY** can be reached by stopping the system.

Requirements:

- You must be logged in as **Installer**.

Procedure:

1. Select the menu **Configuration Wizard** via the page and menu selection.
2. In the **Measurement System** bar, click on the button **[Adjust]**.
3. In the menu **Measurement devices general configuration**, first click on the button **[Apply]** and then on the button **[Continue wizard]**. This opens the menu **Measurement devices detailed configuration**.
4. In the **Assign measurement points** bar, click on the button **[Show devices]**.
5. To select one available device, enable the checkbox for this device in the **Select a measurement point** area.
6. To select all available devices, enable the **Select all** checkbox in the **Select a measurement point** area.

7. Click on the [**<< Remove**] button.
8. Click on the [**Apply and close**] button.

4.14 System History

4.14.1 Overview of the Data Structure

The product records the system history and saves two files with different data each day:

- One file with data for fast acquisition of measured values
- One file with event and error messages

The files are saved in CSV format and recorded according to the following pattern:

File content	Name structure	Save interval	Path for open access	Read access for user group
Data for fast acquisition of measured values	logDataFast_JJJJ-MM-TT.csv	Can be set Value range: 1 s to 3600 s	/fc0/fsc/log/DataFast	User and Installer
Event and error messages	ErrEvtLog_JJJJ-MM-TT.csv	Cannot be set	/fc0/fsc/log/ErrEvt	only Installer
System settings	-	Cannot be set	/fc0/fsc/param	only Installer

Also see:

- [Viewing System History Data](#) ⇒ [page 44](#)
- [Maximum Availability of System History](#) ⇒ [page 43](#)

4.14.2 Maximum Availability of System History

The maximum number of days for the system history depends on the capacity of the memory card installed:

Capacity of memory card installed	Maximum Availability of System History
512 MB	100 days
1 GB	150 days
2 GB	200 days
4 GB	555 days

However, if there is not enough free space on the installed memory card, there will be correspondingly fewer days available for the system history

Once the period for maximum availability of the system history has expired, the product begins to overwrite the files.

Also see:

- Setting storage intervals ⇒ page 44

4.14.3 Viewing System History Data

Safety settings of FTP server

The FTP server in the Hybrid Controller is deactivated by default for safety reasons.

- To view the system history data, use FTPS or temporarily enable the FTP server via the HyC user interface.

Requirements:

- To access the files, a file management program (e.g., Windows Explorer) or web browser (e.g., Google Chrome) must be installed.
- The file management program or web browser must have an FTPS function.
- To open the files, a spreadsheet program or text editor must be installed.

Procedure:

1. Enter the IP address of the Hybrid Controller **ftps://172.16.1.21** in the address bar of the file management program or web browser.
2. Enter password.
3. Enter the required path.
4. Open the required file.

4.14.4 Setting storage intervals

1. Only if you are logged in as **Installer**, select the **System Overview** menu via the page and menu selection.
2. Open the **General Settings** menu via the page and menu selection.
3. Set the parameter **Log fast interval** to the storage time you would like.
4. Select the **[Apply]** button.

4.15 Time planning

4.15.1 Principle of time planning

Temporary settings for various functions and parameters from the system control for the Hybrid Controller can be stored as XML files. This makes it possible to plan these temporary settings in advance. Hybrid Controller can run the stored XML file and implement the time planning.

Also see:

- Requirements for XML files for time planning ⇒ page 45
- Creating time plans ⇒ page 51
- Activating/deactivating time plans ⇒ page 53

4.15.2 Setting the system time

i Executing time schedules at the wrong time because the system time differs from the time valid on site

When executing the time schedules, the product depends on its own system time. If this system time differs from the locally valid time, the time schedules stored in the product are executed at the wrong time.

- Set the product to automatic default of the system time via an SNTP server. This means that the system time automatically corresponds to the time valid on site.
- Ensure that the SNTP server is permanently available.
- If the SNTP server is not available permanently, set the system time manually to the time valid on site. Ensure that the system time and the time valid on site are checked regularly and that deviations are corrected.

Also see:

- [Setting the System Time and Location](#) ⇒ page 25

4.15.3 Requirements for XML files for time planning

4.15.3.1 Specifications for XML file names

The specifications for file names in the following table are mandatory for storing time plans as XML files. If Hybrid Controller contains XML file with file names that are different, Hybrid Controller will delete these XML files automatically.

File Name	Explanation
schedule_YYYY-MM-DD.xml	Time plan for a calendar day: A file named according to the naming scheme schedule_YYYY-MM-DD is intended for one-time use on a specific calendar day. The calendar day must always be indicated based on the naming scheme YYYY-MM-DD . A time plan for a specific calendar day will always be run and is independent from the specifications from the following time plans.

File Name	Explanation
schedule_monday.xml	Time plan for a weekday:
schedule_tuesday.xml	If the name of the weekday is contained in the file name, this file is to be run each week on this day of the week. Hybrid Controller checks every day whether or not there is a time plan for the current calendar day. If there is no time plan for the current calendar day, then the time plan for the current day of the week will be run.
schedule_wednesday.xml	
schedule_thursday.xml	
schedule_friday.xml	
schedule_saturday.xml	
schedule_sunday.xml	
schedule_daily.xml	Time plan to be run daily:
	A file with the name schedule_daily.xml is intended to be run on a daily basis. Hybrid Controller checks every day whether or not there is a time plan for the current day of the week or for the current calendar day. If there is no time plan for the current day of the week or the current calendar day, then the time plan stored in the file schedule_daily.xml will be run.

Also see:

- Requirements for creating time plans ⇒ page 51
- Specifications on file structure and on file elements ⇒ page 47
- Valid function types in XML files ⇒ page 48

4.15.3.2 Specifications on file structure and on file elements

Generally applicable rules for creating syntactically correct (well-formed) XML files must be observed in any case. The additional specifications for the file structure and for the individual elements of the XML file are mandatory for creating time plans as XML files. If Hybrid Controller contains XML files with an invalid file structure or with invalid elements, Hybrid Controller will save these as XML files, but will not run the time plans they contain.

```

<?xml version ="1.0"?>
<schedule xmlns="http://www.sma.de/fsc/schedule">
    <function id="1">
        <type>FFR</type>
        <start>00:00:00</start>
        <stop>16:00:00</stop>
        <parameters>
            </parameters>
    </function>
    <function id="2">
        <type>PowerBlockAt</type>
        <start>16:00:00</start>
        <stop>17:00:00</stop>
        <parameters>
            <param name="ExtAtSpt" value="49990" />
        </parameters>
    </function>
</schedule>

```

Figure 6: Structure of an XML file for a time plan in Hybrid Controller (indents and line breaks are allowed, but not necessary.)

Elements of the XML file	Explanation
<?xml version ="1.0"?>	Required element of the XML file
<schedule xmlns="http://www.sma.de/fsc/schedule">	Required element of the XML file
<function id="1">	This element starts the first time plan function within the XML file. Every time plan function must have its own identification number. A maximum of 16 time plan functions can be defined for each XML file.

Elements of the XML file	Explanation
<type>	<p>Establishes the function type. Each function type corresponds to a function or a selection of parameters for the system control. The function type must be defined as valid by SMA Solar Technology AG. Hybrid Controller will not run XML files with invalid function types.</p> <p>The element <type> occurs exactly once in the time plan function.</p>
<start>	<p>Specifies the start time for the time plan function. The start time must be indicated according to the hh:mm:ss scheme.</p> <p>The element <start> occurs exactly once in the time plan function.</p>
<stop>	<p>Specifies the stop time for the time plan function. The stop time must be indicated according to the hh:mm:ss scheme.</p> <p>The element <stop> occurs exactly once in the time plan function.</p>
<parameters>	<p>The element <parameters> occurs exactly once in the time plan function and establishes the parameters that will be changed by the applicable function to a specific value. Each time plan function may influence a maximum of 16 parameters.</p> <p>Every parameter in the XML file must be defined as valid by SMA Solar Technology AG. Hybrid Controller will not run XML files with invalid parameters.</p> <p>Each parameter setting is described using a param tag. In the process, the following attributes must be set:</p> <ul style="list-style-type: none"> • Name of the parameter: name= • Value to be set: value= <p>Example for a parameter: The element <param name="PwrAtChrMaxPc" value="40" /> has an effect that sets the parameter PwrAtChrMaxPc to the value 40.</p>
</schedule>	Required element of the XML file

Also see:

- Requirements for creating time plans ⇒ page 51
- Specifications for XML file names ⇒ page 45
- Valid function types in XML files ⇒ page 48

4.15.3.3 Valid function types in XML files

Temporary settings for various functions and parameters from the system control for the Hybrid Controller can be stored as XML files. This makes it possible to plan these temporary settings in advance. Hybrid Controller can run the stored XML file and implement the time planning.

The following table contains the function types defined by SMA Solar Technology AG as valid. Each function type is assigned the functions and parameters that are currently approved for temporary influence. Additional functions and parameters can be added following consultation with SMA Solar Technology AG.

Function type	Function of system control	Parameter of system control
EFR ²⁾	Enhanced Frequency Response	DoSocMgmtInFrqDb EnaRestoreSoc MaxPwrDelTm PwrAtChrMaxPc PwrAtDisMaxPc RecoveryTm SocOpLimHi SocOpLimLo SocMgmtPwrAtChrMaxPc SocMgmtPwrAtDisMaxPc
EgyShift ²⁾	Energy Shifting	ChrFromPvSpntLimPc DisBatSpntLimPc MinDisTm RampRate TolerancePc
FFR ²⁾	Firm Frequency Response	DbForm EnaRestoreSoc FrqDbHi FrqDbLo FrqSpnt PwrAtChrMaxPc PwrAtDisMaxPc PwrAtChrMaxTm PwrAtDisMaxTm RecoveryTm

²⁾ The parameters of this function type can be set via XML files and via the user interface (for further information on these parameters, see Technical Information "Parameters and Measured Values").

Function type	Function of system control	Parameter of system control
GridFip	Feed-in Protection	FipMode GridReleaseAllPv PwrAtFeedInMax PwrAtGridMinLoad SpntOfsAbs
PeakLoadShave ²⁾	Peakload-Shaving	Trshld
PwrRt	Automatic Switching of Reactive Power Control Mode	PwrRtCtrlMode PwrRtCtrlModeAuto1 PwrRtCtrlModeAuto2
SocCtrl ²⁾	State of Charge	ChrFromGenTm HysPc PwrAtChrMaxPc PwrAtDisMaxPc SocLimHiPc SocLimLoPc UseFullPvPwr

Function type	Function of system control	Parameter of system control
Setpoints	External Setpoints	PwrAtAprSpt
		PwrApLim
		PwrAtLimHi
		PwrAtLimLo
		PwrAtLoLimPrl
		PwrAtMpp
		PwrAtRateMax
		BatPwrAtSpt
		PwrAtSptOfs
		PwrAtUpLimPrl
		PwrRtLimHi
		PwrRtLimLo
		PwrRtRateMax
		PwrRtSpt
		VtgSpt
		CosPhiSpt
		PwrAtLimSale
		CtrlModeCmd
		FrqSpt
TargetDisEgy ³⁾	-	PwrAtDisMaxPc

Also see:

- Requirements for creating time plans ⇒ page 51
- Specifications for XML file names ⇒ page 45
- Specifications on file structure and on file elements ⇒ page 47

4.15.4 Creating time plans

4.15.4.1 Requirements for creating time plans

- A maximum of 50 XML files may be created.
- Software that is suitable for transfer of XML files under the FTPS protocol (e.g. WinSCP) must be present on the computer that will display the user interface.
- The password that is used for the user group **Installer** must be known.

³⁾ This function type is used for temporarily influencing the electrical power. The parameters of this function type can only be set using XML files.

- The time plans for temporarily influencing the system control must be stored as XML files.
- The XML files must be named and structured according to the specifications of this document.
- The XML files may only access the functions and parameters of the system control that are currently approved for temporary influence.

Also see:

- [Creating time plans ⇒ page 52](#)
- [Requirements for XML files for time planning ⇒ page 45](#)
- [Setting the system time ⇒ page 45](#)
- [Data to add the Hybrid Controller as new host in the FTPS software ⇒ page 52](#)

4.15.4.2 Data to add the Hybrid Controller as new host in the FTPS software

Query the FTPS software	Necessary input for Hybrid Controller
File protocol	FTPS
Encryption	Implicit encryption with TLS/SSL protocol TLS: Transport Layer Security SSL: Secure Sockets Layer
Host name	172.16.1.21 (IP address for the Hybrid Controller)
Port number	990
User name	Installer
Password	The password used for the user group Installer

Also see:

- [Creating time plans ⇒ page 52](#)

4.15.4.3 Creating time plans

1. Start the FTPS software.
2. Once you have started the FTPS software for the first time, make the Hybrid Controller the new host in the FTPS software. Enter the data specified in this section.
 - The path **/cfc0/fsc/** appears in the user interface of the FTPS software. The folders **log**, **newfiles** and **schedulesoperator** are stored on this path.
3. Copy the XML files with time plans to be run daily and the XML files with time plans for a day of the week into the **schedulesoperator** folder.
4. Copy the XML files with time plans for a calendar day into the **newfiles** folder.
5. Log into the Hybrid Controller's user interface as **Installer**.
6. On the home page, select **Schedules**.

7. Select a menu via the page and menu selection **Available Schedule Files**.

8. Select **[Refresh]**.

All available XML files will be shown in the **Available Schedule Files** folder.

Also see:

- [Setting the system time ⇒ page 45](#)
- [Data to add the Hybrid Controller as new host in the FTPS software ⇒ page 52](#)
- [Requirements for creating time plans ⇒ page 51](#)
- [Requirements for XML files for time planning ⇒ page 45](#)

4.15.5 Activating/deactivating time plans

4.15.5.1 Active time plans

Hybrid Controller automatically considers the following XML files as active time plans:

- XML files with time plans to be run daily
- For every weekday within the next 48 hours: XML files with time plans to be run on a day of the week
- For every calendar day within the next 48 hours: XML files with time plans to be run on a calendar day

To deactivate XML files with time plans to be run daily and XML files with time plans to be run on a weekday, you must overwrite these XML files as described in this manual.

XML files with time plans to be run on calendar days that have already passed will be deleted by Hybrid Controller automatically.

Also see:

- [Activating/deactivating time plans ⇒ page 53](#)
- [Example for deleting an XML file ⇒ page 53](#)

4.15.5.2 Example for deleting an XML file

The XML file **schedule_2019-01-12.xml** would have been an active time plan on January 12, 2019 and would have influenced the system control according to the functions established in the file. The XML file **schedule_2019-01-12.xml** would have been automatically deleted on January 13, 2019.

Also see:

- [Active time plans ⇒ page 53](#)

4.15.5.3 Activating/deactivating time plans

1. To activate a time plan, create this time plan as an XML file and transfer it to the Hybrid Controller.
2. To deactivate a time plan, create an empty XML file with the file name of this time plan and transfer it to the Hybrid Controller.

3. Log into the Hybrid Controller's user interface as **Installer**.
4. On the home page, select **Schedules**.
5. Select a menu via the page and menu selection **Available Schedule Files** and press **[Refresh]**.
6. Select **Current Schedule** via the page and menu selection.

All XML files with active time plans will be shown on the **Current Schedule** page.

Also see:

- [Setting the system time ⇒ page 45](#)
- [Active time plans ⇒ page 53](#)

4.16 Reset

4.16.1 Modes for resetting the product

Value	Explanation
Reset only control parameters	Only the parameters of the control functions are reset to default settings. The control function are in the Home > Control Functions menu.
Reset all parameters but not network and DigIO settings	All parameters of the Hybrid Controllers are reset except network settings: For network settings go to Home > Settings > Network settings . For settings of digital inputs and outputs go to Home > Wizard > Digital inputs/outputs > General .
Reset all parameters	All parameters of the Hybrid Controllers are reset.

Also see:

- [Resetting the Product ⇒ page 54](#)

4.16.2 Resetting the Product

1. Log in as an **Installer**.
2. Go to **Home > Parameter files > Factory Reset** via page and menu selection.
3. Select the value for the preferred mode in the drop-down list **Reset mode**:
4. Click on the **[Reset]** button.
5. Click on the **[Proceed]** button.
6. Define a folder to store the new parameter file and click on the **[Save]** button.
7. Restart the product. In doing so, use the new parameter file.

Also see:

- Performing restart ⇒ page 57
- Modes for resetting the product ⇒ page 54

5 Starting and Stopping the System

5.1 Safety when starting and stopping

NOTICE

Destruction of gensets due to overload caused by insufficient reserve power

If the current reserve power of the gensets is insufficient, switch off the loads or connect additional gensets. This increases the reserve power of the gensets.

- Prior to stopping the Hybrid Controller, always check whether the current reserve power of the gensets is sufficient to cover the requirement of the loads.
- If the power management and the communication interface of the genset are not compatible with the Hybrid Controller, power management must be deactivated on the Hybrid Controller. In this case, the gensets must be monitored to ensure that sufficient genset reserve power is retained.
- Make sure that the setpoints for power management on the Hybrid Controller and the gensets are set to the same value.

NOTICE

Power supply failure when the Hybrid Controller is restarted

Before restarting the Hybrid Controller, the Hybrid Controller and PV power plant must be stopped. It can take a few minutes for the Hybrid Controller and PV power plant to stop because the PV inverters have to reduce their output power slowly. If the PV inverters are still feeding energy to the grid when the Hybrid Controller is restarted, this may cause failure of the power supply.

- Once the Hybrid Controller has stopped, wait until the PV inverters have reduced their output power to zero. This can take several minutes.

Also see:

- Stopping the product ⇒ page 57
- Performing restart ⇒ page 57

5.2 Starting the product

1. Start the gensets (see system documentation).
2. On the Hybrid Controller, connect the supply voltage (see the installation manual of the product).
3. Connect the current and voltage measurement inputs (see the installation manual of the product).
4. Log into the user interface as **Installer**.
5. Select the **System overview** menu via the page and menu selection.
6. Go to **Home > Settings > General settings** via the page and menu selection and click on the **[Start]** button.

7. Connect the inverters on the DC main distributor to the AC grid (see PV inverter documentation).
 - The PV power plant synchronizes to the available AC grid. How long synchronization takes depends on the current solar irradiation on the PV modules and on the current power required by the loads.
 - The Hybrid Controller reports the event **Valid product licence found**: The Hybrid Controller is fully functional.
8. If the Hybrid Controller generates a warning **No product licence found**, **Product licence is not valid** or **Product licence is empty**, contact Service and request a valid software license.

5.3 Stopping the product

Requirements:

- You must be logged into the user interface as **Installer**.

Procedure:

1. Log into the user interface as **Installer**.
2. Go to **Home > Settings > General settings** via the page and menu selection.
3. In the **Start/Stop** bar, select the **[Stop HC]** button.
4. Wait until the Hybrid Controller has stopped the inverters. This can take several minutes.
 - The **Hybrid Controller is off** message is displayed.
5. To disconnect the inverters from the AC grid, disconnect the inverters on the DC main distributor from voltage sources (see inverter documentation).

Also see:

- [Safety when starting and stopping ⇒ page 56](#)

5.4 Performing restart

Requirements:

- You must be logged into the user interface as **Installer**.
- The Hybrid Controller and PV power plant must have been stopped.

Procedure:

1. Log into the user interface as **Installer**.
2. Select the **System overview** menu via the page and menu selection.
3. Go to **Home > Settings > General settings** via the page and menu selection.
4. Click on the **[Reboot]** button in the **Hybrid Controller system** area.
 - The **Do you really want to reboot the Hybrid Controller** prompt appears.
5. Confirm the **Do you really want to reboot the Hybrid Controller** prompt by clicking **[Yes]**.

Also see:

- Safety when starting and stopping ⇒ page 56
- Stopping the product ⇒ page 57

6 Troubleshooting

6.1 Event messages

6.1.1 Using the scrollbar

i **Scrollbar can only be used by means of the arrow keys**

If not all messages can be displayed on the user interface, a scrollbar appears on the **Alarm list** page. You can only use this scrollbar by means of the arrow keys.

- To call up messages recorded at an earlier time, press the up row key.
- To call up messages recorded at a later time, press the down arrow key.

Also see:

- [Processing Event Messages](#) ⇒ [page 59](#)

6.1.2 Filter function

The user interface of the Hybrid Controller displays event messages in the categories: information, warning and errors. Using the filter function, you can display and hide these categories.

Also see:

- [Overview of event messages](#) ⇒ [page 59](#)
- [Processing Event Messages](#) ⇒ [page 59](#)

6.1.3 Overview of event messages

Name of the column	Description
Timestamp	Time at which the message was recorded:
Status	<p> Information</p> <p> Warning If a warning occurs, automatic operation continues.</p> <p> Error If an error occurs, automatic operation stops.</p> <p> Warning or error no longer exists.</p> <p> Event, warning or error has occurred.</p>
Code	Four-digit number of the reported event, warning or error
Description	Description of the reported event, warning or error

6.1.4 Processing Event Messages

1. Only if you are logged in as **Installer**, open the **System Overview** menu via the page and menu selection.

2. Choose **Operations > Alarms** via the page and menu selection.
3. Set the filter functions via the checkboxes **Errors**, **Warnings** and **Events**. To do this, activate the checkboxes and deactivate the checkboxes that are not required.
4. If errors are reported, determine and eliminate the causes for each error.
5. When the causes of an error have been eliminated, acknowledge the corresponding error message. To do so, select the **[Acknowledge]** button.
6. Ascertain the causes of reported warnings and take corrective action.
7. To acknowledge reported warnings, select the **[Acknowledge]** button.

Also see:

- Using the scrollbar ⇒ page 59
- Filter function ⇒ page 59
- Overview of event messages ⇒ page 59

6.2 Errors in the Hybrid Controller

Problem	Cause and corrective measures
The inverters do not start although the Hybrid Controller is in OPERATE mode.	<p>There may be an error in an inverter which must be acknowledged manually.</p> <ul style="list-style-type: none">• Ascertain and remove the cause of the error.• Log onto the user interface of the inverter as installer and acknowledge the error message.
Settings of parameters or data on the system history are not saved	<p>It is possible that the Hybrid Controller's internal memory card is defective. A defective memory card can, as a worst-case scenario, prevent Hybrid Controller from restarting.</p> <p>Corrective measures:</p> <ul style="list-style-type: none">• If the problem persists, contact Service.
The voltage 0 V is persistently shown at a measuring point.	<p>The miniature circuit breaker F3, F4 or F5 on the measuring module for the voltage measurement in the Power Plant Manager may be deactivated.</p> <p>Corrective measures:</p> <ul style="list-style-type: none">• Activate the miniature circuit breaker.

Problem	Cause and corrective measures
The Hybrid Controller's user interface is not available.	<p>The external supply voltage may not be connected correctly.</p> <ul style="list-style-type: none">• Ensure that the external supply voltage is attached and turned on correctly.
	<p>The miniature circuit breaker F1 or F11 may be deactivated in the Power Plant Manager.</p> <ul style="list-style-type: none">• Activate the miniature circuit breaker.
	<p>In addition, if no indicator light is lit, there might be an error in the internal supply voltage of the Power Plant Manager.</p> <ul style="list-style-type: none">• Check the voltage on the internal buffer module of the Power Plant Manager.
	<p>Only in the redundancy system: During a role change in the redundancy system, relay K5 in the Power Plant Manager pulls in and drops out again after the switching operation. Relay K5 may be permanently pulled in.</p> <ul style="list-style-type: none">• Check the wiring in the Power Plant Manager.
<p>The Hybrid Controller generates a warning: 2098: No product licence found, 2099: Product licence is not valid, or 2100: Product licence is empty when starting or restarting.</p>	<p>The software license installed may be damaged or invalid for some other reason.</p> <ul style="list-style-type: none">• Contact Service.

7 Contact

If you experience any technical problems with our products, please contact the Service. The following data is required in order to provide you with the necessary assistance:

- Device type
- Serial number
- Event message
- Type of genset control unit used

You can find your country's contact information at:



<https://go.sma.de/service>

ENERGY
THAT
CHANGES



www.SMA-Solar.com

