



Central inverter
SUNNY CENTRAL
User Manual



Table of Contents

1	Notes on this Manual.	5
1.1	Symbols Used	5
1.2	Target Group	6
1.3	Applicability	6
1.4	Documentation	6
2	Safety Instructions	7
3	Description of the Sunny Central	9
3.1	Identifying the Sunny Central	10
3.2	The Sunny Central's Control Elements	11
3.2.1	Sunny Central Control.	11
3.2.2	Light Indicators	12
3.2.3	Start-up Key Switch	12
3.2.4	Emergency Shut-off	12
3.2.5	AC Switch	13
3.3	Operating Modes.	14
3.3.1	Operating Modes of the Sunny Central	14
3.3.2	Operating Modes of Team Systems	16
4	Sunny Central Control Operation.	18
4.1	Functions of the Control Buttons	19
4.2	Explanation of the Display Symbols	20
4.3	Adjusting the Display Contrast	20
4.4	Adjusting Parameters and Settings	20
5	Sunny Central Control Menu.	21
5.1	Overview of the Menu	22
5.2	Setting the Language	23
5.3	Changing the Date and Time	24

5.4	Entering the Password	26
6	Parameters	28
6.1	Description of the Parameter Functions	29
6.2	Default Parameter Settings	31
6.3	Adjusting Parameters	32
7	Communication	34
7.1	Remote-Info	34
7.2	Activating E-mail Reports	36
7.3	Entering or Changing E-Mail Addresses	36
7.4	Selecting the Report Types to Send	37
7.5	Sending a Test Report	39
8	External Sensors	40
8.1	Configuring the External Sensors	40
8.2	Calculating Gain and Offset	43
9	Failures and Warnings	45
9.1	Fault Diagnosis	45
9.1.1	Categories of Failures and Warnings	45
9.1.2	Types of Failures and Warnings	46
9.1.3	Warnings	47
9.1.4	Failures	51
9.2	Confirming Errors at the Sunny Central Control	58
10	Maintenance	60
11	Contact	63

1 Notes on this Manual

1.1 Symbols Used

The following four types of warnings and general information appear in this document as described below:

**DANGER!**

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

**WARNING!**

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

**CAUTION!**

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

**NOTICE!**

NOTICE indicates a situation that can result in property damage if not avoided.

**Information**

Information provides tips that are valuable for the optimal installation and operation of your product.

1.2 Target Group

This documentation is intended for Sunny Central installers and operators. It includes a description of how to operate the Sunny Central Control, maintenance of the Sunny Central, and troubleshooting with the aid of the Sunny Central Control.

1.3 Applicability

This documentation describes how to operate the Sunny Central indoor and outdoor central inverters. It applies for software versions 6.07 and 6.08.

1.4 Documentation

The following list shows the documents which you receive with your Sunny Central, and the information which each respective document contains:

- Installation guide: setup and installation of the Sunny Central
- User manual: how to operate the Sunny Central and Sunny Central Control
- Wiring diagrams: the Sunny Central's wiring diagrams
- Technical data sheets: technical data pertaining to the Sunny Central

2 Safety Instructions

**DANGER!****Risk of lethal electric shock!**

Death resulting from burning and electric shock upon touching the medium-voltage grid's live components.

- Do not touch the live components of the Sunny Central or medium-voltage grid.
- Observe all safety regulations which apply to activity that involves the medium-voltage grid.

**WARNING!****Risk of lethal electric shock!**

High voltages are present in the device.

- All work on the Sunny Central must be carried out by a trained and qualified electrician!
- Work on the Sunny Central is only to be performed as described in the following sections!
- Observe all safety instructions listed!
- Follow all safety instructions included in the Sunny Central's installation guide!

**WARNING!****Lethal danger caused by damage to the Sunny Central!**

Damage to the Sunny Central, e.g. defective cables, or a damaged housing, can lead to death by electric shock or fire!

- Only use the Sunny Central when it is safe to do so!
- Only use the Sunny Central if no damage is visibly evident!
- Visually check the Sunny Central for damage on a regular basis!
- Ensure that all external safety features are freely accessible at all times, and that they are regularly tested for correct functionality!

**NOTICE!****Possible damage to the Sunny Central!**

The Sunny Central can be damaged irreparably by electrostatic discharge at its components.

- When working on the Sunny Central, and handling the module assemblies, remember to observe all ESD safety regulations!
- Discharge any electrostatic charge by touching the grounded Sunny Central housing
- before handling electronic components!

**Storage of handbooks**


This user manual, the installation guide, the data sheets, the operating manuals of installed components, and the wiring diagrams must be kept in the immediate vicinity of the Sunny Central. They must be available to operators and maintenance staff at all times.

3 Description of the Sunny Central

The Sunny Central is a solar inverter. It allows photovoltaic solar energy from solar modules to be converted and fed into a low-voltage or medium-voltage grid.

Principle of a grid-connected solar power system with a Sunny Central

Solar modules



Sunny Central

The standard Sunny Central is equipped with a low-voltage transformer, and feeds into the low-voltage grid.

Sunny Central HE


The Sunny Central HE is a high efficiency photovoltaic inverter. It does not have its own low-voltage transformer. The Sunny Central HE requires an adapted external medium-voltage transformer via which it can feed into the grid.

Sunny Central MV

The MV stations are medium-voltage stations. In an MV station, two Sunny Central HE devices feed into a shared medium-voltage transformer. The Sunny Central MV feeds into the medium-voltage grid.

3.1 Identifying the Sunny Central


You can identify the Sunny Central using the name plate (see figure below). The name plate is located on the inside of the Sunny Central's door.



- A The Sunny Central's type name with option code (optional).
- B The version of the Sunny Central; "s" means special version.
- C Serial number of the Sunny Central.

3.2 The Sunny Central's Control Elements

The illustrations below represent two different Sunny Centrals, and allow you to identify the approximate locations of the Sunny Centrals' control elements.



- A Sunny Central Control
- B Start-up key switch
- C AC switch

3.2.1 Sunny Central Control

Sunny Central settings can be adjusted directly at the device by means of the Sunny Central Control. The functions that the Sunny Central Control performs can be grouped into the following areas:

- Controlling inverter operation
- Displaying present measuring data
- Adjusting Sunny Central parameters
- Maximum power point tracking
- Recording and archiving measurement data
- Remote access capability with NET Piggy-Back
- Connection of external sensors

3.2.2 Light Indicators

Three light indicators are situated on the front of the Sunny Central. If an error occurs, the type of disturbance is shown by these light indicators.


- **Yellow:** The Sunny Central is in "Alert" mode. The Sunny Central does not switch itself off. Once the error is no longer present, the error message is reset automatically. Check the system.
- **White:** The Sunny Centrals are operating in Team mode. The Team contactor is activated.
- **Red:** The Sunny Central is in "Failure" mode. If the Sunny Central has detected a failure, it shuts down. Once the fault has been removed and confirmed, it resumes operation. For more information, see section 9.1.2 "Types of Failures and Warnings" (page 46).

3.2.3 Start-up Key Switch

The start-up key switch activates or deactivates the Sunny Central. When this switch is turned to the "Start" position, the Sunny Central changes from "Stop" mode to "Wait" mode. If there is sufficient radiation, the Sunny Central changes to the "Startup" mode, and subsequently begins grid feeding. If the radiation, and thus the input voltage, is too low, the Sunny Central remains in "Wait" mode.

If the start-up key switch is turned to the "Stop" position, the DC switch is deactivated automatically by a motor drive.

3.2.4 Emergency Shut-off



NOTICE!

Improper use of the emergency shut-off switch causes damage to the Sunny Central!

The Sunny Central's components are subjected to considerable stress if the emergency shut-off switch is used under load. This can irreparably damage individual components.

- Only use the emergency shut-off switch in an emergency.
- To switch off the Sunny Central, use the start-up key switch.

The emergency shut-off switch immediately disconnects the Sunny Central from the grid, and from the solar generator, placing the Sunny Central in a safe condition.

When the emergency shut-off switch is pressed, it locks in the "Off" position. The emergency shut-off switch can only be unlocked using its key. It is also necessary to reset the emergency shut-off operation with the Sunny Central Control or with Sunny Data Control.

The Sunny Central 100 indoor and the Sunny Central 100 outdoor have no emergency shut-off switch. You have the option of installing an external emergency shut-off switch at the Sunny Central.

You can also install an external emergency shut-off switch at the other Sunny Centrals, or deactivate several Sunny Centrals with a shared emergency shut-off switch.

3.2.5 AC Switch

**NOTICE!****Improper use of the AC switch may cause damage to the Sunny Central!**

The Sunny Central's components are subjected to considerable stress if the AC switch is used under load. This can irreparably damage individual components.


- Only use the AC switch if the Sunny Central has been set to "Stop" by turning the start-up key switch.

Upon use of the AC switch, the Sunny Central is disconnected from the grid on the AC side.

3.3 Operating Modes

3.3.1 Operating Modes of the Sunny Central

When activated, the Sunny Central passes through different modes as pictured below. When deactivated, the Sunny Central resides in the operating mode "Stop". If the key switch is turned, the Sunny Central changes to the "Wait" mode



Stop

The Sunny Central is deactivated. The Sunny Central remains in this mode until the start-up key switch is turned to the start position.

Wait

If the input voltage is below the defined start voltage "UpvStart", the Sunny Central resides in "Wait" mode. The value of the UpvStart setting is shown in the Sunny Central Control's display.

Startup

If the input voltage is above the start voltage "UpvStart", the Sunny Central waits until the time defined by the parameter "Tstart" has passed. If the input voltage has not fallen below the start voltage "UpvStart" during this period, the Sunny Central starts up.

The AC contactor is closed and the Sunny Central is isolated. Once the Sunny Central is ready for operation, it begins grid feeding.



Start Voltage UpvStart

The start voltage UpvStart must be adjusted for the solar generator which is connected to the Sunny Central.

MPP Load Operation

After successful activation, the Sunny Central seeks the solar generator's maximum power point (MPP), and begins feeding into the grid.

Shutdown

The Sunny Central shuts down if:

- the power measured during the interval "Tstop" is less than "PpvStop",
- a failure occurs which requires a shutdown of the Sunny Central, or
- the start-up key switch is set to "Stop".

Failures

If a failure occurs during operation, the Sunny Central shuts down and the failure is shown as a disturbance in the Sunny Central Control's display. Refer to section 9 "Failures and Warnings" (page 45) for a list of disturbances.

3.3.2 Operating Modes of Team Systems

In addition to the normal operating modes, Sunny Centrals which are configured as a Team system also have Team operating modes.

Stop

If one of the two Sunny Centrals is deactivated, the second Sunny Central is operated individually without Team. If only the Team leader is operating, it is in the "Startup" mode. If only the Team member is operating, it resides in the "String Operation" mode.

Linking (Mornings)

The Team contactor is disconnected. If the input voltage (V_{pv}) of both Sunny Centrals is greater than the PV start voltage ($U_{pvStart}$) - 50 V, the Team contactor closes itself. The Team leader begins to operate as soon as the start conditions are fulfilled. The Team leader goes into the "Team leader" mode and feeds the power into the grid. The Team member changes to the "PV linked" mode. The Team leader and the Team member operate as a Team.

Disconnecting

The Team member is in "Team mode". The Team leader is in "Team leader" mode. Both Sunny Centrals are feeding into the grid.

If the Team leader's output exceeds the value of "P-NextTeam" (default setting: 80 %), the DC contactor is switched off. Both Sunny Centrals then operate individually, and feed into the grid.

Linking (Evenings)

If the Team leader's AC output falls below the value of "P-PrevTeam" (default setting: 20 %), the Team contactor is switched on. The Team leader feeds the entire system power into the grid, and is in the "Team leader" mode. The Team member is in "PV linked" mode.

Night Operation

If the Team leader's open circuit voltage is below U_{pvMin} - 100 V for 30 minutes, the Team contactor is disconnected. The Team leader changes to "Startup" mode. The Team member changes to "Team mode".

Failures

If, when in Team mode, a failure occurs, the Team mode is immediately interrupted, and the Team contactor is disconnected. The Sunny Centrals continue to operate individually until the failure is rectified.


If a failure is present for more than 60 minutes, Team mode can be resumed. For Team mode to be possible while a failure is present at a Sunny Central, the following conditions must be fulfilled:

- The communication between the two Sunny Centrals must be functioning.
- The DC contactor must be functioning.
- The start-up key switch must be set to the "Start" position.
- None of the following failures must be present:
 - Failure 201: Ground Fault 2 or plant temp. too high
 - Failure 206: Emergency shutdown activated

If these conditions are fulfilled, the Sunny Central at which no failure is present takes over the output of both solar generators.

4 Sunny Central Control Operation

The control panel Sunny Central Control is mounted in or on the Sunny Central at eye level. The Sunny Central Control is operated by means of the four buttons below the four-line display.




Operating the Sunny Central Control with SC 100 Indoor and SC 100 Outdoor Inverters

With the Sunny Central SC 100 indoor and SC 100 outdoor inverters, the Sunny Central Control is situated inside the inverter. The Sunny Central Control may only be used in "Stop" mode with these devices.

Open the Sunny Central as described in the installation guide.

4.1 Functions of the Control Buttons

The four control buttons are situated below the Sunny Central Control's display.



The control buttons have several functions. In the following table, the buttons' functions are explained.

Button	Meaning and function
[ESC]	<ul style="list-style-type: none"> • cancels / ends the present function • answers questions with "No" • returns to the previous menu • changes from the online info display to the main menu
[↑]	<ul style="list-style-type: none"> • moves up to the previous line • increases the present value
[↓]	<ul style="list-style-type: none"> • moves down to the next line • decreases the present value
[ENTER]	<ul style="list-style-type: none"> • selects a function from the menu • selects a value • confirms changes • answers questions with "Yes"
[↑] + [↓]	<ul style="list-style-type: none"> • returns to the online info display

4.2 Explanation of the Display Symbols

The Sunny Central Control display has four lines. It uses various display symbols, which are explained in the following table.

Symbol	Meaning
↑	There are more display lines above.
↓	There are more display lines below.
↕	There are more display lines above and below.
→	Appears at the left of the presently selected line. Press [↑] or [↓] to move to another line.
→ (glows)	Appears to the left of a value which can be changed.
→ (flashes)	If, for example, a parameter has been changed, the arrow flashes at the left of the active line.
⌂	The Sunny Central Control is loading the next menu, or saving data.

4.3 Adjusting the Display Contrast

You can adjust the display contrast in any menu. You must press a combination of two buttons in order to increase or decrease the contrast.

Buttons	Function
[ESC] + [↑]	increases the display contrast
[ESC] + [↓]	decreases the display contrast

4.4 Adjusting Parameters and Settings

You can adjust the Sunny Central's parameters and settings in edit mode. Only parameters which have a solid arrow to their left (→) can be adjusted.

Press [ENTER] to access the parameter's edit mode. The parameter's value begins to flash. You can adjust the value with the two arrow buttons. Confirm the change with [ENTER], or cancel with [ESC]. If no button is pressed for 60 seconds, the change is automatically cancelled.



Password for Adjusting Parameters

Parameters can only be adjusted after an installer password has been entered (see section 5.4 "Entering the Password" (page 26)).

5 Sunny Central Control Menu

The Sunny Central Control initializes upon activation of the Sunny Central. The initialization includes a sequence of three displays. Once the Sunny Central Control has initialized, it changes to the online info display. In the online info display, your Sunny Central's measured values and spot values are displayed.

Status	MPP
Pac	85.7kW
E_Today	357.5kWh
E_Total	2512.3kWh

[↑], [↓] or [ENTER]

Status	MPP
Ppv	89.27kW
Vpv	557V
Ipv	160.26A

[↑], [↓] or [ENTER]

Status	MPP
fac	50.04Hz
Vac	230.51V
Iac	124.07A

You can switch between the three online info displays with the buttons [↑], [↓] or [ENTER]. If a warning or failure is reported, the display will alternate between the present online info display and the error with the highest priority.

5.1 Overview of the Menu

The Sunny Central Control menu is subdivided into four main menus. The four main menus and their subcategories can be seen in the table below.

Main menu	1st menu level	2nd menu level
Operating Data	Faults	
	Plant Status	
	Energy Yield	E-Total, E-Today
	Data Files	Meas. Interval, Daily Values, Meas.Channels
	Other	Operating Time, Working Time, Startup counter, Fault counter, Alert counter
Spot Values	PV	Ppv, Vpv, Ipv
	Grid	Pac, fac, Iac, Vac Phase 1, Vac Phase 2, Vac Phase 3
	Other	Temp. SC, Temp. PT100B, R-Iso, Mppsearchcount, Team Function
Long-Term Data	Meas. Chn.	
	Energy Yield	Daily Values
	Plant Status	Reports
	Faults	
Device Set-up	Password	
	System	Language, Date/Time, Inverter Type, BF_UZWK_Norm, SC_Firmware
	Parameters	Param.-Function, Mpp Limit. Val., Mpp Tracking, Start requiremt, Shut-down requ., Grid Monitor., Other
	INTERFACES	Communication, Analog In, Digital In, Digital Out
	Data archives	Data Recording, Meas. Interval, Max. Storage, Chan. Select.
	SMUs	Devices, Parameters, Measured Values, Failure
	NET/eMail	NET, Remote-Info

- **Operating Data**
 The Operating Data menu provides general information about the Sunny Central. This includes, for example, displaying energy yields, operating and feed hours, or information about the archive of stored data and any failures that are currently being reported.
- **Spot Values**
 The Spot Values menu displays all available online measurement data for the system. Here, a distinction is made between the PV side, the grid side, and other measured values.
- **Long-Term Data**
 Measurement data are saved in the Long-Term Data menu. Here, for example, you can also find a list of the failures which have occurred to date.
- **Device Set-up**
 System, operation, and adjustment parameters are set in the Device Set-up menu. This allows system-specific and customer-specific configuration of the Sunny Central.

5.2 Setting the Language

The Sunny Central Control can be operated in German, English, or Spanish. The Sunny Central's language is preset to the language specified when you placed your order. If you wish to change the language, proceed as follows:

1. In the online info display, press [ESC].

Status	MPP
Pac	85.7kW
E_Today	357.5kWh
E_Total	2512.3kWh

[ESC]

2. Navigate to the "Device Set-up" menu with the [↓] arrow button, and select it by pressing [ENTER].


3 x [↓]

[Main Menu]
Operating Data
Spot Values
Long-Term Data
→ Device Set-up

[ENTER]


- 3. Navigate to the "System" menu with the [↓] arrow button, and select it by pressing [ENTER].

1 x [↓]




[ENTER]

- 4. Select "Language" by pressing [ENTER].



[ENTER]

- 5. Select the desired language by pressing [ENTER], and confirm your selection by pressing [ENTER] again.




2 x [ENTER]

5.3 Changing the Date and Time

The Sunny Central's default settings for date and time correspond to the Central European time zone. If you wish to adjust the date or time (e.g. when changing from summer time to winter time), proceed as follows:


- 1. In the online info display, press [ESC].



[ESC]

- 2. Navigate to the "Device Set-up" menu with the [↓] arrow button, and select it by pressing [ENTER].


3 x [↓]



[ENTER]

- 3. Navigate to the "System" menu with the [↓] arrow button, and select it by pressing [ENTER].


1 x [↓]



[ENTER]


- 4. Navigate to the "Date/Time" menu with the [↓] arrow button, and select it by pressing [ENTER].

1 x [↓]



[ENTER]

- 5. To make an adjustment, select either the date or the time by pressing [ENTER]. You can change from day to month to year, or from hour to minute, by pressing the [ENTER] button. The values can be increased or decreased with the arrow buttons.



- 6. Confirm your changes using [ENTER].

5.4 Entering the Password



Password

You can obtain the password from the Sunny Central Serviceline. This can be reached on the following telephone number:

+49 561 9522-299

Safety-relevant Sunny Central parameters can only be adjusted upon entry of a password. To enter the password, proceed as follows:

1. In the online info display, press [ESC].

Status	MPP
Pac	85.7kW
E_Today	357.5kWh
E_Total	2512.3kWh

[ESC]

2. Navigate to the "Device Set-up" menu with the [↓] arrow button, and select it by pressing [ENTER].

3 x [↓]

[Main Menu]
Operating Data
Spot Values
Long-Term Data
→ Device Set-up

[ENTER]

3. Select "Password" by pressing [ENTER].

[Device Set-up]
→ Password
System
Parameters ↓

[ENTER]

4. Enter the password.
5. If the correct password is entered, the Sunny Central Control beeps three times. If the password is incorrect, the Sunny Central Control beeps once.

[PASSWORD]

[ENTER]

Locking the Sunny Central Control

You can relock the Sunny Central Control under the menu item "Password", by entering an incorrect password, or no password. Password protection will automatically resume at midnight, or upon a restart.

6 Parameters

The Sunny Central's parameters are pre-configured for operation. It is a good idea to adapt a number of the Sunny Central's parameters to the solar generator.

The Sunny Central's parameters are subdivided into six menus:

- Mpp Limit. Val.
Threshold values for MPP mode
- MPP Tracking
Settings for MPP mode
- Start requiremt
Parameters for startup of the Sunny Central
- Shut-down requ.
Parameters for the regular shutdown of the Sunny Central
- Grid Monitor.
Parameters for grid conditions
- Other
Various additional functions, e.g. the Team function

6.1 Description of the Parameter Functions

The following parameters can be found in the menus.

Parameters marked with * may only be adjusted upon consultation with SMA.

Parameter	Description of the function
Mpp Limit. Val.	
VmppMin *	Minimum MPP voltage required for the Sunny Central to feed.
dVreference	MPP tracking is possible within a range equal to $2 \times dUreference$. As soon as the voltage drops or rises outside of this range, the inverter goes into "MPP Search" mode. Default setting: 80 V Recommendation for operation with thin-film modules: 120 V
PsearchMpp *	If the currently measured solar power drops below the value PsearchMpp for the duration of TsearchMpp, the Sunny Central begins to search for the MPP again.
TsearchMpp *	
MPP Tracking	
dVtrack *	During MPP tracking, the inverter changes the voltage in "dUtrack" steps at "TcheckMpp" intervals before it selects the MPP.
TcheckMpp *	
Mpp Factor	The start value for MPP tracking is obtained by multiplying the "MppFactor" parameter by the measured open circuit voltage. Default setting: 0.80 Recommendation for operation with thin-film modules: 0.70
TrackCnt	During operation, the Sunny Central seeks the maximum power point. It checks the voltage up to seven times (default setting) in one direction, e.g. always toward the higher voltage. After the seventh time (at the latest), it also seeks below the last voltage, in order to check whether the maximum power point has decreased. If, for example, the Sunny Central finds a lower power point upon the third increase, it seeks below the most recently checked voltage.
Start requirement	
Operating Mode *	MPP is set as a condition for starting up the inverter.
VpvStart	If $Vpv \geq UpvStart$ for the duration of Tstart, the Sunny Central can switch from "Wait" mode to "Startup" mode. UpvStart must be adjusted for the solar generator which is connected to the Sunny Central.
Tstart	
Twait	If, in three consecutive startup attempts, PpvStop has not been exceeded, the next startup attempt will not occur before Twait has passed.

Parameter	Description of the function
Shut-down requ.	
PpvStop *	If $P_{pv} < P_{pvStop}$ for the duration of T_{stop} , the Sunny Central goes into "Shutdown" mode.
Tstop	
Grid Monitor.	
PacMax *	PacMax is the maximum power output to the grid. If this limit is exceeded, the Sunny Central reduces the power.
PpvMin Check *	PpvMinCheck appears only after entry of the installer password. If PpvMinCheck is set to "off", the Sunny Central continues to operate after the shutdown conditions have been met. As a result, the Sunny Central operates even at night and needs to draw its operating power from the grid.
Other	
E-Total Offset	With this parameter, the internal energy counter can have a constant offset applied to it. It may be a good idea to adjust this parameter after replacement of the Sunny Central Control.
TMax. cabinet *	If the TMax. cabinet temperature is exceeded, the warning "cabinet Temp." is generated.
TMin. cabinet *	If the cabinet temperature drops below "TMin. cabinet", the warning "cabinet Temp." is generated.
Team activated	If the Sunny Central is a Team device, the Team function can be activated here. The following settings are available: OFF: Team function deactivated ON: Team function activated
Team-Register	If the Sunny Central is a Team device, the Team register can be defined here. The following values are available: 0: the Sunny Central is defined as Team leader. 1: the Sunny Central is defined as Team member.
P-Next Team	In Team systems, this parameter defines the percentage of the nominal power output required for the two Sunny Centrals to be disconnected from each other. The default setting is 80 %.
P-Prv. Team	In Team systems, this parameter defines the percentage of the nominal power output required for the Team contactor to close. If "Pac smoothed" falls short of this value, the Team contactor closes, causing both solar generators to feed one inverter. The default setting is 20 %.

Parameter	Description of the function
Tau-FP*	A damping function for the switching points helps minimize the number of switchings and thus lengthen the service life of the Team contactor. This parameter influences "Pac smoothed".

6.2 Default Parameter Settings

The following table summarizes the main operating parameters, and includes the adjusting range and default value of each parameter. The adjusting range and default value depend on the Sunny Central model.

The parameters shown here with a gray background are only visible / adjustable after the installer password has been entered (see section 5.4 "Entering the Password" (page 26)).

Parameter	Range	Default
VmppMin	275 - 400 V (Sunny Central LV) 450 - 600 V	300 V (Sunny Central LV) 450 V
dVreference	5 V - 200 V (Sunny Central LV) 5 V - 200 V	60 V (Sunny Central LV) 80 V
PsearchMpp	0 - 25000 W	device-specific setting
TsearchMpp	60 - 3600 s	600 s
dVtrack	1 - 10 V	5 V/TaMp
TcheckMpp	5 - 60 s	10 s
Mpp Factor	0.20 - 1.00	0.80
TrackCnt	5 - 20	7
VpvStart	300 - 600 V (Sunny Central LV) 450 - 800 V	400 V (Sunny Central LV) 600 V
Tstart	1 - 600 s	90 s
Twait	0 - 1800 s	600 s
PpvStop	0 - 10000 W	device-specific setting
Tstop	1 - 300 s	60 s
PacMax	3 - 500 kW	device-specific setting
TMax. cabinet	30 - 70 °C	50 °C
TMin. cabinet	-30 - 10 °C	-20 °C

6.3 Adjusting Parameters



Impaired Functionality of Sunny Central due to Altered Parameters

Improperly altered parameters can partly or completely impair the functionality of the Sunny Central.

- Parameters marked with * may only be adjusted upon consultation with SMA (see section 6.3 "Adjusting Parameters" (page 32)).
- After work has been carried out on the Sunny Central Control, it must then be relocked, in order to prevent third parties from changing the parameters.



Adjusting Parameters

These instructions describe how you can adjust parameters at the Sunny Central Control. You can use the following possibilities and tools to adjust the parameters:

- At the Sunny Central with the Sunny Central Control
- On site with a laptop and the Sunny Data Control software
- From a PC via remote access, with Sunny Data Control

The Sunny Data Control documentation describes how you can adjust parameters with Sunny Data Control.

The Sunny Central parameters can be adjusted as follows:

1. Enter the password as described in section 5.4 "Entering the Password" (page 26).
2. In the online info display, press [ESC].

Status	MPP
Pac	85.7kW
E_Today	357.5kWh
E_Total	2512.3kWh

[ESC]

3. Navigate to the "Device Set-up" menu with the [↓] arrow button, and select it by pressing [ENTER].


3 x [↓]

[Main Menu]
Operating Data
Spot Values
Long-Term Data
→ Device Set-up

[ENTER]


4. Navigate to the "Parameters" menu with the [↓] arrow button, and select it by pressing [ENTER].

2 x [↓]



[ENTER]

5. Select the menu in which you wish to adjust a parameter, by pressing [ENTER].
6. Select the parameter that you would like to change, by pressing [ENTER].
7. Take note of the previous value of the parameter.
8. Adjust the parameter as discussed with SMA.
9. Confirm your adjustment using [ENTER].



[ENTER]

Resetting Parameters

To reset parameters, proceed as described above, and enter your Sunny Central's original values.

7 Communication

With the option "NET Piggy-Back", the Sunny Central Control can be remotely monitored, and can send you e-mail reports regarding the operating mode, or present failures. Depending on your order preferences, the Sunny Central is delivered ex works either without communication, or with a NET Piggy-Back in one of the three following variants:

- Analog
- ISDN
- Ethernet

The connection of the Sunny Central Control to the telephone line, to a router, or to a PC, is described in the NET Piggy-Back documentation.

The Sunny Central Control is preconfigured for the respective communication type. If you wish to receive e-mail reports, you must specify this in the menu "Remote-Info".

7.1 Remote-Info

1. Enter the password as described in section 5.4 "Entering the Password" (page 26).
2. In the online info display, press [ESC].

Status	MPP
Pac	85.7kW
E_Today	357.5kWh
E_Total	2512.3kWh

[ESC]

3 x [↓]


3. Navigate to the "Device Set-up" menu with the [↓] arrow button, and select it by pressing [ENTER].

[Main Menu]
Operating Data
Spot Values
Long-Term Data
→ Device Set-up

[ENTER]

4. Navigate to the "NET/eMail" menu with the [↓] arrow button, and select it by pressing [ENTER].


6 x [↓]



[ENTER]


5. Navigate to the "Remote-Info" menu with the [↓] arrow button, and select it by pressing [ENTER].

1 x [↓]



[ENTER]


6. The menu shown to the right appears.



[ENTER]

7.2 Activating E-mail Reports


1. Select the "Remote-Info" menu as described in section 7.1 "Remote-Info" (page 34).
2. Press [ENTER].
3. The line "deactivated" begins to flash.
4. With the [↓] arrow button, change the menu item to "activated".
5. Confirm your adjustment by pressing [ENTER] twice.



7.3 Entering or Changing E-Mail Addresses


1. Select the "Remote-Info" menu as described in section 7.1 "Remote-Info" (page 34).
2. Navigate to the "Recipient" menu with the [↓] arrow button, and select it by pressing [ENTER].

2 x [↓]



[ENTER]

3. On the first line, enter a company name. Confirm your entry using [ENTER].
4. On the second line, enter your name. Confirm your entry using [ENTER].
5. Enter your e-mail address on the third line. Confirm your entry using [ENTER].
6. On lines four and five, you can specify two additional e-mail addresses, to which the reports are to be sent. Confirm your entry using [ENTER].



7.4 Selecting the Report Types to Send

1. Select the "Remote-Info" menu as described in section 7.1 "Remote-Info" (page 35).
2. Navigate to the "Events" menu with the [↓] arrow button, and select it by pressing [ENTER].

2 x [↓]

[REMOTE-INFO]
E-mail
...deactivated

→ Events
Recipient

[ENTER]

3. In the "Events" menu, you can specify which reports you wish to have sent to you, and when.

[EVENTS]
Plant-Info
...daily report
Warnings
...daily report
Errors
...hourly report

Send at
.....22:15


Menu item	Description	Possible settings
Plant-Info	reports the present values of your system, e.g. E-Total, E-Today	<ul style="list-style-type: none"> • no report • daily report (recommended)
Warnings	reports the generated warning messages	<ul style="list-style-type: none"> • no report • hourly report • daily report (recommended)
Errors	reports the failures which have occurred	<ul style="list-style-type: none"> • no report • hourly report (recommended) • daily report
Send at	Here, the time at which the daily report is to be sent can be defined. We recommend setting the time to 22:15 (10.15 p. m.).	<ul style="list-style-type: none"> • time

7.5 Sending a Test Report

To check the settings, you can send a test report.


1. Select the "Remote-Info" menu as described in section 7.1 "Remote-Info" (page 35).
2. Navigate to the "Test-Report" menu with the [↓] arrow button, and select it by pressing [ENTER].

6 x [↓]




[ENTER]

3. The Sunny Central Control shows "Start" in the display. Press [ENTER] to send a test report.



If the test report cannot be sent, the display shown to the right appears. The meaning of the error code on the bottom line is described in the NET Piggy-Back documentation.



8 External Sensors

This section describes how the sensors are configured. The connection of sensors is described in the Sunny Central's installation guide. The connection points are shown in your Sunny Central's wiring diagrams.

8.1 Configuring the External Sensors

In total, two external analog sensors and one analog PT100 temperature sensor can be installed at the Sunny Central Control. You can use the analog inputs 3, 4 and 8 for the sensors.

Input	Possible settings	Default value	Measured value
3	deactivated,	+/- 10 V	analog measured value
4	+/- 20 mA (jumper required)		
	+/- 10 mV		
	+/- 20 mV		
	+/- 50 mV		
	+/- 100 mV		
	+/- 500 mV		
	+/- 1 V		
	+/- 5 V		
	+/- 10 V		
8	PT100	PT100	PT100 temperature


1. Enter the password as described in section 5.4 "Entering the Password" (page 26).
2. In the online info display, press [ESC].

Status	MPP
Pac	85.7kW
E_Today	357.5kWh
E_Total	2512.3kWh

[ESC]

- 3. Navigate to the "Device Set-up" menu with the [↓] arrow button, and select it by pressing [ENTER].


3 x [↓]



[ENTER]

- 4. Navigate to the "Interfaces" menu with the [↓] arrow button, and select it by pressing [ENTER].


3 x [↓]



[ENTER]


- 5. Navigate to the "Analog In" menu with the [↓] arrow button, and select it by pressing [ENTER].

1 x [↓]



[ENTER]

- 6. Navigate to the desired analog input (Ain 3, Ain 4, or Ain 8) with the [↓] arrow button, and select it by pressing [ENTER].



[ENTER]

7. You are presented with a detailed view of the selected analog input.

[Ain 3]
Function Ain 3
.....-
Name
Ain 3
Unit
mV
Gain
1
Offset
0

[ENTER]

Menu item	Meaning	
Function Ain x	Function of the analog input	
	Possible settings	Meaning
	deactivated	the analog input is deactivated
	+/- 20 mA	current measurement -20 mA to +20 mA
	+/- 10 mV	voltage measurement -10 mV to +10 mV
	+/- 20 mV	voltage measurement -20 mV to +20 mV
	+/- 50 mV	voltage measurement -50 mV to +50 mV
	+/- 100 mV	voltage measurement -100 mV to +100 mV
	+/- 500 mV	voltage measurement -500 mV to +500 mV
	+/- 1 V	voltage measurement -1 V to +1 V
	+/- 5 V	voltage measurement -5 V to +5 V
	+/- 10 V	voltage measurement -10 V to +10 V
Name	name of the analog input	
Unit	measurement unit of the analog input	
Gain	conversion factor	
Offset	value which is added	

8.2 Calculating Gain and Offset

1. To activate the analog input, you must select a measurement range for the analog sensor (e.g. +/- 10 V).
2. Name the sensor (e.g. Temperature).
3. Enter the unit of measurement (e.g. W/m²).
4. The displayed value is calculated by means of:
 - the value measured by the sensor,
 - the value which you have specified as the gain, and
 - the value which you have specified as the offset.
5. The gain factor is obtained by dividing the display range by the measuring range.

[Ain 3]
Function Ain 3
...+/- 10V
Name
Radiation
Unit
W/m ²
Gain
135
Offset
0

$$\text{Gain factor} = \frac{\text{Display range}}{\text{Measuring range}}$$

6. The offset is calculated by subtracting the product of the gain factor and the lower end of the measuring range from the lower end of the display range.

$$\text{Offset} = \text{lower end of display range} - (\text{gain factor} * \text{lower end of measuring range})$$

Expressed in formulas:

M is a value measured in a range between Ml and Mu.

D is the value displayed in a range between Dl and Du.

Gain: $G = (Du - Dl) / (Mu - Ml)$

Offset: $O = Dl - (G * Ml)$

Displayed value: $D = (G * M) + O$

Explanation of the Abbreviations Used

M	measured value	Mu	upper end of measuring range
Ml	lower end of measuring range	O	offset
G	gain	D	displayed value
Du	upper end of display range	Dl	lower end of display range

Example Calculations: Pyranometer

A pyranometer has an output voltage of 0 to 10 V. This corresponds to irradiation of 0 to 1350 W/m².

$$M_l = 0 \text{ V}$$

$$M_u = 10 \text{ V}$$

$$D_l = 0 \text{ W/m}^2$$

$$D_u = 1350 \text{ W/m}^2$$

Formula	Calculation
$G = (D_u - D_l) / (M_u - M_l)$	$G = (1350 - 0) / (10 - 0) = 135$
$O = D_l - (G * M_l)$	$O = 0 - (135 * 0) = 0 \text{ W/m}^2$

If $M = 5 \text{ V}$:

Formula	Calculation
$D = (G * M) + O$	$135 * 5 + 0 = 675$

Example Calculations: Temperature Sensor

A temperature sensor with a converter outputs 4 - 20 mA. This corresponds to a temperature range of -30 to 80 °C.

$$M_l = 4 \text{ mA}$$

$$M_u = 20 \text{ mA}$$

$$D_l = -30 \text{ °C}$$

$$D_u = 80 \text{ °C}$$


Formula	Calculation
$G = (D_u - D_l) / (M_u - M_l)$	$G = (80 - (-30)) / (20 - 4) = 6.875$
$O = D_l - (G * M_l)$	$O = (-30) - (6.875 * 4) = -57.5 \text{ °C}$

If $M = 4 \text{ mA}$:

Formula	Calculation
$D = (G * M) + O$	$4 * 6.875 + (-57.5) = -30$

9 Failures and Warnings

If a failure occurs during operation, the Sunny Central will shut down and the disturbance will be displayed by the Sunny Central Control. If several disturbances or warnings are present, the Sunny Central Control shows the disturbance which has the highest priority. It alternates between the present online info display, and the failure message. A failure message appears in the display as shown below.



- A Failure / warning number
- B Reason for failure / warning in plain text

9.1 Fault Diagnosis

9.1.1 Categories of Failures and Warnings

The failure numbers and warning numbers are allocated to different areas of the Sunny Central.

Numerical range	Category of failure / warning
100 to 179	grid faults
180 to 199	grid warnings
200 to 279	cabinet hardware failures
280 to 299	cabinet hardware warnings
300 to 379	Sunny String Monitor failures
380 to 399	Sunny String Monitor warnings
400 to 479	stack hardware failures
480 to 499	stack hardware warnings
500 to 579	Team failures
580 to 599	Team warnings

9.1.2 Types of Failures and Warnings

Sunny Central failures and warnings are subdivided into four types:

Error Type 1 (Warning)

The Sunny Central does not switch itself off. Once the error is no longer present, the error message is reset automatically. Check the system.

Error Type 2 (Failure)

The Sunny Central switches itself off. Once the fault is no longer present, the error message is reset automatically, and the Sunny Central starts up again.

Error Type 3 (Failure)

The Sunny Central switches itself off. Error type 3 only arises if the Sunny Central is feeding the grid when a fault occurs. Once the fault is no longer present, the error message is reset automatically, and the Sunny Central starts up again.

Error Type 4 (Failure)

Error type 4 must be confirmed before the Sunny Central can resume operation.

The Sunny Central switches itself off. Rectify the cause of the fault, and confirm the error at the Sunny Central Control, or with Sunny Data Control. Once you have confirmed the error, the Sunny Central starts up again.

9.1.3 Warnings

No.	Description
281	<p data-bbox="180 244 1012 288">Error text: Error type 1</p> <p data-bbox="180 288 1012 328">Ground fault or SPD defect</p> <p data-bbox="180 328 1012 368">Cause:</p> <p data-bbox="180 368 1012 408">The alert chain is interrupted (refer to the wiring diagram).</p> <ul data-bbox="202 408 1012 560" style="list-style-type: none"> • Overvoltage protector damaged. • Back-up fuse(s) damaged on the grid side or generator side (if present). • The solar power system's insulation resistance is lower than the set threshold value. • The transformer's biasing circuit breaker has tripped. <p data-bbox="180 560 1012 600">Corrective measures:</p> <ul data-bbox="202 600 1012 919" style="list-style-type: none"> • Check fault signaling of the overvoltage protectors, and replace protector if necessary. • Check the back-up fuse(s) of the overvoltage protector and replace it / them if necessary. • Check the resistance of the solar power system. • In the event of an insulation fault, check strings under load-free conditions. Separate and connect individual strings to determine which string is faulty. • Check the function of the ground fault monitor. • Switch biasing circuit breaker of the transformer back on.
283	<p data-bbox="180 919 1012 959">Error text: Error type 1</p> <p data-bbox="180 959 1012 999">cabinet Temp.</p> <p data-bbox="180 999 1012 1038">Cause:</p> <p data-bbox="180 1038 1012 1110">The threshold value (parameter TMin or TMax) for the permissible cabinet temperature has been breached (too high or too low).</p> <p data-bbox="180 1110 1012 1150">Corrective measures:</p> <ul data-bbox="202 1150 1012 1270" style="list-style-type: none"> • Check function of cabinet cooling fans. • Clean or replace dirty air filters. • Check ambient temperature, and adjust if necessary.

No.	Description
380	<p data-bbox="184 204 1009 236">Error text: Error type 1</p> <p data-bbox="184 244 235 276">SMU</p> <p data-bbox="184 292 263 323">Cause:</p> <p data-bbox="184 331 940 387">The string monitoring system has detected one or more faulty strings or overvoltage protectors.</p> <p data-bbox="184 403 425 435">Corrective measures:</p> <ul data-bbox="201 443 940 539" style="list-style-type: none"> <li data-bbox="201 443 940 499">• Under "Device Set-up -> SMUs -> Devices -> Measured Values", read out the individual string currents to detect the faulty string. <li data-bbox="201 507 940 539">• More detailed information can be found in the Sunny String Monitor manual.
381	<p data-bbox="184 550 1009 582">Error text: Error type 1</p> <p data-bbox="184 590 453 622">ser. com. with SMU disturbed</p> <p data-bbox="184 638 263 670">Cause:</p> <p data-bbox="184 678 896 710">Communication failure between Sunny Central and the Sunny String Monitors.</p> <p data-bbox="184 726 425 758">Corrective measures:</p> <ul data-bbox="201 766 940 826" style="list-style-type: none"> <li data-bbox="201 766 940 790">• Check communication lines and connections. <li data-bbox="201 798 940 826">• More detailed information can be found in the Sunny String Monitor manual.
382	<p data-bbox="184 837 1009 869">Error text: Error type 1</p> <p data-bbox="184 877 364 909">thievery solar panel</p> <p data-bbox="184 925 263 957">Cause:</p> <p data-bbox="184 965 912 997">Signal loop for theft detection at the Sunny String Monitor has been interrupted.</p> <p data-bbox="184 1013 425 1045">Corrective measures:</p> <ul data-bbox="201 1053 1002 1176" style="list-style-type: none"> <li data-bbox="201 1053 1002 1077">• Check string currents. <li data-bbox="201 1085 1002 1109">• Check signal loop. <li data-bbox="201 1117 1002 1176">• For further details, refer to the installation guide and user manual of the Sunny String Monitor or Sunny String Monitor Cabinet.

No.	Description
585	<p data-bbox="188 209 1010 247">Error text: Error type 1 ser. com. with team disturbed</p> <p data-bbox="188 292 1010 330">Cause: The communication between Team leader and member is interrupted.</p> <p data-bbox="188 375 1010 517">Corrective measures:</p> <ul data-bbox="204 414 705 517" style="list-style-type: none"> • Check the RS485 cabling for Team communication. • Check power supply of the Team member. • Check Team parameters at both Sunny Centrals.
586	<p data-bbox="188 533 1010 571">Error text: Error type 1 Team contactor remain opened</p> <p data-bbox="188 616 1010 654">Cause: The Team contactor does not switch on.</p> <p data-bbox="188 699 1010 841">Corrective measures:</p> <ul data-bbox="204 738 812 841" style="list-style-type: none"> • Check the triggering of the Team contactor. • Check the isolation contactor's feedback contact. • Check whether the Team current monitoring system has tripped.
587	<p data-bbox="188 857 1010 895">Error text: Error type 1 Team contactor remain closed</p> <p data-bbox="188 940 1010 978">Cause: The Team contactor has not switched off. The switching contacts may have become stuck.</p> <p data-bbox="188 1023 1010 1161">Corrective measures:</p> <ul data-bbox="204 1062 688 1161" style="list-style-type: none"> • Check the triggering of the Team contactor. • Check the contact position of the Team contactor. • Contact the Sunny Central Serviceline.

No.	Description
588	<div style="display: flex; justify-content: space-between;"> <div data-bbox="185 209 300 233">Error text:</div> <div data-bbox="866 209 987 233">Error type 1</div> </div> <p data-bbox="185 248 445 272">Team contactor was opened</p> <hr/> <p data-bbox="185 293 264 317">Cause:</p> <p data-bbox="185 333 882 357">The Team contactor was switched off by the Team current monitoring system.</p> <p data-bbox="185 378 426 402">Corrective measures:</p> <ul data-bbox="204 418 983 549" style="list-style-type: none"> • Check the triggering of the Team contactor. • Check the Team current monitoring system (settings, defect). • Check the Team current, may be too high due to asymmetrical current distribution. • Contact the Sunny Central Serviceline.

9.1.4 Failures

No.	Description
104	<p data-bbox="184 252 1010 292">Error text: Error type 3 No Grid Synchronization</p> <p data-bbox="184 336 1010 405">Cause: Left-hand rotary field or internal device fault.</p> <p data-bbox="184 421 1010 564">Corrective measures:</p> <ul data-bbox="202 459 684 564" style="list-style-type: none"> • Check (right-hand) rotary field. • Check whether all internal fuses are switched on. • Contact the Sunny Central Serviceline.
105	<p data-bbox="184 576 1010 616">Error text: Error type 2 Grid voltage too low</p> <p data-bbox="184 660 1010 729">Cause: Voltage on the AC side is below the permitted range.</p> <p data-bbox="184 745 1010 852">Corrective measures:</p> <ul data-bbox="202 783 490 852" style="list-style-type: none"> • Check the grid connections. • Check grid stability.
106	<p data-bbox="184 863 1010 903">Error text: Error type 2 Grid voltage too high</p> <p data-bbox="184 948 1010 1016">Cause: Voltage on the AC side is above the permitted range.</p> <p data-bbox="184 1032 1010 1139">Corrective measures:</p> <ul data-bbox="202 1070 490 1139" style="list-style-type: none"> • Check the grid connections. • Check grid stability.
110	<p data-bbox="184 1150 1010 1190">Error text: Error type 2 UVW-Range</p> <p data-bbox="184 1235 1010 1303">Cause: Voltage on phase L1, L2, or L3 outside the permitted range.</p> <p data-bbox="184 1319 1010 1423">Corrective measures:</p> <ul data-bbox="202 1358 490 1423" style="list-style-type: none"> • Check the grid connections. • Check grid stability.

No.	Description
111	<p data-bbox="188 209 1012 245">Error text: Error type 2</p> <p data-bbox="188 253 505 276">Grid frequency too high or too low</p> <hr/> <p data-bbox="188 293 264 316">Cause:</p> <p data-bbox="188 333 703 355">Frequency on the AC side is outside the permitted range.</p> <p data-bbox="188 373 426 395">Corrective measures:</p> <ul data-bbox="204 413 505 512" style="list-style-type: none"> • Check the grid connections. • Check grid stability. • Check right-hand rotary field.
201	<p data-bbox="188 536 1012 572">Error text: Error type 2</p> <p data-bbox="188 580 538 603">Ground Fault 2 or plant temp. too high</p> <hr/> <p data-bbox="188 620 264 643">Cause:</p> <ul data-bbox="204 660 981 895" style="list-style-type: none"> • The overtemperature fault chain is interrupted (refer to the wiring diagram). • Cabinet overtemperature • Transformer overtemperature • Diode overtemperature • The insulation resistance of the solar power system is lower than the set threshold value. • GFDI tripped. <p data-bbox="188 912 426 935">Corrective measures:</p> <ul data-bbox="204 952 1005 1265" style="list-style-type: none"> • Check function of cooling fans. • Clean or replace dirty air filters. • Ambient or cooling air temperature too high. • Check solar generator's insulation resistance. • In the event of an insulation fault, separate and connect individual strings to detect the faulty one. • Check the function of the ground fault monitor. • Check the GFDI (see "Additional Notes for Sunny Central M/P Inverters for Grounded Operation of the Solar Generator").

No.	Description
206	<p data-bbox="184 204 1010 236">Error text: Error type 4 Emergency shutdown activated</p> <p data-bbox="184 288 1010 357">Cause: Own emergency shut-off of the inverter activated.</p> <p data-bbox="184 373 1010 466">Corrective measures: Deactivate the emergency shut-off and confirm the failure as described in section 9.2 "Confirming Errors at the Sunny Central Control" (page 58).</p>
209	<p data-bbox="184 483 1010 552">Error text: Error type 4 DC Short circuit</p> <p data-bbox="184 568 1010 660">Cause: An internal short circuit was detected on the DC side within the inverter. The DC switch was switched off.</p> <p data-bbox="184 676 1010 820">Corrective measures:</p> <ul data-bbox="202 719 777 820" style="list-style-type: none"> • Check the Sunny Central from the outside. • If possible, the Sunny Central should be externally isolated. • Contact the Sunny Central Serviceline.
215	<p data-bbox="184 837 1010 906">Error text: Error type 2 heat sink fan fault</p> <p data-bbox="184 922 1010 1066">Cause:</p> <ul data-bbox="202 965 972 1066" style="list-style-type: none"> • Motor overload switch for fan(s) for cooling the power module has tripped. • Overtemperature protection for fan(s) for cooling the power module has tripped. • Ambient or cooling air temperatures too high. <p data-bbox="184 1082 1010 1256">Corrective measures:</p> <ul data-bbox="202 1125 852 1256" style="list-style-type: none"> • Switch the motor overload switch back on. • Check function of cooling fans. • Clean soiled air inlet or heatsink. • If this error occurs frequently, contact the Sunny Central Serviceline.

No.	Description
217	<p data-bbox="188 209 1010 245">Error text: Error type 2 DC CB tripped or door switch open</p> <p data-bbox="188 292 264 316">Cause:</p> <ul data-bbox="204 331 880 467" style="list-style-type: none"> • The cabinet door was opened during operation. • The DC circuit breaker was tripped due to an internal fault. • The reverse current monitoring system on the DC side has switched off. • The EVR resistor's current monitoring system has tripped. <p data-bbox="188 488 426 512">Corrective measures:</p> <ul data-bbox="204 528 835 735" style="list-style-type: none"> • Close the cabinet doors. • Check the function of the door switches. • Check the function and activation of the emergency shut-off relay. • Check reverse current monitoring system. • Visually inspect the chopper module and the EVR resistors. • Contact the Sunny Central Serviceline.
220	<p data-bbox="188 759 1010 796">Error text: Error type 2 Release or Reset Signal faulty</p> <p data-bbox="188 842 264 866">Cause: The release signal or confirmation signal of the inverter bridge is defective.</p> <p data-bbox="188 922 426 946">Corrective measures: If this error is always present, contact the Sunny Central Serviceline.</p>
221	<p data-bbox="188 1007 1010 1043">Error text: Error type 3 CHOPPER overtemperature</p> <p data-bbox="188 1090 264 1114">Cause:</p> <ul data-bbox="204 1129 667 1233" style="list-style-type: none"> • EVR resistor overtemperature. • Defective chopper module. • After 90 minutes, a new startup attempt occurs. <p data-bbox="188 1254 426 1278">Corrective measures:</p> <ul data-bbox="204 1294 589 1382" style="list-style-type: none"> • Check resistor for dirt. • Ventilate resistor sufficiently. • Contact the Sunny Central Serviceline.

No.	Description						
400	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">Error text: internal failure of inverter bridge</td> <td style="width: 30%; text-align: right;">Error type 2/3</td> </tr> <tr> <td colspan="2">Cause: Internal inverter bridge failure (e.g. symmetry fault, board voltage, undertemperature, sensor breakage).</td> </tr> <tr> <td colspan="2">Corrective measures: If this error occurs frequently, contact the Sunny Central Serviceline.</td> </tr> </table>	Error text: internal failure of inverter bridge	Error type 2/3	Cause: Internal inverter bridge failure (e.g. symmetry fault, board voltage, undertemperature, sensor breakage).		Corrective measures: If this error occurs frequently, contact the Sunny Central Serviceline.	
Error text: internal failure of inverter bridge	Error type 2/3						
Cause: Internal inverter bridge failure (e.g. symmetry fault, board voltage, undertemperature, sensor breakage).							
Corrective measures: If this error occurs frequently, contact the Sunny Central Serviceline.							
402	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">Error text: ser. com. with inverter bridge disturbed</td> <td style="width: 30%; text-align: right;">Error type 2</td> </tr> <tr> <td colspan="2">Cause: <ul style="list-style-type: none"> • The RS485 communication between the inverter bridge and the Sunny Central Control is interrupted. • The inverter bridge or the Sunny Central Control may be faulty. </td> </tr> <tr> <td colspan="2">Corrective measures: <ul style="list-style-type: none"> • Check the RS485 wiring. • If this error is always present, contact the Sunny Central Serviceline. </td> </tr> </table>	Error text: ser. com. with inverter bridge disturbed	Error type 2	Cause: <ul style="list-style-type: none"> • The RS485 communication between the inverter bridge and the Sunny Central Control is interrupted. • The inverter bridge or the Sunny Central Control may be faulty. 		Corrective measures: <ul style="list-style-type: none"> • Check the RS485 wiring. • If this error is always present, contact the Sunny Central Serviceline. 	
Error text: ser. com. with inverter bridge disturbed	Error type 2						
Cause: <ul style="list-style-type: none"> • The RS485 communication between the inverter bridge and the Sunny Central Control is interrupted. • The inverter bridge or the Sunny Central Control may be faulty. 							
Corrective measures: <ul style="list-style-type: none"> • Check the RS485 wiring. • If this error is always present, contact the Sunny Central Serviceline. 							
408	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">Error text: PV Overvoltage</td> <td style="width: 30%; text-align: right;">Error type 3</td> </tr> <tr> <td colspan="2">Cause: DC voltage is too high on the generator side (software).</td> </tr> <tr> <td colspan="2">Corrective measures: <ul style="list-style-type: none"> • Immediately disconnect the solar generator from the Sunny Central! Risk of damage to the Sunny Central! • Check DC voltage. • Check module wiring and system design. </td> </tr> </table>	Error text: PV Overvoltage	Error type 3	Cause: DC voltage is too high on the generator side (software).		Corrective measures: <ul style="list-style-type: none"> • Immediately disconnect the solar generator from the Sunny Central! Risk of damage to the Sunny Central! • Check DC voltage. • Check module wiring and system design. 	
Error text: PV Overvoltage	Error type 3						
Cause: DC voltage is too high on the generator side (software).							
Corrective measures: <ul style="list-style-type: none"> • Immediately disconnect the solar generator from the Sunny Central! Risk of damage to the Sunny Central! • Check DC voltage. • Check module wiring and system design. 							

No.	Description
409	<p data-bbox="185 209 994 236">Error text: IGBT Stack Temperature Error type 3</p> <p data-bbox="185 292 264 316">Cause: Heatsink temperature is too high (software).</p> <p data-bbox="185 375 426 399">Corrective measures:</p> <ul data-bbox="204 413 852 549" style="list-style-type: none"> • Check function of the cooling fans of the inverter bridge. • Clean soiled air inlet or heatsink. • Ambient or cooling air temperature too high. • If this error occurs frequently, contact the Sunny Central Serviceline.
410	<p data-bbox="185 571 994 598">Error text: IGBT Stack Error Sum Error type 3</p> <p data-bbox="185 654 264 678">Cause: Internal failure of the inverter bridge (e.g. DC overvoltage, overtemperature, defective driver, overcurrent).</p> <p data-bbox="185 766 426 790">Corrective measures: If this error occurs frequently, contact the Sunny Central Serviceline.</p>
411	<p data-bbox="185 847 994 874">Error text: IGBT Overcurrent or UVW phase fault ADAPSCP Error type 3</p> <p data-bbox="185 930 264 954">Cause: Internal inverter bridge failure.</p> <p data-bbox="185 1013 426 1037">Corrective measures: If this error occurs frequently, contact the Sunny Central Serviceline.</p>
412	<p data-bbox="185 1098 994 1125">Error text: Overcurrent Error type 3</p> <p data-bbox="185 1181 264 1204">Cause: Internal inverter bridge failure.</p> <p data-bbox="185 1260 426 1284">Corrective measures: If this error occurs frequently, contact the Sunny Central Serviceline.</p>

No.	Description
420	<p data-bbox="184 204 1002 236">Error text: ADAPSCP overtemperature Error type 3</p> <p data-bbox="184 288 263 316">Cause: Heatsink temperature is too high (hardware threshold).</p> <p data-bbox="184 373 425 400">Corrective measures:</p> <ul data-bbox="201 411 851 550" style="list-style-type: none"> • Check function of the cooling fans of the inverter bridge. • Clean soiled air inlet or heatsink. • Ambient or cooling air temperature too high. • If this error occurs frequently, contact the Sunny Central Serviceline.
421	<p data-bbox="184 566 1002 598">Error text: ADAPSCP Overvoltage DC voltage link Error type 2</p> <p data-bbox="184 651 263 678">Cause: DC voltage is too high on the solar generator side (hardware threshold).</p> <p data-bbox="184 735 425 762">Corrective measures:</p> <ul data-bbox="201 774 1002 896" style="list-style-type: none"> • Immediately disconnect the solar generator from the Sunny Central! Risk of damage to the Sunny Central! • Check DC voltage. • Check module wiring and system design.

9.2 Confirming Errors at the Sunny Central Control

1. Rectify the cause of the fault at the Sunny Central.
2. In the online info display, press [ESC].

Status	MPP
Pac	85.7kW
E_Today	357.5kWh
E_Total	2512.3kWh

[ESC]

3. Select "Operating Data" by pressing [ENTER].

[Main Menu]
→ Operating Data
Spot Values
Long-Term Data
Device Set-up

[ENTER]

4. Select "Faults" by pressing [ENTER].

[Plant Data]
→ Faults
Plant Status
Energy Yield
Data Files
Other


[ENTER]

5. Select "Actual Faults" by pressing [ENTER].

[Faults]
→ Current Faults

[ENTER]


- 6. If a failure or warning is present, it is displayed with its date and time of occurrence.
- 7. To confirm the error, press [ENTER]. The display begins to flash.



[ENTER]


- 8. Press the [↓] arrow button once. The word "quit" appears in the display.
- 9. If you wish to confirm the error, confirm twice with [ENTER].

1 x [↓]



2 x [ENTER]

- 10. The message "no faults" appears in the display.



10 Maintenance

**WARNING!****Risk of lethal electric shock!****High voltages are present in the device.**

- All work on the Sunny Central must be carried out by a qualified electrician!
- Open the Sunny Central for maintenance as described in the installation guide.

The Sunny Central must be maintained at regular intervals. Maintenance includes:

- Inspection of wearing parts, and replacement thereof if necessary
- Functionality test of components
- Inspection of contact joints
- Cleaning of cabinet interior if necessary

The maintenance intervals depend on the location and the ambient conditions. A Sunny Central installed in an environment with very dusty ambient air requires more frequent maintenance than indicated in the following table.

Time Intervals for Maintenance Work

Maintenance work	Maintenance interval (recommended)
Read out long-term data and error memory.	1 month * (depending on system size)
Clean or replace the filter material in the air inlet filters.	6 months *
Clean the insect guards at the air inlets and outlets.	6 months *
Clean the heatsink power module	12 months *
Check the inside of the cabinet and the EVR resistor for heavy dust deposits, dirt, moisture, and water penetration from outside. If necessary, clean the Sunny Central and employ suitable corrective measures.	12 months
Check all power cable connections for looseness and tighten them if necessary. Check the connectors and insulation for discoloration or degradation. Replace any damaged connectors or corroded contacts.	12 months
Check adhesive warning labels and replace if necessary.	12 months
Cooling fans functionality test. Check all cooling fans for functionality and operating noise. The fans can be switched on by adjusting the thermostats, or during operation. If present: cabinet fan, heatsink fan(s), internal circulation fan(s), diode fan, heating fan	12 months
Heating functionality test.	12 months
Functionality test of all protective equipment present: <ul style="list-style-type: none"> • leakage current circuit breakers • line circuit breakers • power switches • motor overload switches by means of manual activation or by pressing the test button (if applicable).	12 months
Visually check all fuses and disconnectors, and lubricate the contacts if necessary.	12 months
Check overvoltage protectors.	12 months *
Check the 230 V und 24 V control and auxiliary voltages.	12 months
Overtemperature functionality test. Check the overtemperature safety circuit.	12 months

Maintenance work	Maintenance interval (recommended)
Emergency shut-off functionality test. Check the function of the internal and external emergency shut-off switches.	12 months
Check the function of the door contacts.	12 months
Insulation monitoring / GFDI functionality test. Check the function and the signaling.	12 months

* The maintenance interval may need to be shortened, depending on the location or ambient conditions.



Regular Data Backups

Backup and archive the Sunny Central Control data regularly with Sunny Data Control. This can occur by means of remote querying, or during routine maintenance.

11 Contact

If you have technical problems with our products, contact the SMA Service Line. We require the following information in order to provide you with the necessary assistance:

- Inverter type
- Type and number of modules connected
- Communication method
- Serial number of the Sunny Central
- Sunny Central failure or warning number
- Sunny Central display message

SMA Solar Technology AG

Sonnenallee 1

34266 Niestetal, Germany

Tel. +49 561 9522 299

Fax +49 561 9522 3299

SunnyCentral.Service@SMA.de

www.SMA.de

The information contained in this document is the property of SMA Solar Technology AG. Publishing its content, either partially or in full, requires the written permission of SMA Solar Technology AG. Any internal company copying of the document for the purposes of evaluating the product or its correct implementation is allowed and does not require permission.

Exclusion of liability

The general terms and conditions of delivery of SMA Solar Technology AG shall apply.

The content of these documents is continually checked and amended, where necessary. However, discrepancies cannot be excluded. No guarantee is made for the completeness of these documents. The latest version is available online at www.SMA.de or from the usual sales channels.

Guarantee or liability claims for damages of any kind are excluded if they are caused by one or more of the following:

- Damages during transportation
- Improper or inappropriate use of the product
- Operating the product in an unintended environment
- Operating the product whilst ignoring relevant, statutory safety regulations in the deployment location
- Ignoring safety warnings and instructions contained in all documents relevant to the product
- Operating the product under incorrect safety or protection conditions
- Altering the product or supplied software without authority
- The product malfunctions due to operating attached or neighboring devices beyond statutory limit values
- In case of unforeseen calamity or force majeure

The use of supplied software produced by SMA Solar Technology AG is subject to the following conditions:

- SMA Solar Technology AG rejects any liability for direct or indirect damages arising from the use of software developed by SMA Solar Technology AG. This also applies to the provision or non-provision of support activities.
- Supplied software not developed by SMA Solar Technology AG is subject to the respective licensing and liability agreements of the manufacturer.

SMA Factory Warranty

The current guarantee conditions come enclosed with your device. These are also available online at www.SMA.de and can be downloaded or are available on paper from the usual sales channels if required.

Trademarks

All trademarks are recognized even if these are not marked separately. Missing designations do not mean that a product or brand is not a registered trademark.

The *Bluetooth*[®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by SMA Solar Technology is under license.

SMA Solar Technology AG

Sonnenallee 1

34266 Niestetal

Germany

Tel. +49 561 9522-0

Fax +49 561 9522-100

www.SMA.de

E-Mail: info@SMA.de

© 2004 to 2009 SMA Solar Technology AG. All rights reserved

SMA Solar Technology AG

www.SMA.de

Sonnenallee 1

34266 Niestetal, Germany

Tel.: +49 561 9522 4000

Fax: +49 561 9522 4040

E-Mail: Vertrieb@SMA.de

Freecall: 0800 SUNNYBOY

Freecall: 0800 78669269

