


**SUNNY CENTRAL 500CP-JP / 630CP-JP /
800CP-JP / 1000CP-JP**



Legal Provisions

The information contained in these documents is property of SMA Solar Technology AG. Any publication, whether in whole or in part, requires prior written approval by SMA Solar Technology AG. Internal reproduction used solely for the purpose of product evaluation or other proper use is allowed and does not require prior approval.

SMA Warranty

You can download the current warranty conditions from the Internet at www.SMA-Solar.com.

Software licenses

You will find the software licenses for the installed software modules on the Internet at www.SMA-Solar.com.

Trademarks

All trademarks are recognized, even if not explicitly identified as such. Missing designations do not mean that a product or brand is not a registered trademark.

Modbus® is a registered trademark of Schneider Electric and is licensed by the Modbus Organization, Inc.

QR Code is a registered trademark of DENSO WAVE INCORPORATED.

Phillips® and Pozidriv® are registered trademarks of Phillips Screw Company.

Torx® is a registered trademark of Acument Global Technologies, Inc.

SMA Solar Technology AG

Sonnenallee 1

34266 Niestetal

Germany

Tel. +49 561 9522-0

Fax +49 561 9522-100

www.SMA.de

Email: info@SMA.de

Copyright © 2016 SMA Solar Technology AG. All rights reserved.

Table of Contents

1	Information on this Document.....	6
1.1	Validity	6
1.2	Target Group	6
1.3	Additional Information.....	6
1.4	Levels of warning messages.....	6
1.5	Symbols in the Document.....	7
1.6	Typographies	7
1.7	Designations in the Document	7
2	Safety	8
2.1	Intended Use.....	8
2.2	Safety Information	9
2.3	Personal Protective Equipment	12
3	Product Overview	13
3.1	Design of the Inverter	13
3.2	Devices of the Inverter.....	13
3.3	Symbols on the Product.....	14
4	Transport and Mounting.....	15
4.1	Safety during Transport and Mounting	15
4.2	Requirements for Transport and Mounting	15
4.2.1	Requirements and Ambient Conditions.....	15
4.2.2	Center of Gravity Marker on the Inverter.....	16
4.2.3	Preparation for Mounting	16
4.2.3.1	Drilling Mounting Holes in the Foundation.....	16
4.2.3.2	Preparation for Mounting on a Base	16
4.3	Transporting the Inverter	17
4.3.1	Transporting the Inverter Using a Pallet Truck	17
4.3.2	Transporting the Inverter Using a Forklift or a Crane Fork	17
4.3.3	Transporting the Inverter Using a Crane	18
4.4	Mounting of the Inverter.....	20
4.4.1	Mounting the Inverter on a Foundation	20
4.4.2	Mounting the Inverter on a Base.....	20
5	Installation	21
5.1	Safety during Installation.....	21
5.2	Preparing the Installation.....	22
5.2.1	Mounting the Silencing Baffle	22
5.2.2	Replacing the Desiccant Bag in the Inverter.....	23
5.2.3	Mounting the Ventilation Plate	23
5.3	Installing the Grounding.....	23
5.4	Installing the DC Connection	24
5.4.1	Connecting the DC Cable to the Busbar	24
5.4.2	Connecting the DC Cables to the Connection Brackets	26
5.5	Installing the AC Connection	27
5.6	Cables for Communication, Control, Supply Voltage and Monitoring.....	29
5.6.1	Connecting Optical Fibers with Subscriber Connector.....	29
5.6.2	Connecting Optical Fibers via Optical Fiber Pigtail	31
5.6.3	Connecting the Network Cables.....	32
5.6.4	Connecting Cables for Analog Setpoints	33

5.6.5	Connecting the Cable for the External Fast Stop	33
5.6.6	Connecting the Cable for Remote Shutdown	34
5.6.7	Connecting the Cable for the Status Report of the Insulation Monitoring	34
5.6.8	Connecting the Cable for the Supply Voltage	34
5.6.9	Connecting the Cable for the Status Report of the AC Contactor Monitoring	35
5.6.10	Connecting the Data Cable of the Sunny String-Monitor	35
5.6.11	Connecting the Transformer Protection	36
6	Disconnecting and Reconnecting	37
6.1	Safety When Disconnecting and Reconnecting Voltage Sources	37
6.2	Disconnecting the Inverter	37
6.2.1	Switching off the Inverter	37
6.2.2	Disconnecting the DC Side	37
6.2.3	Disconnecting the AC Side	38
6.2.4	Disconnecting the Supply Voltage at the Inverter from Voltage Sources	38
6.3	Reconnecting the Inverter	39
6.3.1	Reconnecting the Supply Voltage at the Inverter	39
6.3.2	Reconnecting the AC Side	39
6.3.3	Reconnecting the DC Side	40
6.3.4	Restarting the Inverter	40
7	Periodic Actions	41
7.1	Insert the cable into the inverter	41
7.2	Mounting and Disassembly Work	41
7.2.1	Disassembling and Mounting the Panels	41
7.2.2	Disassembling and Mounting the Protective Covers	42
7.2.3	Disassembling and Mounting the Ventilation Grids	43
7.3	Bolted Connections	45
7.3.1	Preparing the Grounding and DC Cables for Connection	45
7.3.2	Preparing the AC Connection	49
7.4	Clamp Connections	50
7.4.1	Connecting the Cable to the Spring-Cage Terminals	50
7.4.2	Connecting the Cable Shield Using a Shield Clamping Saddle	51
8	Technical Data	53
8.1	Sunny Central 500CP-JP	53
8.2	Sunny Central 630CP-JP	55
8.3	Sunny Central 800CP-JP	57
8.4	Sunny Central 1000CP-JP	59
9	Appendix	62
9.1	Information for Installation	62
9.1.1	Requirements for the Mounting Location	62
9.1.2	Requirements for the Support Surface	63
9.1.3	Requirements for the Foundation and Cable Routing	63
9.1.4	Requirements for Cable Routing between MV Transformer and Inverter	64
9.1.5	Dimensions of the Inverter	66
9.1.6	Minimum Clearances	68
9.1.6.1	Minimum Clearances for Outdoor Installation	68
9.1.6.2	Minimum Clearances in Electrical Equipment Rooms	71
9.1.7	Grounding Concept	72
9.2	Storage	73
9.3	Installation Information	73
9.3.1	Torques	73
9.3.2	Reduction of DC Input Currents for DC Fuses	74
9.4	Type Label	74

9.5 Scope of Delivery 74

9.6 Schematic Diagram 76

10 Contact 77

1 Information on this Document

1.1 Validity

This document is valid for the following device types:

Device type	Production version	OCU firmware version	DSP firmware version
SC 500CP-10-JP (Sunny Central 500CP-JP)	B1	02.00.01.R	02.00.01.R
SC 630CP-10-JP (Sunny Central 630CP-JP)	B1	02.00.01.R	02.00.01.R
SC 800CP-10-JP (Sunny Central 800CP-JP)	B1	02.00.01.R	02.00.01.R
SC 1000CP-10-JP (Sunny Central 1000CP-JP)	B1	02.00.01.R	02.00.01.R

The production version is indicated on the type label.

The firmware version can be read off from the user interface.

Illustrations in this document are reduced to the essential and may deviate from the real product.

1.2 Target Group

The tasks described in this document must only be performed by qualified persons. Qualified persons must have the following skills:

- Knowledge of how the product works and is operated
- Training in how to deal with the dangers and risks associated with installing and using electrical devices and systems
- Training in the installation and commissioning of electrical devices and systems
- Knowledge of all applicable standards and directives
- Knowledge of and adherence to this manual and all safety precautions

1.3 Additional Information

Links to additional information can be found at www.SMA-Solar.com.

1.4 Levels of warning messages

The following levels of warning messages may occur when handling the product.

DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.





CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates a situation which, if not avoided, can result in property damage.

1.5 Symbols in the Document

Symbol	Explanation
	Information that is important for a specific topic or goal, but is not safety-relevant
	Indicates a requirement for meeting a specific goal
	Desired result
	A problem that might occur

1.6 Typographies

Typographies	Use	Example
bold	<ul style="list-style-type: none"> • Display messages • Elements on a user interface • Terminals • Slots • Elements to be selected • Elements to be entered 	<ul style="list-style-type: none"> • Set parameter WGra to 0.2.
>	<ul style="list-style-type: none"> • Connects several elements to be selected 	<ul style="list-style-type: none"> • Select PV system > Detect.
[Button/Key]	<ul style="list-style-type: none"> • Button or key to be selected or pressed 	<ul style="list-style-type: none"> • Select [Start detection].

1.7 Designations in the Document

Complete designation	Designation in this document
Sunny Central	Inverter
Sunny Central Communication Controller	SC-COM or communication unit

2 Safety

2.1 Intended Use

The Sunny Central is a PV inverter which converts the direct current generated in the PV modules into grid-compliant alternating current. An external MV transformer fitted downstream feeds the generated alternating current into the utility grid.

The product is suitable for indoor and outdoor use.

The enclosure complies with degree of protection IP54. The inverter is classified under Class 4C2 as per EN 60721-3-4 and is suitable for operation in a chemically active environment.

The maximum permissible DC input voltage of the inverter must not be exceeded.

The inverter must only be operated in conjunction with a suitable MV transformer. The MV transformer must be designed for voltages that arise during pulsed mode of the inverter. The maximum AC voltages to ground are as follows:

- For the Sunny Central 500CP-JP, the maximum voltage to ground is: ± 800 V.
- For the Sunny Central 630CP-JP, the maximum voltage to ground is: ± 1450 V.
- For the Sunny Central 800CP-JP, the maximum voltage to ground is: ± 1450 V.
- For the Sunny Central 1000CP-JP, the maximum voltage to ground is: ± 1600 V.

Do not switch off or adjust settings that affect grid management services without first obtaining approval from the grid operator.

Use this product only in accordance with the information provided in the enclosed documentation and with the locally applicable standards and directives. Any other application may cause personal injury or property damage.

Alterations to the product, e.g. changes or modifications, are only permitted with the express written permission of SMA Solar Technology AG. Unauthorized alterations will void guarantee and warranty claims and in most cases terminate the operating license. SMA Solar Technology AG shall not be held liable for any damage caused by such changes.

Any use of the product other than that described in the Intended Use section does not qualify as the intended use.

The enclosed documentation is an integral part of this product. Keep the documentation in a convenient place for future reference and observe all instructions contained therein.

All work on the product must only be performed using appropriate tools and in compliance with the ESD protection regulations.

Suitable personal protective equipment has to be worn by all persons working on or with the product.

Unauthorized persons must not operate the product and must be kept at a safe distance from the product.

The product must not be operated with open covers or doors.

The product must not be opened when it is raining or when humidity exceeds 95%.

The product must not be operated with any technical defects.

The type label must remain permanently attached to the product.

2.2 Safety Information

This section contains safety information that must be observed at all times when working on or with the product. To prevent personal injury and property damage and to ensure long-term operation of the product, read this section carefully and observe all safety information at all times.

DANGER

Danger to life from electric shock due to live voltage

High voltages are present in the live components of the product. Touching live components results in death or serious injury due to electric shock.

- Wear suitable personal protective equipment for all work on the product.
- Do not touch any live components.
- Observe all warning messages on the product and in the documentation.
- Observe all safety information of the module manufacturer.
- After switching off the inverter, wait at least 15 minutes before opening it to allow the capacitors to discharge completely (see Section 6.2, page 37).

DANGER

Danger to life due to electric shock when live components or DC cables are touched

When exposed to sunlight, the PV modules generate high DC voltage which is present in the DC cables. Touching live DC cables results in death or lethal injuries due to electric shock.

- Do not touch non-insulated parts or cables.

DANGER

Danger to life due to electric shock in case of a ground fault

If there is a ground fault, components that are supposedly grounded may in fact be live. Touching live parts will result in death or serious injury due to electric shock.

DANGER

Danger to life from electric shock due to damaged product

Operating a damaged product can lead to hazardous situations that result in death or serious injuries due to electric shock.

- Only operate the product when it is in a flawless technical condition and safe to operate.
- Check the product regularly for visible damage.
- Make sure that all external safety equipment is freely accessible at all times.
- Make sure that all safety equipment is in good working order.
- Wear suitable personal protective equipment for all work on the product.

⚠ DANGER**Danger to life from electric shock even if the inverter is disconnected on the AC and DC sides**

The precharge unit of the order option "Q at Night" will carry live voltage even if the AC contactor and the DC switchgear are open. Touching live components results in death or serious injury due to electric shock.

- Do not touch any live components.
- Switch off the inverter.
- After switching off the inverter, wait at least 15 minutes before opening it to allow the capacitors to discharge completely.
- Ensure that no voltage is present.
- Do not remove protective covers.
- Observe the warning messages.
- Wear suitable personal protective equipment for all work on the product.

⚠ WARNING**Danger to life from electric shock when entering the PV field**

Ground-fault monitoring does not provide protection from personal injury. PV modules which are grounded with ground-fault monitoring discharge voltage to ground. Entering the PV field can result in lethal electric shocks.

- Ensure that the insulation resistance of the PV field exceeds the minimum value. The minimum value of the insulation resistance is: 1 kΩ.
- Before entering the PV field, switch the PV modules to insulated operation.
- Configure the PV power plant as a closed electrical operating area.

⚠ WARNING**Danger to life due to electric arc if there are tools inside the product**

When reconnecting or during operation, an electric arc can occur if there are tools in the product creating a conductive connection between the live components. This can result in death or serious injury.

- Before commissioning or reconnection, verify that no tools are inside the product.

⚠ WARNING**Danger to life from electric shock if the product is not locked**

If the product is not locked, unauthorized persons will have access to live components carrying lethal voltages. Touching live components can result in death or serious injury due to electric shock.

- Always close and lock the product.
- Remove the keys.
- Store the keys in a safe place.
- Ensure that no unauthorized persons have access to the closed electrical operating area.

⚠ WARNING**Danger to life due to blocked escape routes**

In hazardous situations, blocked escape routes can lead to death or serious injury. Opening the doors of two products located opposite each other can block the escape route. It is imperative that the escape route is freely accessible at all times.

- An escape route must be available at all times. Make sure the minimum passage width of the escape route meets local standards.
- Do not place any objects in the escape route area.
- Remove all tripping hazards from escape routes.

⚠ CAUTION**Risk of burns due to hot components**

Some components of the product can get very hot during operation. Touching these components can cause burns.

- Observe the warnings on all components.
- During operation, do not touch any components marked with such warnings.
- After switching off the product, wait until any hot components have cooled down sufficiently.
- Wear suitable personal protective equipment for all work on the product.

NOTICE**Property damage due to dust intrusion and moisture penetration**

Dust or moisture intrusion can damage the product and impair its functionality.

- Do not open the enclosure during rainfall or when humidity exceeds the specified thresholds. The humidity thresholds are: 15% to 95%.
- Only perform maintenance work when the environment is dry and free of dust.
- Operation of the product is only permitted when it is closed.
- Connect the external supply voltage after mounting and installing the product.
- If the installation or commissioning process is interrupted, mount all panels.
- Close and lock the enclosure.
- The product must always be closed for storage.
- Store the product in a dry and covered location.
- The temperature at the storage location must be in the specified range. The temperature range is: -25°C to $+70^{\circ}\text{C}$.

NOTICE**Damage to electronic components due to electrostatic discharge**

Electrostatic discharge can damage or destroy electronic components.

- Observe the ESD safety regulations when working on the product.
- Wear suitable personal protective equipment for all work on the product.
- Discharge electrostatic charge by touching grounded enclosure parts or other grounded elements. Only then is it safe to touch electronic components.

2.3 Personal Protective Equipment

i Always wear suitable protective equipment

When working on the product, always wear the appropriate personal protective equipment for the specific job.

The following personal protective equipment is regarded to be the minimum requirement:

- ☐ In a dry environment, safety shoes of category S3 with perforation-proof soles and steel toe caps
- ☐ During precipitation or on moist ground, safety boots of category S5 with perforation-proof soles and steel toe caps
- ☐ Tight-fitting work clothes made of 100% cotton
- ☐ Suitable work pants
- ☐ Individually fitted hearing protection
- ☐ Safety gloves

Any other prescribed protective equipment must also be used.

3 Product Overview

3.1 Design of the Inverter




Figure 1: Design of the Inverter

Position	Designation
A	Inverter cabinet
B	Interface cabinet
C	Connection area

3.2 Devices of the Inverter












Figure 2: Inverter Components

Position	Component	Description
A	Touch Display	Different kinds of inverter data can be viewed on the touch display. The touch display is only used to view data. The display screen is activated by touching the touch display.
B	Service interface	The service interface allows access to the user interface.
C	Key switch	The key switch is used to switch the inverter on and off.
D	DC switchgear	The DC switchgear disconnects the inverter from the PV array.

Position	Component	Description
E	SC-COM	The SC-COM is the communication unit of the inverter. The SC-COM establishes the connection between the inverter and the system operator.
F	AC disconnection unit	With the AC disconnection unit, the electrical connection between the inverter and MV transformer can be disconnected manually. In the event of residual current, the AC disconnection unit disconnects the connection between the inverter and MV transformer automatically.
G	AC contactor	The AC contactor disconnects the electrical connection between the inverter and MV transformer automatically.

3.3 Symbols on the Product

The following gives an explanation of all the symbols found on the inverter and on the type label.

Symbol	Designation	Explanation
	CE marking	The product complies with the requirements of the applicable EU directives.
	Protection class I	All electrical equipment is connected to the grounding conductor system of the product.
	Degree of protection IP54	The product is protected against interior dust deposits and splashing water from all angles.
	Beware of a danger zone	This warning symbol indicates a danger zone. Be particularly vigilant and cautious when working on the product.
	Beware of dangerous voltage	The product operates at high voltages. All work on the product must be carried out by qualified persons only.
	Beware of hot surface	The product can get hot during operation. Avoid contact during operation. Allow the product to cool down sufficiently before carrying out any work. Wear personal protective equipment such as safety gloves.
	Use hearing protection.	The product generates loud noises. When working on the product, wear hearing protection.
	Observe the documentation.	Observe all documentation supplied with the product.

4 Transport and Mounting

4.1 Safety during Transport and Mounting

⚠ WARNING

Danger of crushing if raised or suspended loads tip over, fall or sway

Vibrations or careless or hasty lifting and transportation may cause the product to tip over or fall. This can result in death or serious injury.

- All national standards and provisions for transport must be respected.
- Always transport the product as close to the floor as possible.
- Use all suspension points for transportation.
- Avoid fast or jerky movements during transport.
- Always maintain a sufficient safety distance from the product during transport.
- All means of transport and auxiliary equipment used must be designed for the weight of the product. Weight: 1800 kg.
- Wear suitable personal protective equipment for all work on the product.
- Disassemble the kick plates when transporting the inverter with a forklift, pallet truck or crane fork. Thus, the contact surface of the product on the forks is sufficiently extended (see Section 7.2.1, page 41).

NOTICE

Damage to the frame construction of the inverter due to uneven support surface

Placing the inverter on uneven surfaces can cause buckling so that the inverter doors will no longer close properly. This may lead to moisture and dust penetration into the inverter.

- Never place the inverter on an unstable, uneven surface even for a short period of time.
- The unevenness of the support surface must be less than 0.25%.
- The support surface must be suitable to take the weight of the inverter. Weight: 1800 kg.
- Do not transport the inverter with mounted kick plates.

4.2 Requirements for Transport and Mounting

4.2.1 Requirements and Ambient Conditions

- ☐ The requirements for the mounting location must be met (see Section 9.1.1, page 62).
- ☐ The requirements for the support surface must be met (see Section 9.1.2, page 63).
- ☐ The requirements for the foundation and cable arrangement must be met (see Section 9.1.3, page 63).
- ☐ Minimum clearances must be observed (see Section 9.1.6, page 68).

4.2.2 Center of Gravity Marker on the Inverter

The center of gravity of the inverter is not in the middle of the device. Take this into account during transport. The center of gravity of the inverter is marked on the packaging and on the enclosure with the center of gravity symbol.



Figure 3: Center of gravity symbol

4.2.3 Preparation for Mounting

4.2.3.1 Drilling Mounting Holes in the Foundation

The inverter must be attached to the support surface by means of six bolts. Mounting holes for attaching the inverter to the foundation or the base are located in the inverter floor.




Figure 4: Position of the mounting holes

Position	Designation
A	Mounting holes for mounting on a base or mounting surface
B	Mounting holes for mounting on a base
C	Mounting holes for mounting on a mounting surface

Additionally required material (not included in the scope of delivery):

- ☐ Six suitable concrete screw anchors

Procedure:

1. Mark the positions of the drill holes on the mounting surface.
2. Drill mounting holes at the marked positions.
3. Push the concrete dowels into the drill holes.

4.2.3.2 Preparation for Mounting on a Base

Requirement:

- ☐ The base must level off above the ground level. The base height above ground level is approx.: 150 mm.

Procedure:


1. Insert all cables through the openings into the base. Make sure that the data cables are routed separately from the power cables.

2. Seal the opening, e.g. with expanding foam. This will prevent living creatures from getting into the inverter.
3. Fill up the excavation pit and level off to ground level.


4.3 Transporting the Inverter

4.3.1 Transporting the Inverter Using a Pallet Truck

1. If the inverter is to be transported on a wooden pallet, push the pallet truck under the inverter from the front or the back.



2. If the inverter is to be transported without wooden pallet, disassemble the kick plates (see Section 7.2.1, page 41). Move the pallet truck under the inverter from the side only. Make sure the side panels of the inverter are not damaged by the forks.




3. Slightly raise the inverter.
4. Transport the inverter to the mounting location and set it down on a suitable surface.


4.3.2 Transporting the Inverter Using a Forklift or a Crane Fork

1. Disassemble the panels (see Section 7.2.1, page 41).

2. If a crane fork is used, move the forks of the crane fork under the inverter from the front or the back. Take the center of gravity of the inverter into account and move the crane fork completely under the inverter.



3. If a forklift is used, move the forks of the forklift under the inverter from the front or the back. Take the center of gravity of the inverter into account and move the forklift completely under the inverter.



4. Secure the inverter, e.g., with harness, to prevent it from tipping over.
5. Slightly raise the inverter.
6. Transport the inverter to the mounting location and set it down on a suitable surface.

4.3.3 Transporting the Inverter Using a Crane

In order to transport the inverter with a crane, the roof must be disassembled.

The shackles are not included in the scope of delivery of the inverter.

⚠ CAUTION

Danger of crushing due to heavy, unwieldy roof

The inverter roof is heavy and bulky. If you try to move the roof on your own, you run a risk of having limbs crushed. Weight of the roof: 30 kg.

- Wear suitable personal protective equipment for all work on the product.
- Always have two persons disassemble and mount the roof.

NOTICE





Property damage due to rupture of grounding conductors

The components are connected to the inverter via the grounding conductor. If the roof is not disassembled correctly, the grounding conductors may be pulled out.


- Take care not to damage the grounding conductors during disassembly.

Procedure:


1. Disassemble the ventilation grid (see Section 7.2.3, page 43).
2. Pull the front edge of the roof forward and push upward.
3. Gently push the roof to the rear. In doing so, you push the roof out of the guide rails.
4. Remove the grounding conductor from the inverter.
5. Remove the roof and set it down on a suitable surface.
6. Attach the hoist to all four lifting lugs- (hole diameter: 40 mm).
7. Raise the crane hook slowly until the hoist is taut.
8. Ensure that the hoist is attached correctly.
9. Slightly raise the inverter.
10. Transport the inverter as close to the floor as possible.
11. Transport the inverter to the mounting location and set it down on a suitable surface.
12. Place the roof on the inverter.
13. Screw the grounding conductor to the inverter (torque: 14.2 Nm).



14. Slide the roof into the guide rails on the inverter and pull forward.



15. Press the roof down.



16. Mount the ventilation grids (see Section 7.2.3, page 43).

4.4 Mounting of the Inverter

4.4.1 Mounting the Inverter on a Foundation

Requirements:

- ☐ The inverter must be off the Euro pallet and has to stand at the mounting location.
- ☐ The mounting holes must be drilled in the foundation and appropriate screw anchors inserted (see Section 4.2.3.1, page 16).

Additionally required material (not included in the scope of delivery):

- ☐ Six suitable screws to attach the inverter

Procedure:

- Attach the inverter to the mounting surface with the bolts.

4.4.2 Mounting the Inverter on a Base

Requirements:

- ☐ The inverter must be off the Euro pallet and has to stand at the mounting location.
- ☐ The base must be prepared for installation (see Section 4.2.3.2, page 16).

Additionally required material (not included in the scope of delivery):

- ☐ Six suitable hammer nuts to attach the inverter

Procedure:

- Attach the inverter with the screws (from the scope of delivery of the base) and hammer nuts to the base.

5 Installation

5.1 Safety during Installation

DANGER

Danger to life from electric shock due to live voltage

High voltages are present in the live components of the product. Touching live components results in death or serious injury due to electric shock.

- Wear suitable personal protective equipment for all work on the product.
- Do not touch any live components.
- Observe all warning messages on the product and in the documentation.
- Observe all safety information of the module manufacturer.
- After switching off the inverter, wait at least 15 minutes before opening it to allow the capacitors to discharge completely (see Section 6.2, page 37).

DANGER

Danger to life from electric shock due to live DC cables

DC cables connected to PV modules that are exposed to sunlight carry live voltage. Touching live cables results in death or serious injury due to electric shock.

- Prior to connecting the DC cables, ensure that the DC cables are voltage-free.
- Wear suitable personal protective equipment for all work on the device.

DANGER

Danger to life from electric shock due to ground fault

If a ground fault has occurred, parts of the PV power plant that are supposedly grounded may in fact be live. Touching incorrectly grounded parts of the PV power plant results in death or serious injuries from electric shock.

- Before working on the PV power plant, ensure that no ground fault is present.
- Wear suitable personal protective equipment for all work on the device.

WARNING

Danger to life from electric shock when entering the PV field

Ground-fault monitoring does not provide protection from personal injury. PV modules which are grounded with ground-fault monitoring discharge voltage to ground. Entering the PV field can result in lethal electric shocks.

- Ensure that the insulation resistance of the PV field exceeds the minimum value. The minimum value of the insulation resistance is: 1 k Ω .
- Before entering the PV field, switch the PV modules to insulated operation.
- Configure the PV power plant as a closed electrical operating area.

⚠ WARNING**Danger to life due to arc fault caused by damaged connection busbars**

If excessive force is exerted while connecting the cables, the connection busbars can be bent or damaged. This will lead to reduced clearances and creepage distances. Reduced clearances and creepage distances can lead to arc faults.

- Cut the cables to the correct length and prepare them for connection.
- Position the terminal lugs on the connection busbars ensuring a large contact surface.
- Tighten to the specified torque.

5.2 Preparing the Installation

5.2.1 Mounting the Silencing Baffle

With the order option "Noise reduction", a silencing baffle is delivered with the inverter. The silencing baffle must be mounted on the rear panel of the inverter cabinet. When mounting, use the allround paste from the scope of delivery for the bolted connections.

Mounting the rear panel of the silencing baffle

Required mounting material:

- ☐ 2 cylindrical screws
- ☐ 2 contact washers

Procedure:

1. Remove all screws from the threads for attaching the silencing baffle.
2. Position the rear panel of the silencing baffle on the rear panel of the inverter.
3. Screw two cylindrical screws with contact washers into the middle threads on the rear panel (torque: 8 Nm).

Mounting the cover of the silencing baffle

Required mounting material:

- ☐ 1 cylindrical screw
- ☐ 3 contact washers
- ☐ 9 pan head flange screws
- ☐ 13 washers
- ☐ 10 hexagon nuts

Procedure:

1. Align the lid on the rear panel. Place the cover over the stud bolts.
2. Insert a cylindrical screw with contact washer into the top left thread. Do not tighten the screw yet.
3. Screw five pan head flange screws into the upper threads on the cover. Do not tighten the screws yet.
4. Fasten the ventilation plate of the rear panel of the silencing baffle to the cover. Do not yet tighten the four pan head flange screws yet.
5. Screw two hexagon nuts with contact washers onto the bottom right and left stud bolts on the rear panel.
6. Screw all hexagon nuts and washers onto the remaining stud bolts of the rear panel.
7. Align the cover and tighten all screws and nuts (torque: 8 Nm).

Mounting the Rain Shield

Required mounting material:

- ☐ 2 cylindrical screws
- ☐ 2 contact washers
- ☐ 6 pan head flange screws

Procedure:

1. Position the rain shield on the silencing baffle.
2. Screw two cylindrical screws with contact washers into the bottom right and left threads on the cover and tighten them (torque: 8 Nm).
3. Screw six pan head flange screws into the threads and tighten them (torque: 8 Nm).

5.2.2 Replacing the Desiccant Bag in the Inverter

i Desiccant bag in the inverter cabinet

The desiccant bag in the inverter cabinet protects the electronic components from moisture. The desiccant bag must be replaced by a new desiccant bag included in the scope of delivery one day before commissioning.

Procedure:

1. Remove and dispose of the desiccant bag located under the inverter bridges.
2. Remove the desiccant bag included in the scope of delivery from the foil and position it under the inverter bridges.

5.2.3 Mounting the Ventilation Plate

The guide rails for the ventilation plate are located in the floor area of the inverter cabinet.

Procedure:

- Slide the ventilation plate into the guide rails in the inverter cabinet. The ventilation grid in the ventilation plate should be facing the rear panel.
 - ☒ The ventilation plate is flush with the inverter.
 - ☒ The ventilation plate will not go all the way in?
 - Grip the ventilation plate from underneath and press the middle part upwards while sliding it in.

5.3 Installing the Grounding




Figure 5: Position of grounding in the inverter (example)

Position	Designation
A	Grounding busbar
B	Cable support rail

Terminal lug requirements:

- ☐ Use tin-plated terminal lugs only.
- ☐ For the connection, only the supplied screws, washers and nuts must be used.
- ☐ The terminal lugs must be designed according to the temperature. Temperature: +95 °C
- ☐ The width of the terminal lugs must exceed the washer diameter. Washer diameter: 32 mm. This will ensure that the defined torques are effective over the whole surface.

Cable requirements:

- ☐ Do not attach more than one cable to each connection bracket.
- ☐ Use copper or aluminum cables only.
- ☐ Maximum cable cross-section: 400 mm².

Torques of the power connections:

Type of terminal lug	Torque
Tin-plated aluminum or copper terminal lug on aluminum bar	37 Nm

Additionally required mounting material (not included in the scope of delivery):

- ☐ Clean cloth
- ☐ Ethanol cleaning agent

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Disassemble the protective covers (see Section 7.2.2, page 42).
3. Prepare the cables for connection (see Section 7.3, page 45).
4. Clean the non-tin-plated contact surfaces in the connection area with the non-woven abrasive until they have a light metallic sheen.
5. Clean all contact surfaces in the connection area using a clean cloth and ethanol cleaning agent and do not touch the contact surfaces after cleaning.
6. Connect the cables in accordance with the circuit diagram. Only use the screws, nuts and washers included in the scope of delivery and make sure that the screw heads always point forwards.
7. Secure the cables on the cable support rail. This will prevent the cable from being pulled out inadvertently.
8. Mount the protective covers (see Section 7.2.2, page 42).
9. Mount the panels (see Section 7.2.1, page 41).

5.4 Installing the DC Connection

5.4.1 Connecting the DC Cable to the Busbar

Position	Designation
A	Connection area DC+
B	Connection area DC-
C	DC connection bracket with dimensions

Terminal lug requirements:

- ☐ Use tin-plated terminal lugs only.
- ☐ For the connection, only the supplied screws, washers and nuts must be used.

- ☐ The terminal lugs must be designed according to the temperature. Temperature: +95 °C
- ☐ The width of the terminal lugs must exceed the washer diameter. Washer diameter: 32 mm. This will ensure that the defined torques are effective over the whole surface.

Cable requirements:

- ☐ The DC cables must be designed for the maximum PV voltage and must have double or reinforced insulation.
- ☐ No more than two cables must be connected to each DC terminal.
- ☐ Use copper or aluminum cables only.
- ☐ Maximum cable cross-section: 400 mm².
- ☐ Terminal lugs: M12

Torques of the power connections:

Type of terminal lug	Torque
Tin-plated aluminum terminal lug on copper bar	37 Nm
Tin-plated copper terminal lug on copper bar	60 Nm

Additionally required mounting material (not included in the scope of delivery):

- ☐ Clean cloth
- ☐ Ethanol cleaning agent

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Disassemble the protective covers (see Section 7.2.2, page 42).
3. Prepare the cables for connection (see Section 7.3, page 45).
4. Clean the non-tin-plated contact surfaces in the connection area with the non-woven abrasive until they have a light metallic sheen.
5. Clean all contact surfaces in the connection area using a clean cloth and ethanol cleaning agent and do not touch the contact surfaces after cleaning.
6. Connect the cables in accordance with the circuit diagram. Only use the screws, nuts and washers included in the scope of delivery and make sure that the screw heads always point forwards.
7. Secure the cables on the cable support rail. This will prevent the cable from being pulled out inadvertently.
8. Mount the protective covers (see Section 7.2.2, page 42).
9. Mount the panels (see Section 7.2.1, page 41).

5.4.2 Connecting the DC Cables to the Connection Brackets




Figure 6: Connection area for DC fuses (example)

Position	Designation
A	Connection area DC-
B	Connection area DC+
C	DC connection bracket with dimensions

Terminal lug requirements:

- ☐ Use tin-plated terminal lugs only.
- ☐ For the connection, only the supplied screws, washers and nuts must be used.
- ☐ The terminal lugs must be designed according to the temperature. Temperature: +95 °C
- ☐ The width of the terminal lugs must exceed the washer diameter. The diameter of the washers for M12 screws is 32 mm. The diameter of the washers for M8 screws is 20 mm. This will ensure that the defined torques are effective over the whole surface.

Cable requirements:

- ☐ The DC cables must be designed for the maximum PV voltage and must have double or reinforced insulation.
- ☐ No more than two cables must be connected to each DC terminal.
- ☐ Use copper or aluminum cables only.
- ☐ Maximum cable cross-section: 400 mm².
- ☐ Terminal lugs: M12 or M8

Torques of the power connections:

Type of terminal lug	Torque
Tin-plated aluminum or copper terminal lug on aluminum bar	37 Nm for M12 10 Nm for M8

Additionally required mounting material (not included in the scope of delivery):

- ☐ Clean cloth
- ☐ Ethanol cleaning agent

Requirement:

- ☐ The reduction of DC input currents must be complied with (see Section 9.3.2, page 74).

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Disassemble the protective covers (see Section 7.2.2, page 42).
3. Prepare the cables for connection (see Section 7.3, page 45).
4. Clean the non-tin-plated contact surfaces in the connection area with the non-woven abrasive until they have a light metallic sheen.
5. Clean all contact surfaces in the connection area using a clean cloth and ethanol cleaning agent and do not touch the contact surfaces after cleaning.
6. Connect the cables in accordance with the circuit diagram. Only use the screws, nuts and washers included in the scope of delivery and make sure that the screw heads always point forwards.
7. Secure the cables on the cable support rail. This will prevent the cable from being pulled out inadvertently.
8. Mount the protective covers (see Section 7.2.2, page 42).
9. Mount the panels (see Section 7.2.1, page 41).

5.5 Installing the AC Connection




Figure 7: Dimensions of the AC connection

Cable and cable laying requirements:

- ☐ The cables must be designed for the maximum voltages to ground.

Inverter	Maximum voltage to ground
Sunny Central 500CP-JP	±800 V
Sunny Central 630CP-JP	±1450 V

Inverter	Maximum voltage to ground
Sunny Central 800CP-JP	± 1450 V
Sunny Central 1000CP-JP	± 1600 V

- ☐ The cables must be designed for the maximum root-mean-square value:

Inverter	Maximum root-mean-square value
Sunny Central 500CP-JP	390 V
Sunny Central 630CP-JP	800 V
Sunny Central 800CP-JP	800 V
Sunny Central 1000CP-JP	800 V

- ☐ Do not attach more than four cables to each AC connecting plate.
- ☐ Use copper or aluminum cables only.
- ☐ Maximum cable cross-section: 325 mm².
- ☐ All line conductor cables must be of the same length and must not exceed the maximum cable length. The maximum cable length is 15 m.
- ☐ The AC cables must be bundled in the three-phase system.
- ☐ Between the MV transformer and the inverter, three separate cable routes for the AC cables must be available, e.g. cable channels.
- ☐ A line conductor L1, L2 or L3 must be laid in each cable channel. Ensure that the distance between the cable bundles is at least twice the diameter of a cable. This will prevent current imbalances. Furthermore, it is recommended to execute cabling between inverter and MV transformer directly on a grounding strap. This measure further reduces electromagnetic influences.




Figure 8: Arrangement of AC cables with three cables per line conductor (example)

Position	Designation
L1	Line conductor L1
L2	Line conductor L2
L3	Line conductor L3
A	Grounding strap

Torques of the power connections:

Type of terminal lug	Torque
Tin-plated aluminum terminal lug on copper bar	37 Nm
Tin-plated copper terminal lug on copper bar	60 Nm

Additionally required mounting material (not included in the scope of delivery):

- ☐ Clean cloth
- ☐ Ethanol cleaning agent

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Disassemble the protective covers (see Section 7.2.2, page 42).
3. Prepare the cables for connection (see Section 7.3, page 45).
4. Clean the non-tin-plated contact surfaces in the connection area with the non-woven abrasive until they have a light metallic sheen.
5. Clean all contact surfaces in the connection area using a clean cloth and ethanol cleaning agent and do not touch the contact surfaces after cleaning.
6. Connect the cables in accordance with the circuit diagram. Only use the screws, nuts and washers included in the scope of delivery and make sure that the screw heads always point forwards.
7. Secure the cables on the cable support rail. This will prevent the cable from being pulled out inadvertently.
8. Mount the protective covers (see Section 7.2.2, page 42).
9. Mount the panels (see Section 7.2.1, page 41).

5.6 Cables for Communication, Control, Supply Voltage and Monitoring

5.6.1 Connecting Optical Fibers with Subscriber Connector




Figure 9: Position of the splice box

Position	Designation
A	Splice box

Additionally required mounting material (not included in the scope of delivery):

- ☐ 2 subscriber connectors


NOTICE**Damage to optical fibers due to too tight bend radii**

Excessive bending or kinking will damage the optical fibers.


- Observe the minimum permissible bend radii of the optical fibers.

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the optical fibers in the inverter (see Section 7.1, page 41).
3. Remove the splice box from the top-hat rail:
4. Open the enclosure of the splice box.
5. Insert the optical fibers from below through the cable gland into the splice box.



6. Mount the subscriber connectors on the optical fibers.
7. Plug the subscriber connectors into the SC-P plugs in the splice box.
8. Coil the residual glass fiber in the fiber reservoir. Observe the permissible bend radii.



9. Screw on the enclosure of the splice box.
10. Reinstall the splice box on the top-hat rail.

11. Attach the optical fibers to the cable support rail using a cable tie. This ensures that the optical fibers cannot be pulled out inadvertently.
12. Mount the panels (see Section 7.2.1, page 41).

5.6.2 Connecting Optical Fibers via Optical Fiber Pigtail




Figure 10: Position of the splice box

Position	Designation
A	Splice box

Optical fiber requirements:

- ☐ The optical fiber cables must be equipped with a 50 µm multi-mode optical fiber.
- ☐ The optical fibers must be fitted with a subscriber connector.

NOTICE

Damage to optical fibers due to too tight bend radii


Excessive bending or kinking will damage the optical fibers.

- Observe the minimum permissible bend radii of the optical fibers.


Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the optical fibers in the inverter (see Section 7.1, page 41).
3. Remove the splice box from the top-hat rail:
4. Open the enclosure of the splice box.

5. Insert the optical fibers from below through the cable gland into the splice box.



6. Splice the optical fibers with the optical fiber pigtails in the splice box.
7. Plug the subscriber connectors into the SC-P plugs in the splice box.
8. Coil the residual glass fiber in the fiber reservoir. Observe the permissible bend radii.



9. Screw on the enclosure of the splice box.
10. Reinstall the splice box on the top-hat rail.
11. Attach the optical fibers to the cable support rail using a cable tie. This ensures that the optical fibers cannot be pulled out inadvertently.
12. Mount the panels (see Section 7.2.1, page 41).

5.6.3 Connecting the Network Cables

Network cable requirements:

- ☐ The network cables must be shielded and pair-twisted.
- ☐ The network cables must be of at least category 5 (CAT 5).
- ☐ Maximum cable length: 100 m

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the network cables (see Section 7.1, page 41).
3. Insert the network cables into the network ports.

4. Attach the network cables to the cable support rail using a cable tie. This will prevent the network cables from being pulled out inadvertently.
5. Mount the panels (see Section 7.2.1, page 41).

5.6.4 Connecting Cables for Analog Setpoints

If the setpoints for active power limitation and reactive power control are not transmitted via the network, there are terminals in the inverter for connecting external setpoints. The inverter processes standard analog signals from 4.0 mA to 20.0 mA.

Cable requirement:

- ☐ The cable used must be shielded.

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the cables (see Section 7.1, page 41).
3. Connect the cables in accordance with the circuit diagram (see Section 7.4, page 50).
4. Secure the cables on the cable support rail. This will prevent the cables from being pulled out inadvertently.
5. Mount the panels (see Section 7.2.1, page 41).

5.6.5 Connecting the Cable for the External Fast Stop

If required, you can connect an external fast stop in accordance with the circuit diagram. The fast stop can be operated by means of an internal or external supply voltage.

i Shortfall of external supply voltage

If there is an external supply voltage between 18.5 V to 24.0 V, the inverter will continue to operate in its current operating state. If the external supply voltage falls below 18.5 V, the inverter switches from the current operating state to the operating state "Stop". If the temperature inside the inverter exceeds the temperature limit, a supply voltage of 20.0 V to 24.0 V must be present to continue operating the inverter in its current operating state.

Temperature limit: +60°C

- Ensure that the external supply voltage is between 20.0 V and 24.0 V.

Cable requirement:

- ☐ The cable used must be shielded.

Additional cable requirements for internal supply voltage:

- ☐ Maximum cable length with cable cross-section: 130 m / 2.5 mm²
- ☐ Maximum cable length with cable cross-section: 80 m / 1.5 mm²

Requirements:

- ☐ A switch must be used that can interrupt the supply voltage.

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the cables (see Section 7.1, page 41).
3. Connect the cables in accordance with the circuit diagram (see Section 7.4, page 50).
4. Secure the cables on the cable support rail. This will prevent the cables from being pulled out inadvertently.
5. Mount the panels (see Section 7.2.1, page 41).

5.6.6 Connecting the Cable for Remote Shutdown

The remote shutdown enables the inverter to be switched off from a distance, e.g. from a control room. The function of the remote shutdown is similar to the stop function of the key switch.

i Shortfall of external supply voltage

If there is an external supply voltage between 18.5 V to 24.0 V, the inverter will continue to operate in its current operating state. If the external supply voltage falls below 18.5 V, the inverter switches from the current operating state to the operating state "Stop". If the temperature inside the inverter exceeds the temperature limit, a supply voltage of 20.0 V to 24.0 V must be present to continue operating the inverter in its current operating state.
Temperature limit: +60°C

- Ensure that the external supply voltage is between 20.0 V and 24.0 V.

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the cables (see Section 7.1, page 41).
3. Connect the cables in accordance with the circuit diagram (see Section 7.4, page 50).
4. Secure the cables on the cable support rail. This will prevent the cables from being pulled out inadvertently.
5. Mount the panels (see Section 7.2.1, page 41).

5.6.7 Connecting the Cable for the Status Report of the Insulation Monitoring

i Status report

The switching status can be queried via a contact. For details of terminal assignment, see circuit diagram.

Requirements:

- ☐ The connected load must operate with a voltage of 230 V_{AC} or 24 V_{DC}.
- ☐ The connected load must draw a current of 10 mA to 6 A.

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the cables (see Section 7.1, page 41).
3. Connect the cables in accordance with the circuit diagram (see Section 7.4, page 50).
4. Secure the cables on the cable support rail. This will prevent the cables from being pulled out inadvertently.
5. Mount the panels (see Section 7.2.1, page 41).

5.6.8 Connecting the Cable for the Supply Voltage

The inverter must be connected to an external, three-phase supply voltage with 230 V line voltage/400 V line-to-line voltage (3/N/PE) per line conductor.

i Circuit breaker between the external supply voltage and the inverter

A type-B circuit breaker with a rated current of 16 A is installed in the inverter.

- Provide a selective circuit breaker for insulating the cable to the inverter.

Cable requirements:

- ☐ The cable used must be shielded.
- ☐ Maximum conductor cross-section: 10 mm²

NOTICE**Failure of the inverter due to incorrect connection of the internal power supply**

If the internal power supply is not properly connected, the residual-current device in the inverter may trip and put the inverter is no longer ready for operation. This can result in financial damage due to yield loss.

- Connect the neutral conductor N.
- Ground the neutral point of the internal power supply transformer.

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the cables (see Section 7.1, page 41).
3. Connect the cables in accordance with the circuit diagram (see Section 7.4, page 50).
4. Secure the cables on the cable support rail. This will prevent the cables from being pulled out inadvertently.
5. Mount the panels (see Section 7.2.1, page 41).

5.6.9 Connecting the Cable for the Status Report of the AC Contactor Monitoring**i Status report**

The switching status can be queried via a contact. For details of terminal assignment, see circuit diagram.

Requirements:

- ☐ The connected load must operate with a voltage of 230 V_{AC} or 24 V_{DC}.
- ☐ The connected load must draw a current of 10 mA to 6 A.

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the cables (see Section 7.1, page 41).
3. Connect the cables in accordance with the circuit diagram (see Section 7.4, page 50).
4. Secure the cables on the cable support rail. This will prevent the cables from being pulled out inadvertently.
5. Mount the panels (see Section 7.2.1, page 41).

5.6.10 Connecting the Data Cable of the Sunny String-Monitor

For an optimum supply voltage, it is recommended to connect two insulated conductors each in the terminals of the supply voltage and of the grounding.

Cable requirements:

- ☐ The supply voltage and the communication connection must be combined in one cable.
- ☐ The cable used must be shielded.
- ☐ Recommended cable type: Li2YCYv (TP) 4 x 2 x 0.5 mm².

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the cables (see Section 7.1, page 41).
3. Connect the cables in accordance with the circuit diagram (see Section 7.4, page 50).
4. Secure the cables on the cable support rail. This will prevent the cables from being pulled out inadvertently.
5. Mount the panels (see Section 7.2.1, page 41).

5.6.11 Connecting the Transformer Protection

The inverter is equipped with a terminal for monitoring the MV transformer. Under fault conditions, the inverter is immediately switched off. To use the transformer monitoring, an external supply voltage of 230 V_{AC} must be provided in the MV transformer.

Cable requirement:

- ☐ The cable used must be shielded.

Procedure:

1. Disassemble the panels (see Section 7.2.1, page 41).
2. Insert the cables (see Section 7.1, page 41).
3. Connect the cables in accordance with the circuit diagram (see Section 7.4, page 50).
4. Secure the cables on the cable support rail. This will prevent the cables from being pulled out inadvertently.
5. Mount the panels (see Section 7.2.1, page 41).

6 Disconnecting and Reconnecting

6.1 Safety When Disconnecting and Reconnecting Voltage Sources

DANGER

Danger to life from electric shock due to live voltage

High voltages are present in the live components of the product. Touching live components results in death or serious injury due to electric shock.

- Wear suitable personal protective equipment for all work on the product.
- Do not touch any live components.
- Observe all warning messages on the product and in the documentation.
- Observe all safety information of the module manufacturer.
- After switching off the inverter, wait at least 15 minutes before opening it to allow the capacitors to discharge completely (see Section 6.2, page 37).

DANGER

Danger to life due to electric shock in case of a ground fault

If there is a ground fault, components that are supposedly grounded may in fact be live. Touching live parts will result in death or serious injury due to electric shock.

CAUTION

Risk of burns due to hot components

Some components of the product can get very hot during operation. Touching these components can cause burns.

- Observe the warnings on all components.
- During operation, do not touch any components marked with such warnings.
- After switching off the product, wait until any hot components have cooled down sufficiently.
- Wear suitable personal protective equipment for all work on the product.

6.2 Disconnecting the Inverter

6.2.1 Switching off the Inverter


1. Turn the key switch to **Stop**.
2. Remove the key. This will protect the inverter from inadvertent reconnection.
3. Wait 15 minutes before opening the doors. This allows the inverter capacitors to discharge.

6.2.2 Disconnecting the DC Side

1. Switch off the inverter (see Section 6.2.1, page 37).
2. Disconnect all poles of the DC voltage in the DC main distribution or DC subdistribution (see documentation of the main or subdistribution).
3. Ensure that the DC switchgear in the inverter is open.
4. Ensure that no voltage is present on the load side of the DC switchgear.
5. Cover or isolate any adjacent live components.
6. Remove the protective covers over the fuses.
7. Remove all fuses and disconnection blades from all fuse holders of the inverters. Use an LV/HRC fuse extractor.

6.2.3 Disconnecting the AC Side

1. Switch off the inverter (see Section 6.2.1, page 37).
2. Disconnect the DC side (see Section 6.2.2, page 37).
3. Externally disconnect the AC voltage of the MV transformer.
4. Switch off the AC disconnection unit in the inverter.




5. Ensure that no voltage is present.
6. Cover or isolate any adjacent live components.

6.2.4 Disconnecting the Supply Voltage at the Inverter from Voltage Sources


1. If the supply voltage is only to be disconnected upstream from the circuit breaker, switch the circuit breaker of the supply voltage off.
2. If the supply voltage is also to be disconnected downstream from the supply voltage circuit breaker, switch the external circuit breaker of the supply voltage off.

Tip: The external circuit breaker of the supply voltage is usually located in a subordinate distribution station.

3. Disconnect any additional external voltage.
4. Switch off the circuit breaker of the grid monitoring.



5. Open the measurement and disconnect terminals.




6. Ensure that no voltage is present.
7. Cover or isolate any adjacent live components.


6.3 Reconnecting the Inverter

6.3.1 Reconnecting the Supply Voltage at the Inverter

1. Close the measurement and disconnect terminals.




2. Switch on the circuit breaker of the grid monitoring.



3. Connect any additional external voltage.
4. If the supply voltage has been disconnected downstream from the circuit breaker, switch the external circuit breaker of the supply voltage on.
Tip: The external circuit breaker of the supply voltage is usually located in a subordinate distribution station.
5. If the supply voltage has been disconnected upstream from the circuit breaker, switch the circuit breaker of the supply voltage on.

6.3.2 Reconnecting the AC Side

1. Reconnect the supply voltage and external voltages (see Section 6.3.1, page 39).
2. Reconnect the AC voltage of the MV transformer.
3. Switch on the AC disconnection unit in the inverter.



6.3.3 Reconnecting the DC Side

1. Insert all fuses and disconnection blades into all fuse holders of the inverter. Use an LV/HRC fuse extractor.
2. Screw on the protective covers over the fuses (torque: 5 Nm).
3. Switch on the DC voltage in the DC main distribution or DC subdistribution (see documentation of the main or subdistribution).


6.3.4 Restarting the Inverter

- Turn the key switch to **Start**.


7 Periodic Actions

7.1 Insert the cable into the inverter.

1. Remove the screws at the top of the sealing plate.



2. Remove the sealing plate.
3. Loosen the screws at the side of the sealing plate.



4. Remove the required number of rubber seals from the sealing plate. Make sure that the diameter of the rubber seals corresponds to the diameter of the cables to be inserted. Use the additional rubber seals included in the scope of delivery, if necessary.
5. Remove the sealing plugs from those rubber seals through which the cables are to be led.
6. Lead the cables through the rubber seals.
7. Insert the rubber seals in the sealing plate avoiding any distortion. This will ensure the tightness of the seal.
8. Tighten the screws at the side of the sealing plate.
9. Screw the sealing plate to the floor of the interface cabinet.

7.2 Mounting and Disassembly Work

7.2.1 Disassembling and Mounting the Panels

⚠ DANGER

Danger to life due to electric shock or electric arc if live components are touched

- Switch off the inverter and wait at least 15 minutes before opening it to allow the capacitors to discharge completely.
- Disconnect the inverter (see Section 6, page 37).

NOTICE


Property damage due to rupture of grounding conductors

The components are connected to the inverter via the grounding conductor. If the roof is not disassembled correctly, the grounding conductors may be pulled out.

- Take care not to damage the grounding conductors during disassembly.

Disassembling the panels

1. Remove the screws of the front panels using a Torx screwdriver (head size T30).
2. Detach the grounding straps from the panels.
3. Remove the panels.



Mounting the panels

Requirement:

- ☐ The protective covers in the connection area must be mounted (see Section 7.2.2, page 42).

Procedure:

1. Attach the grounding straps to the panels of the interface cabinet (torque: 8 Nm to 10 Nm).
2. Ensure that the grounding straps are firmly in place.
3. Attach the panels using a Torx screwdriver (torque: 2 Nm to 3 Nm, head size T30).

7.2.2 Disassembling and Mounting the Protective Covers




Figure 11: Position of the protective covers

Position	Designation
A	Protective cover

⚠ DANGER**Danger to life due to electric shock or electric arc if live components are touched**

- Switch off the inverter and wait at least 15 minutes before opening it to allow the capacitors to discharge completely.
- Disconnect the inverter (see Section 6, page 37).

Disassembling the protective covers**Requirements:**

- The panels must be disassembled (see Section 7.2.1, page 41).

Procedure:




- Disassemble the protective covers.

Mounting the protective covers


1. Tighten all protective covers (torque: 5 Nm).
2. Ensure that the protective covers are firmly in place.

7.2.3 Disassembling and Mounting the Ventilation Grids**Disassembling the ventilation grids**

1. Release the screws of the right-hand ventilation grid. (head size: T40).
2. Pull the lower side of the right-hand ventilation grid forwards to remove it.
3. Release the screws of the left-hand ventilation grid. (head size: T40).




4. Pull the lower side of the left-hand ventilation grid forwards to remove it.




Mounting the ventilation grids


1. Insert the left-hand ventilation grid.




2. Screw the left-hand ventilation grid on (torque: 20 Nm, head size T40).



3. Insert the right-hand ventilation grid.



4. Screw the right-hand ventilation grid on (torque: 20 Nm, head size T40).



7.3 Bolted Connections

7.3.1 Preparing the Grounding and DC Cables for Connection

Connection overview with one two-hole terminal lug for grounding and DC cables




Figure 12: Design of the connection with one two-hole terminal lug

Position	Designation
A	Nut M12
B	Spring washer (29 mm)
C	Fender washer (32 mm)
D	Connection busbar
E	Tin-plated two-hole terminal lug
F	Screw M12

Connection overview with one one-hole terminal lug for grounding and DC cables




Figure 13: Design of the connection with one one-hole terminal lug

Position	Designation
A	Nut M12 or M8
B	Spring washer (29 mm for M12 or 18 mm for M8)
C	Fender washer (32 mm for M12 or 20 mm for M8)
D	Connection busbar
E	Tin-plated one-hole terminal lug
F	Screw M12 or M8

Connection overview with two two-hole terminal lugs for DC cables




Figure 14: Design of the connection with two two-hole terminal lugs

Position	Designation
A	Nut M12
B	Spring washer (29 mm)
C	Fender washer (32 mm)
D	Tin-plated two-hole terminal lugs
E	Connection busbar
F	Screw M12

Connection overview with two one-hole terminal lugs for DC cables




Figure 15: Design of the connection with two one-hole terminal lugs

Position	Designation
A	Nut M12 or M8
B	Spring washer (29 mm for M12 or 18 mm for M8)
C	Fender washer (32 mm for M12 or 20 mm for M8)
D	Tin-plated one-hole terminal lugs
E	Connection busbar
F	Screw M12 or M8

Additionally required mounting material (not included in the scope of delivery):

- ☐ Clean cloth
- ☐ Ethanol cleaning agent

Procedure:

1. Strip the cable insulation.
2. Fit the cables with terminal lugs.
3. Clean the contact surfaces of the terminal lugs with a clean cloth and ethanol cleaning agent.

7.3.2 Preparing the AC Connection

Overview of the connection with one one-hole terminal lug




Figure 16: Design of the connection with one one-hole terminal lug

Position	Designation
A	Nut M12
B	Spring washer (29 mm)
C	Fender washer (32 mm)
D	Connection busbar
E	Tin-plated one-hole terminal lug
F	Screw M12

Connection overview with two one-hole terminal lugs




Figure 17: Design of the connection with two one-hole terminal lugs

Position	Designation
A	Nut M12
B	Spring washer (29 mm)
C	Fender washer (32 mm)
D	Tin-plated one-hole terminal lugs
E	Connection busbar
F	Screw M12

Additionally required mounting material (not included in the scope of delivery):

- ☐ Clean cloth
- ☐ Ethanol cleaning agent


Procedure:

1. Strip the cable insulation.
2. Fit the cables with terminal lugs.
3. Clean the contact surfaces of the terminal lugs with a clean cloth and ethanol cleaning agent.


7.4 Clamp Connections

7.4.1 Connecting the Cable to the Spring-Cage Terminals


1. Dismantle the cable.




2. Strip the insulation of the insulated conductors.
3. Connect the cable in accordance with the circuit diagram.
 - Remove the connection plug from the base terminal.



- Insert the screwdriver in the square opening of the connection plug. This will release the opening of the connection plug for the insulated conductors.




- Insert the insulated conductors of the cable into the connection plug in accordance with the circuit diagram.
- Remove the screwdriver from the connection plug.
- Plug the connection plug into the base terminal.



7.4.2 Connecting the Cable Shield Using a Shield Clamping Saddle

1. Remove the shield clamping saddle from the busbar.

2. Press the shield clamping saddle down onto the shield of the stripped cable until it snaps into place and fasten hand-tight.



8 Technical Data

8.1 Sunny Central 500CP-JP

DC Input	
Maximum DC power	511 kW
Maximum input voltage	600 V
MPP voltage range at 50 Hz	332 V to 600 V
MPP voltage range at 60 Hz	332 V to 600 V
DC voltage range at 50 Hz	311 V to 600 V
DC voltage range at 60 Hz	321 V to 600 V
DC rated input voltage	365 V
Maximum input current	1400 A
Maximum short-circuit current	2500 A
Maximum reverse current	2300 A
MPP voltage at 50 Hz*	311 V
MPP voltage at 60 Hz*	321 V
Number of independent MPP inputs	1
Number of DC inputs	9
* For $I_{MPP} < I_{DCmax}$	
AC Output	
Nominal AC power at +50 °C	455 kVA*
Rated power at +25 °C	500 kVA
Nominal AC voltage	205 V
Nominal AC voltage range	185 V to 235 V
AC power frequency	50 Hz / 60 Hz
AC power frequency range	47 Hz to 63 Hz
Rated frequency	50 Hz
Rated voltage	205 V
Maximum output current	1411 A
Maximum residual current at the AC output	3500 A
Maximum overcurrent protection at output	50000 A
Maximum total harmonic distortion	3 %
Power factor at rated power	1

AC Output

Displacement power factor $\cos \varphi$	0.9 overexcited to 0.9 underexcited
Feed-in phases	3
Connection phases	3
Inrush current of the internal power supply	48 A (100 ms)

* For order option "Noise reduction", the values change (see datasheet).

Efficiency*

Maximum efficiency	98.0%
European weighted efficiency	97.7%
CEC weighted efficiency	97.4%

* For order option "Noise reduction", the values change (see datasheet).

Protective Devices

DC overvoltage protection	Type I
Lightning protection as per IEC 62305-1	Lightning protection level III
Surge arrester for auxiliary power supply	Type I and type II
Protection class in accordance with IEC 62109-01	I
Overvoltage category in accordance with IEC 60664-1	III

General Data

Width x height x depth	2562 mm x 2272 mm x 956 mm*
Weight	1800 kg*
Operating temperature range	-25°C to +62°C
Noise emission at a distance of 10 m (without order option "Noise reduction")	61 db(A)
Noise emission at a distance of 10 m (with order option "Noise reduction")	53 db(A)
Maximum self-consumption in operation	1950 W
Standby consumption	< 100 W
External supply voltage	230 V/400 V (3/N/PE), 50 Hz/60 Hz
Degree of protection of electronics	IP54
Degree of protection of the connection area	IP43
Maximum permissible value for relative humidity (non-condensing)	15% to 95%
Maximum operating altitude above mean sea level	2000 m

General Data

Fresh air consumption	3000 m ³ /h
-----------------------	------------------------

* For order option "Noise reduction", the values change (see datasheet).

8.2 Sunny Central 630CP-JP**DC Input**

Maximum DC power	713 kW
Maximum input voltage	1000 V
MPP voltage range at 50 Hz	500 V to 850 V
MPP voltage range at 60 Hz	505 V to 850 V
DC voltage range at 50 Hz	500 V to 850 V
DC voltage range at 60 Hz	500 V to 850 V
DC rated input voltage	529 V
Maximum input current	1,350 A
Maximum short-circuit current	2500 A
Maximum reverse current	2300 A
MPP voltage at 50 Hz*	500 V
MPP voltage at 60 Hz*	500 V
Number of independent MPP inputs	1
Number of DC inputs	9

* For $I_{MPP} < I_{DCmax}$

AC Output

Nominal AC power at +50°C	630 kVA*
Rated power at +25°C	700 kVA
Nominal AC voltage	315 V
Nominal AC voltage range	284 V to 362 V
AC power frequency	50 Hz / 60 Hz
AC power frequency range	47 Hz to 63 Hz
Rated frequency	50 Hz
Rated voltage	315 V
Maximum output current	1350 A
Maximum residual current at the AC output	3500 A
Maximum overcurrent protection at output	50000 A

AC Output

Maximum total harmonic distortion	3 %
Power factor at rated power	1
Displacement power factor $\cos \varphi$	0.9 overexcited to 0.9 underexcited
Feed-in phases	3
Connection phases	3
Inrush current of the internal power supply	48 A (100 ms)

* For order option "Noise reduction", the values change (see datasheet).

Efficiency*

Maximum efficiency	98.7%
European weighted efficiency	98.5%
CEC weighted efficiency	98.5%

* For order option "Noise reduction", the values change (see datasheet).

Protective Devices

DC overvoltage protection	Type I
Lightning protection as per IEC 62305-1	Lightning protection level III
Surge arrester for auxiliary power supply	Type I and type II
Protection class in accordance with IEC 62109-01	I
Overvoltage category in accordance with IEC 60664-1	III

General Data

Width x height x depth	2562 mm x 2272 mm x 956 mm*
Weight	1800 kg*
Operating temperature range	-25°C to +62°C
Noise emission at a distance of 10 m (without order option "Noise reduction")	64 db(A)
Noise emission at a distance of 10 m (with order option "Noise reduction")	53 dB(A)
Maximum self-consumption in operation	< 1950 W
Standby consumption	< 100 W
External supply voltage	230 V/400 V (3/N/PE), 50 Hz/60 Hz
Degree of protection of electronics	IP54
Degree of protection of the connection area	IP43
Maximum permissible value for relative humidity (non-condensing)	15% to 95%

General Data

Maximum operating altitude above mean sea level	2000 m
Fresh air consumption	3000 m ³ /h

* For order option "Noise reduction", the values change (see datasheet).

8.3 Sunny Central 800CP-JP**DC Input**

Maximum DC power	898 kW
Maximum input voltage	1000 V
MPP voltage range at 50 Hz	583 V to 850 V
MPP voltage range at 60 Hz	583 V to 850 V
DC voltage range at 50 Hz	530 V to 850 V
DC voltage range at 60 Hz	530 V to 850 V
DC rated input voltage	641 V
Maximum input current	1,400 V
Maximum short-circuit current	2500 A
Maximum reverse current	2300 A
MPP voltage at 50 Hz*	530 V
MPP voltage at 60 Hz*	530 V
Number of independent MPP inputs	1
Number of DC inputs	9

* For $I_{MPP} < I_{DCmax}$

AC Output

Nominal AC power at +50°C	800 kVA*
Rated power at +25°C	880 kVA
Nominal AC voltage	360 V
Nominal AC voltage range	324 V to 414 V
AC power frequency	50 Hz / 60 Hz
AC power frequency range	47 Hz to 63 Hz
Rated frequency	50 Hz
Rated voltage	360 V
Maximum output current	1411 A
Maximum residual current at the AC output	3500 A

AC Output

Maximum overcurrent protection at output	50000 A
Maximum total harmonic distortion	3 %
Power factor at rated power	1
Displacement power factor $\cos \varphi$	0.9 overexcited to 0.9 underexcited
Feed-in phases	3
Connection phases	3
Inrush current of the internal power supply	48 A (100 ms)

* For order option "Noise reduction", the values change (see datasheet).

Efficiency*

Maximum efficiency	98.6%
European weighted efficiency	98.4%
CEC weighted efficiency	98.5%

* For order option "Noise reduction", the values change (see datasheet).

Protective Devices

DC overvoltage protection	Type I
Lightning protection as per IEC 62305-1	Lightning protection level III
Surge arrester for auxiliary power supply	Type I and type II
Protection class in accordance with IEC 62109-01	I
Overvoltage category in accordance with IEC 60664-1	III

General Data

Width x height x depth	2562 mm x 2272 mm x 956 mm*
Weight	1800 kg*
Operating temperature range	-25 °C to +62 °C
Noise emission at a distance of 10 m (without order option "Noise reduction")	64 db(A)
Noise emission at a distance of 10 m (with order option "Noise reduction")	55 dB(A)
Maximum self-consumption in operation	1950 W
Standby consumption	< 100 W
External supply voltage	230 V/400 V (3/N/PE), 50 Hz/60 Hz
Degree of protection of electronics	IP54
Degree of protection of the connection area	IP43

General Data

Maximum permissible value for relative humidity (non-condensing)	15% to 95%
Maximum operating altitude above mean sea level	2000 m
Fresh air consumption	3000 m ³ /h

* For order option "Noise reduction", the values change (see datasheet).

8.4 Sunny Central 1000CP-JP**DC Input**

Maximum DC power	1 122 kW
Maximum input voltage	1000 V
MPP voltage range at 50 Hz	625 V to 850 V
MPP voltage range at 60 Hz	625 V to 850 V
DC voltage range at 50 Hz	596 V to 850 V
DC voltage range at 60 Hz	596 V to 850 V
DC rated input voltage	688 V
Maximum input current	1635 A
Maximum short-circuit current	2500 A
Maximum reverse current	2300 A
MPP voltage at 50 Hz*	596 V
MPP voltage at 60 Hz*	596 V
Number of independent MPP inputs	1
Number of DC inputs	9

* For $I_{MPP} < I_{DCmax}$

AC Output

Nominal AC power at +50°C	900 kVA*
Rated power at +25°C	1 100 kVA
Nominal AC voltage	405 V
Nominal AC voltage range	365 V to 465 V
AC power frequency	50 Hz / 60 Hz
AC power frequency range	47 Hz to 63 Hz
Rated frequency	50 Hz
Rated voltage	405 V
Maximum output current	1568 A

AC Output

Maximum residual current at the AC output	3500 A
Maximum overcurrent protection at output	50000 A
Maximum total harmonic distortion	3%
Power factor at rated power	1
Displacement power factor $\cos \varphi$	0.9 overexcited to 0.9 underexcited
Feed-in phases	3
Connection phases	3
Inrush current of the internal power supply	48 A (100 ms)

* For order option "Noise reduction", the values change (see datasheet).

Efficiency*

Maximum efficiency	98.7%
European weighted efficiency	98.4%
CEC weighted efficiency	98.5%

* For order option "Noise reduction", the values change (see datasheet).

Protective Devices

DC overvoltage protection	Type I
Lightning protection as per IEC 62305-1	Lightning protection level III
Surge arrester for auxiliary power supply	yes
Protection class in accordance with IEC 62109-01	I
Overvoltage category in accordance with IEC 60664-1	III

General Data

Width x height x depth	2562 mm x 2272 mm x 956 mm*
Weight	1900 kg*
Operating temperature range	-25 °C to +62 °C
Noise emission at a distance of 10 m (without order option "Noise reduction")	68 db(A)
Noise emission at a distance of 10 m (with order option "Noise reduction")	60 db(A)
Maximum self-consumption in operation	< 1950 W
Standby consumption	< 100 W
External supply voltage	230 V / 400 V (3/N/PE), 50 Hz / 60 Hz
Degree of protection of electronics	IP 54

General Data

Degree of protection of the connection area	IP43
Maximum permissible value for relative humidity (non-condensing)	15% to 95%
Maximum operating altitude above mean sea level	2000 m
Fresh air consumption	3000 m ³ /h

* For order option "Noise reduction", the values change (see datasheet).

9 Appendix

9.1 Information for Installation

9.1.1 Requirements for the Mounting Location

- ☐ The mounting location must be freely accessible at all times.
- ☐ The fresh air requirement of the inverter amounting to 3000 m³/h must be assured.
- ☐ The mounting location must be below the maximum installation altitude.
- ☐ The ambient temperature must be within the operating temperature range.
- ☐ The fresh air must meet the 4S2 classification.

Air Quality Classification for Mechanically Active Substances

Ambient conditions for stationary application	Class 4S2
a) Sand in air [mg/m ³]	300
b) Dust (suspended matter) [mg/m ³]	5.0
c) Dust (precipitation) [mg/m ³]	20
Installation sites where appropriate measures are taken to keep dust levels to a minimum	x
Installation sites where no special measures have been taken to reduce the sand or dust levels and which are not located in the vicinity of sand or dust sources	x

The inverter is protected against salt spray in accordance with EN 60721-3-4 Class 4C2 and can be operated near the coast, for example.

Air Quality Classification for Chemically Active Substances

Ambient conditions for stationary application	Class 4C2	
	Mean value	Limiting value
a) Sea salt	Occurrence of salt spray	
b) Sulfur dioxide [mg/m ³]	0.3	1.0
c) Hydrogen sulfide [mg/m ³]	0.1	0.5
d) Chlorine [mg/m ³]	0.1	0.3
e) Hydrogen chloride [mg/m ³]	0.1	0.5
f) Hydrogen fluoride [mg/m ³]	0.01	0.03
g) Ammonia [mg/m ³]	1.0	3.0
h) Ozone [mg/m ³]	0.05	0.1
i) Nitrogen oxides [mg/m ³]	0.5	1.0
Installation sites in rural or densely populated areas with little industry and moderate traffic volume	x	
Installation sites in densely populated areas with industry and high traffic volume	x	

9.1.2 Requirements for the Support Surface

If you are using a base from SMA Solar Technology AG, you must prepare the mounting location with a subgrade.

The excavation pit must have the following properties:


- ☐ The pit must be excavated to the respective height of the base.
- ☐ A work area around the station must be available. The work area is at least: 500 mm.
- ☐ The corners of the excavation pit must be clearly marked.
- ☐ It must be possible to dump excavated material away from access routes so that the truck is not hindered during transport.

The subgrade must have the following properties:

- ☐ The subgrade must be made of stone-free, compactable material without sharp edges, e.g. a horizontal lean concrete plate.
- ☐ The compression ratio of the subgrade must be 98%.
- ☐ The soil pressure must be 150 kN/m².
- ☐ The unevenness must be less than 0.25% (as per DIN 18202: table 3, line 4).
- ☐ The subgrade must have the following minimum dimensions:

Position	Designation
Width	2600 mm
Depth	1000 mm + double foundation extension (0 mm to 300 mm)
Height	150 mm

- ☐ The preparation of the subgrade must ensure that the base sits about 150 mm above ground level after installation. This will ensure that the inverter is protected against high water levels after heavy rain or a snow melt.



- ☐ If the ground is to be paved up to the inverter, a gap must be maintained between the inverter and the paved area. The gap width is: 30 mm.

9.1.3 Requirements for the Foundation and Cable Routing

If you do not use a base from SMA Solar Technology AG, you can also position the inverter on a foundation.


The foundation must have the following properties:

- ☐ The foundation must be suitable for the weight of the inverter. The inverter weighs: 1800 kg.
- ☐ The unevenness must be less than 0.25% (as per DIN 18202: table 3, line 4).

- ☐ The inclination of the foundation must be between 0.5% and 1%. This will allow rain water to drain from underneath the inverter.
- ☐ The foundation must have at least the following dimensions:

Position	Designation
Width	2600 mm
Depth	1000 mm

- ☐ Cable feedthroughs must be provided in the foundation.



- ☐ For convenient operation and trouble-free maintenance, it is recommended to extend the inverter foundation on all sides or to provide a level, reinforced surface around the inverter. The foundation must have the following minimum dimensions:

Position	Designation
Width	3400 mm
Depth	1800 mm

- ☐ If the ground is to be paved up to the inverter foundation, a gap must be maintained between the foundation and the paved area. The gap width is: 30 mm.

Requirements for the cable arrangement:

- ☐ Openings for the cables must be located in the foundation underneath the interface cabinet.
- ☐ Empty conduits for the cables must be laid under the foundation.
- ☐ Cables for communication, control and supply voltage must be separated from AC and DC cables.
- ☐ There must be sufficient space available to lay the cables properly.

i Stage at which cables are laid

The stage at which the cables are laid must be determined individually for each system.

9.1.4 Requirements for Cable Routing between MV Transformer and Inverter

⚠ WARNING

Risk of fire due to overheating of cables if different cable lengths are used

Cables of differing lengths may cause the cables to overheat and catch fire. This can result in death or serious injury.

- All line conductors from the inverter to the MV transformer must be of the same length.
- The cable length between the connection points must not exceed a maximum length. Maximum cable length: 15 m.

i Design of the AC cables for high temperatures

If AC cables with a cable cross-section of $3 \times 240 \text{ mm}^2$ are installed and the inverter is being operated at outside temperatures of over $+45^\circ\text{C}$, temperatures of up to $+95^\circ\text{C}$ may arise at the busbars in the connection area. In order to preserve the ampacity at such temperatures, the AC cables must be fitted with ring terminal lugs and must be designed for operation at such high temperatures. SMA Solar Technology AG recommends the use of cable sets supplied by SMA. These are designed for temperatures of up to $+100^\circ\text{C}$.

Cable and cable laying requirements:

- ☐ The cables must be designed for the maximum voltages to ground.

Inverter	Maximum voltage to ground
Sunny Central 500CP-JP	$\pm 800 \text{ V}$
Sunny Central 630CP-JP	$\pm 1450 \text{ V}$
Sunny Central 800CP-JP	$\pm 1450 \text{ V}$
Sunny Central 1000CP-JP	$\pm 1600 \text{ V}$

- ☐ The cables must be designed for the maximum root-mean-square value:

Inverter	Maximum root-mean-square value
Sunny Central 500CP-JP	390 V
Sunny Central 630CP-JP	800 V
Sunny Central 800CP-JP	800 V
Sunny Central 1000CP-JP	800 V

- ☐ Do not attach more than four cables to each AC connecting plate.
- ☐ Use copper or aluminum cables only.
- ☐ Maximum cable cross-section: 325 mm^2 .
- ☐ All line conductor cables must be of the same length and must not exceed the maximum cable length. The maximum cable length is 15 m.
- ☐ The AC cables must be bundled in the three-phase system.
- ☐ Between the MV transformer and the inverter, three separate cable routes for the AC cables must be available, e.g. cable channels.
- ☐ A line conductor L1, L2 or L3 must be laid in each cable channel. Ensure that the distance between the cable bundles is at least twice the diameter of a cable. This will prevent current imbalances. Furthermore, it is recommended to execute cabling between inverter and MV transformer directly on a grounding strap. This measure further reduces electromagnetic influences.




Figure 18: Arrangement of AC cables with three cables per line conductor (example)

Position	Designation
L1	Line conductor L1
L2	Line conductor L2
L3	Line conductor L3
A	Grounding strap

9.1.5 Dimensions of the Inverter

Dimensions of the inverter with roof




Figure 19: Dimensions of the inverter with roof

Dimensions of the optionally available silencing baffle




Figure 20: Dimensions of the silencing baffle

Dimensions of the inverter without roof




Figure 21: Dimensions of the inverter without roof

9.1.6 Minimum Clearances

9.1.6.1 Minimum Clearances for Outdoor Installation

NOTICE

Damage due to intake of exhaust air or blocked ventilation openings

The supply air is intended to cool the inverter components. Failure to observe the specified minimum clearances can result in warm exhaust air from the inverter being drawn in. This increases the risk of a thermal short circuit. Property damage due to yield loss and damage to the components may result.

- Ensure that no exhaust air can be drawn in through the air inlets.
- Ensure that it is not possible for exhaust air to be drawn into the air intake of other devices.
- Make sure that the air inlets are not obstructed.
- Make sure that the exhaust air vents are not obstructed.
- Make sure that the ventilation openings are accessible for cleaning at all times.
- Ensure that the minimum clearances are complied with.

i Installation in closed electrical operating area

The inverter must be installed in a closed electrical operating area.

- Ensure that unauthorized persons have no access to the inverter.

i Observe minimum clearances

Observe the minimum clearances to ensure trouble-free operation of the inverter.

Maintain a certain distance between inverters installed back to back. This will facilitate maintenance and cleaning.
Recommended clearance: 800 mm

Minimum clearances for one inverter




Figure 22: Minimum clearances for one inverter

Minimum clearances between two inverters and transformer

Version 1: Rear to rear




Figure 23: Minimum clearances between two inverters and transformer

Position	Designation
A	Inverter 1
B	Inverter 2
C	MV transformer and medium-voltage switchgear
D	Cable route between inverter and MV transformer

Minimum clearances between two inverters and transformer

Version 2: Front to front




Figure 24: Minimum clearances between two inverters and transformer

Position	Designation
A	Inverter 1
B	Inverter 2
C	MV transformer and medium-voltage switchgear
D	Cable route between inverter and MV transformer

Recommended clearances for the facilitation of service work

In order to facilitate service work, minimum clearances to the rear and sides of 1000 mm are recommended. If you are using a service tent during installation and service work, maintain 5000 mm clearance to the inverter.

9.1.6.2 Minimum Clearances in Electrical Equipment Rooms

The option "Noise reduction" is not recommended for the option "Station installation" and therefore not further considered.

NOTICE

Damage due to intake of exhaust air or blocked exhaust air outlets

The supply air is intended to cool the inverter components. Failure to observe the specified minimum clearances can result in warm exhaust air from the inverter being drawn in. This increases the risk of a thermal short circuit. Property damage due to yield loss and damage to the components may result.

- Ensure that no exhaust air can be drawn in through the air inlets.
- Ensure that it is not possible for exhaust air to be drawn into the air intake of other devices.
- Make sure that the exhaust air vents are not obstructed.
- Make sure that the exhaust air vents are accessible for cleaning at all times.
- Ensure that the minimum clearances are complied with.

Minimum clearances for one inverter to be installed in electrical equipment rooms

The minimum passage width between the open door of the inverter and the next fixed obstacle must be maintained. The minimum passage width must comply with national standards.




Figure 25: Minimum clearances for one inverter in an electrical equipment room

Position	Designation
A	Minimum passage width
B	Inverter

Minimum clearances for two inverters to be installed in electrical equipment rooms

⚠ WARNING

Danger to life due to blocked escape routes

In hazardous situations, blocked escape routes can lead to death or serious injury. Opening the doors of two products located opposite each other can block the escape route. It is imperative that the escape route is freely accessible at all times.

- An escape route must be available at all times. Make sure the minimum passage width of the escape route meets local standards.
- Do not place any objects in the escape route area.
- Remove all tripping hazards from escape routes.

The minimum passage width between the open door of the inverter and the next fixed obstacle must be maintained. The minimum passage width must comply with national standards.




Figure 26: Minimum clearances for two inverters in an electrical equipment room

Position	Designation
A	Minimum passage width
B	Inverter

9.1.7 Grounding Concept

In accordance with the latest technology, the inverters are discharged to ground. As a result, leakage currents to ground occur which must be taken into account when planning the PV power plant. The magnitude and distribution of such leakage currents is influenced by the grounding concept of all devices in the PV power plant. It is therefore recommended that e.g. for use of cameras and monitoring technology, signal transmission is executed in fiber-optic technology. This will counteract possible interference sources.

The recommended grounding of inverter and MV transformer in meshed design reduces leakage current levels.

9.2 Storage

If you need to store the inverter prior to final installation, note the following points:

NOTICE

Property damage due to dust intrusion and moisture penetration

Dust or moisture intrusion can damage the product and impair its functionality.

- Do not open the enclosure during rainfall or when humidity exceeds the specified thresholds. The humidity thresholds are: 15% to 95%.
- Only perform maintenance work when the environment is dry and free of dust.
- Operation of the product is only permitted when it is closed.
- Connect the external supply voltage after mounting and installing the product.
- If the installation or commissioning process is interrupted, mount all panels.
- Close and lock the enclosure.
- The product must always be closed for storage.
- Store the product in a dry and covered location.
- The temperature at the storage location must be in the specified range. The temperature range is: -25°C to $+70^{\circ}\text{C}$.

NOTICE

Damage to the frame construction of the inverter due to uneven support surface

Placing the inverter on uneven surfaces can cause buckling so that the inverter doors will no longer close properly. This may lead to moisture and dust penetration into the inverter.

- Never place the inverter on an unstable, uneven surface even for a short period of time.
- The unevenness of the support surface must be less than 0.25%.
- The support surface must be suitable to take the weight of the inverter. Weight: 1800 kg.
- Do not transport the inverter with mounted kick plates.

i Desiccant bag in the inverter cabinet

The desiccant bag in the inverter cabinet protects the electronic components from moisture. The desiccant bag must be replaced by a new desiccant bag included in the scope of delivery one day before commissioning.

9.3 Installation Information

9.3.1 Torques

Torques of the power connections:

Type of terminal lug	Torque
Tin-plated aluminum terminal lug on copper bar	37 Nm
Tin-plated copper terminal lug on copper bar	60 Nm
Tin-plated aluminum or copper terminal lug on aluminum bar	37 Nm for M12 10 Nm for M8

Torques at panels, covers and grounding conductor:

Position	Torque
Grounding conductors on the kick plates	8 Nm to 10 Nm
Mounting the kick plates	2 Nm to 3 Nm
Grounding conductor on the roof	14.2 Nm
Mounting the ventilation grids on the roof	20 Nm
Protective covers	5 Nm

9.3.2 Reduction of DC Input Currents for DC Fuses

The DC inputs are fused with LV/HRC fuses. Thermal stress and alternating loads result in reduction factors which must be taken into account when designing the DC cables.

The reduction factor 0.70 is applicable for regions where maximum ambient temperatures of 40°C are expected. If higher ambient temperatures are expected, a reduction factor of 0.64 must be used.

Fusing	Maximum DC short-circuit current I_{SC_STC} (reduction factor 0.64 at ambient temperatures exceeding 40°C)	Maximum DC short-circuit current I_{SC_STC} (reduction factor 0.70 at ambient temperatures up to and including 40°C)
125 A	80.0 A	87.5 A
160 A	102.4 A	112.0 A
200 A	128.0 A	140.0 A
250 A	160.0 A	175.0 A
315 A	201.6 A	220.5 A
400 A	256.0 A	280.0 A

When selecting the fuse size, always consider the short-circuit current of the connected PV array at standard test conditions (I_{SC_STC}).

The reduction factors apply for a maximum irradiation of 1,200 W/m² (hourly average value of the horizontal global radiation). In case the irradiation is higher, the reduction factor must be adapted linearly.

9.4 Type Label

The type label clearly identifies the product. One type label is present in the inverter. The type label is located in the right-hand top corner inside the interface cabinet. You will require the information on the type label to use the product safely and when seeking customer support. The type labels must be permanently attached to the product.

i Reading off the serial number

You can identify the serial number without opening the inverter. The serial number can be found on the roof of the inverter at the top left. You can also read off the serial number from the touch display.

i Reading Off the Firmware Version

You can read off the version number of the inverter and touch display firmware via the user interface. You can also read off the version number of the touch display firmware on the touch display.

9.5 Scope of Delivery

Check the scope of delivery for completeness and any externally visible damage. Contact your distributor if the scope of delivery is incomplete or damaged.

Scope of Delivery of the Inverter




Figure 27: Scope of delivery

Position	Quantity	Designation
A	1	Inverter
B	1	Ventilation plate
C	5	Kick plate
D	1	Low-voltage HRC fuse handle (optional)
E	1	Non-woven abrasive
F	1	Desiccant bag
G	68	Bolt M12
	20	Bolt M8
H	68	Nut M12
	20	Nut M8
I	136	Fender washer (32 mm)
	40	Fender washer (20 mm)
K	136	Spring washer (29 mm)
	40	Spring washer (18 mm)
L	80	Cable tie
M	1	Cable support sleeve (15 mm to 16 mm)
N	1	Cable support sleeve (17 mm)
O	5	Cable support sleeves (9.5 mm to 13 mm)
P	1	Touch-up stick RAL 7004

Position	Quantity	Designation
Q	1	Touch-up stick RAL 9016
R	1	Circuit diagram, documentation, report

i Position of the LV/HRC fuse handle

The LV/HRC fuse handle is located on the inside of the right-hand interface cabinet door.

Scope of delivery with order option "Noise reduction"




Figure 28: Components for order option "Noise reduction"

Position	Quantity	Designation
A	1	Rear panel silencing baffle, including ventilation plate
B	1	Silencing baffle cover
C	1	Rain shield
D	1	Touch-up stick RAL 7035
E	1	Assembly paste (Anti-Seize)
F	15	Pan head flange screw
G	9	Socket head cap screw
H	7	Contact washer
I	14	Washer
K	10	Hex nut

9.6 Schematic Diagram

Schematic diagrams in PDF format contain jump marks. By double clicking a jump mark, the display will change to the corresponding current path or the referenced place in the equipment list. Using schematic diagrams in PDF format is recommended for the installation. The schematic diagrams in PDF format are available on request (see Section 10 "Contact", page 77).

10 Contact

If you have technical problems concerning our products, contact your service partner. The following data is required in order to provide you with the necessary assistance:

- Device type
- Firmware version
- Event message
- Type of communication
- Optional equipment, e.g. communication products
- Detailed description of the problem

**ENERGY
THAT
CHANGES**

