



## READ ME

<b>Inverter</b>	STP 8000TL-10 STP 10000TL-10 STP 12000TL-10 STP 15000TL-10 STP 17000TL-10
<b>FW-Version</b>	PACK 2.65.02
<b>Update feature/reason</b>	-Modbus functionality
<b>Update medium</b>	SD card (directly on the inverter)
<b>File-Name</b>	FW2.65.02R_STP8-17000TL_SD-Card.zip
<b>Update manual</b>	Please go to the SMA download area and do as follows: <a href="https://www.sma.de/service/downloads.html">https://www.sma.de/service/downloads.html</a> Search for "NG_UpdSD-TB" and select your preferred language.
<b>Note</b>	<ul style="list-style-type: none"><li>• The package includes 3 update Files (*.up2, *.bin and *.xml). All files need to be copied to the SD card.</li><li>• The SD-card update package consists of 3 files which must be located in the "UPDATE" folder</li><li>• The package contains a new PVS version. PVS updates need at least 1000 W DC Power lasting longer than 5 minutes Further information concerning the activation and setting of the "Self-learning string failure detection" can you find in the installation manual on <a href="http://www.SMA.de">www.SMA.de</a>.</li></ul>