

READ ME

Inverter	SB3.0-1AV-41 / SB3.6-1AV-41 / SB4.0-1AV-41 / SB5.0-1AV-41 / SB6.0-1AV-41
FW-Version	PACK 4.10.10.R
Warning	The firmware update can only be installed on inverters with firmware version 4.10.09.R. If an older firmware version is installed, version 4.10.09.R must be installed first. After a successful update, version 4.10.10.R can be installed as a second step.
Update feature	<p>The update file contains all features of the former firmware versions.</p> <ul style="list-style-type: none"> – RED compliance: Fulfilment of all RED (Radio Equipment Directive 2014/53/EU) and ETSI EN 303 645 cybersecurity requirements, further enhancing the system's IT security. – Bugfixes / Improvements: Includes various stability improvements and fixes for known issues to ensure reliable system performance.
Update medium	SB3.0_6.0-1AV-41-V4.10.10.R.up2 file update via integrated webserver
File Name	FW4-10-10-R_SB60-1AV-41.zip
Update manual	<ol style="list-style-type: none"> 1. Activate the user interface of the inverter. 2. Log in as Installer. 3. Select the menu Device Configuration. 4. In line Inverter click on the gear icon and select Update firmware. 5. Select the update package made available for the inverter and select Update firmware. 6. Follow the instructions in the dialog. 7. After completion of the update, it is strongly recommended to check the inverter settings, especially the grid code settings.
Note	<ul style="list-style-type: none"> – The package includes 2 update files (*.up2). The files can be downloaded directly to the inverter via Webserver interface using a smartphone, notebook or PC. – The update files contains all features of former firmware versions.