




## System Description

### **SMA FLEXIBLE STORAGE SYSTEM in the United Kingdom**

**Adjustment of electrical connection and configuration for the low-voltage grid in the  
United Kingdom of Great Britain and Northern Ireland**



## Legal Provisions

The information contained in this document is the property of SMA Solar Technology AG. Publishing its content, either partially or in full, requires the written permission of SMA Solar Technology AG.

Any internal company copying of the document for the purposes of evaluating the product or its correct implementation is allowed and does not require permission.

### SMA Warranty

You can download the current warranty conditions from the Internet at [www.SMA-Solar.com](http://www.SMA-Solar.com).

### Trademarks

All trademarks are recognized, even if not explicitly identified as such. A lack of identification does not mean that a product or symbol is not trademarked.

The BLUETOOTH® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of these marks by SMA Solar Technology AG is under license.

Modbus® is a registered trademark of Schneider Electric and is licensed by the Modbus Organization, Inc.

QR Code is a registered trademark of DENSO WAVE INCORPORATED.

Phillips® and Pozidriv® are registered trademarks of Phillips Screw Company.

Torx® is a registered trademark of Acument Global Technologies, Inc.

### SMA Solar Technology AG

Sonnenallee 1  
34266 Niestetal  
Germany

Tel. +49 561 9522-0  
Fax +49 561 9522-100  
[www.SMA.de](http://www.SMA.de)  
E-mail: [info@SMA.de](mailto:info@SMA.de)

© 2004 to 2018 SMA Solar Technology AG. All rights reserved.

## Table of Contents

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>Information on this Document</b>                                 | <b>4</b>  |
| 1.1      | Validity  | 4         |
| 1.2      | Content of this Document  | 4         |
| 1.3      | Target Group  | 4         |
| 1.4      | Additional Information  | 4         |
| 1.5      | Symbols   | 5         |
| 1.6      | Nomenclature  | 5         |
| <b>2</b> | <b>Safety</b>   | <b>6</b>  |
| 2.1      | Intended Use  | 6         |
| 2.2      | Safety Information  | 6         |
| <b>3</b> | <b>Planning</b>   | <b>7</b>  |
| 3.1      | Planning the Installation of the SMA Flexible Storage System        | 7         |
| 3.2      | Planning the Installation of the Battery-Backup System              | 8         |
| <b>4</b> | <b>SMA Flexible Storage System (Self-Consumption Only)</b>          | <b>9</b>  |
| 4.1      | Circuitry Overview of a Single-Phase SMA Flexible Storage System    | 9         |
| 4.2      | Circuitry Overview of a Three-Phase SMA Flexible Storage System     | 10        |
| <b>5</b> | <b>Battery-Backup System</b>  | <b>11</b> |
| 5.1      | Single-Phase Battery-Backup System                                  | 11        |
| 5.1.1    | Automatic Transfer Switch of the Single-Phase Battery-Backup System | 11        |
| 5.1.2    | Circuitry Overview of the Single-Phase Battery-Backup System        | 12        |
| 5.2      | Three-Phase Battery-Backup System                                   | 13        |
| 5.2.1    | Automatic Transfer Switch of the Three-Phase Battery-Backup System  | 13        |
| 5.2.2    | Circuitry Overview of the Three-Phase Battery-Backup System         | 14        |
| <b>6</b> | <b>Extended Configuration of the Sunny Island</b>                   | <b>15</b> |
| <b>7</b> | <b>Changing the Configuration of the PV Inverters</b>               | <b>16</b> |

# 1 Information on this Document

## 1.1 Validity

This document is valid for the following device types:

- HM-20 (Sunny Home Manager 2.0) from firmware version 2.00.00.R
- SI4.4M-12 (Sunny Island 4.4M) from firmware version 1.00.xx.R
- SI6.0H-12 (Sunny Island 6.0H) from firmware version 1.00.xx.R
- SI8.0H-12 (Sunny Island 8.0H) from firmware version 1.00.xx.R

## 1.2 Content of this Document

This document summarizes the information required in Great Britain and Northern Ireland for the installation of an SMA Flexible Storage System or an SMA Flexible Storage System with battery-backup function.

## 1.3 Target Group

The activities described in this document must only be performed by qualified persons. Qualified persons must have the following skills:

- Knowledge of how an inverter works and is operated
- Knowledge of how batteries work and are operated
- Training in the installation and commissioning of electrical devices and installations
- Knowledge of the applicable standards and directives
- Knowledge of and compliance with this document and all safety information
- Knowledge of and compliance with the documents of the battery manufacturer with all safety information

## 1.4 Additional Information

Links to additional information can be found at [www.SMA-Solar.com](http://www.SMA-Solar.com):

| Document title   | Document type         |
|--|-----------------------|
| SMA Smart Home   | Planning Guidelines   |
| SMA Flexible Storage System with Battery-Backup Function | Planning Guidelines   |
| List of Approved Batteries                               | Technical Information |

## 1.5 Symbols

| Symbol   | Explanation   |
|--|---|
|  <b>DANGER</b>  | Indicates a hazardous situation which, if not avoided, will result in death or serious injury |
|  <b>WARNING</b> | Indicates a hazardous situation which, if not avoided, can result in death or serious injury  |
|  <b>CAUTION</b> | Indicates a hazardous situation which, if not avoided, can result in minor or moderate injury |
|  <b>NOTICE</b>  | Indicates a situation which, if not avoided, can result in property damage                    |
|  <b>i</b>       | Information that is important for a specific topic or goal, but is not safety-relevant        |
| <input type="checkbox"/>   | Indicates a requirement for meeting a specific goal   |
| <input checked="" type="checkbox"/>  | Desired result  |
|  <b>x</b>       | A problem that might occur  |

## 1.6 Nomenclature

In this document, the SMA Flexible Storage System with battery-backup function is referred to as battery-backup system.

## 2 Safety

### 2.1 Intended Use

When using the SMA Flexible Storage System and the battery-backup system in Great Britain and Northern Ireland, an external grid and PV system protection must be installed. Contact your grid operator to check which standards are locally applicable for the planned battery-backup system:

- G83/2: Engineering Recommendation G83, Issue 2
- G59/3: Engineering Recommendation G59, Issue 3

This standard must comply with the external grid and PV system protection.

Use the SMA Flexible Storage System and the battery-backup system only in accordance with the enclosed documentation and with the locally applicable standards and directives. Any other use may cause personal injury or property damage. Alterations to the SMA Flexible Storage System and the battery-backup system, e.g., modifications and conversions, are permitted only with the express written permission of SMA Solar Technology AG. Unauthorized alterations will void guarantee and warranty claims and usually void the operating license. SMA Solar Technology AG shall not be held liable for any damage caused by such changes. Any use of the SMA Flexible Storage System and the battery-backup system other than that described in the Intended Use section does not qualify as appropriate. The enclosed documentation is an integral part of this product. Keep the documentation in a convenient place for future reference and observe all instructions contained therein.

### 2.2 Safety Information

#### **WARNING**

##### **Danger to life due to incorrect installation and configuration**

Incorrect installation of the products in the SMA Flexible Storage System can result in death or serious injury.

Incorrect configuration of the Sunny Island can result in death or serious injury.

This document is a supplement to the documentation that is provided with each product. This document does not replace any locally applicable standards or directives.

- Read and observe the documentation supplied with the products.
- Observe all applicable local standards and directives.

## 3 Planning

### 3.1 Planning the Installation of the SMA Flexible Storage System

| Procedure   | Required information                                     | See   |
|---|--|---|
| 1. Connecting the SMA Flexible Storage System   | Information and system description<br>Circuitry overview | System description "SMA Flexible Storage System"<br>Section 4, page 9 |
|   | Connecting the Sunny Island inverters                    | System description "SMA Flexible Storage System"                      |
|   | Connecting the Sunny Home Manager                        |   |
| 2. Basic configuration of the Sunny Island<br><br>During the first ten operating hours, set the country data set of the Sunny Island to <b>AS4777</b> . | -  | System description "SMA Flexible Storage System"                      |
| 3. Extended configuration of the Sunny Island   | -  | Section 6, page 15  |
| 4. Commissioning the SMA Flexible Storage System  | -  | System description "SMA Flexible Storage System"                      |

### 3.2 Planning the Installation of the Battery-Backup System

| Procedure   | Required information                          | See   |
|---|---|---|
| 1. Connecting the battery-backup system   | Procurement of the automatic transfer switch* | Planning Guidelines<br>"SMA Flexible Storage System with Battery-Backup Function" |
|   | Information and system description            | System description<br>"SMA Flexible Storage System with Battery-Backup Function"  |
|   | Circuitry overview                            | Section 5, page 11  |
|   | Connecting the Sunny Island inverters         | System description<br>"SMA Flexible Storage System with Battery-Backup Function"  |
| 2. Basic configuration of the Sunny Island<br><br>During the first ten operating hours, set the country data set of the Sunny Island to <b>AS4777</b> . | Connecting the Sunny Home Manager             | System description<br>"SMA Flexible Storage System with Battery-Backup Function"  |
|   | -   | System description<br>"SMA Flexible Storage System with Battery-Backup Function"  |
|   | -   | Section 6, page 15  |
|   | -   | Section 7, page 16  |
| 3. Extended configuration of the Sunny Island   | -   | System description<br>"SMA Flexible Storage System with Battery-Backup Function"  |
| 4. Changing the configuration of the PV inverters   | -   | System description<br>"SMA Flexible Storage System with Battery-Backup Function"  |
| 5. Commissioning the battery-backup system  | -   | System description<br>"SMA Flexible Storage System with Battery-Backup Function"  |

\* An automatic transfer switch can be purchased from enwitec electronic GmbH & Co.KG. When setting up the automatic transfer switch independently, make suitable provision for external grid and PV system protection.

## 4 SMA Flexible Storage System (Self-Consumption Only)

### 4.1 Circuitry Overview of a Single-Phase SMA Flexible Storage System




Figure 1: Circuitry overview of a single-phase SMA Flexible Storage System in Great Britain/Northern Ireland

## 4.2 Circuitry Overview of a Three-Phase SMA Flexible Storage System




Figure 2: Circuitry overview of a three-phase SMA Flexible Storage System in Great Britain/Northern Ireland

## 5 Battery-Backup System

### 5.1 Single-Phase Battery-Backup System

#### 5.1.1 Automatic Transfer Switch of the Single-Phase Battery-Backup System




Figure 3: Schematic diagram of the automatic transfer switch for a single-phase battery-backup system in Great Britain/Northern Ireland

## 5.1.2 Circuitry Overview of the Single-Phase Battery-Backup System





Figure 4: Circuitry overview of a single-phase battery-backup system in Great Britain/Northern Ireland

## 5.2 Three-Phase Battery-Backup System

### 5.2.1 Automatic Transfer Switch of the Three-Phase Battery-Backup System



\* The indicated values are recommended by SMA Solar Technology AG. The electrical devices must be designed in accordance with the locally applicable standards and directives.

<sup>\*2</sup> Only applicable for TT grid configuration

<sup>\*3</sup> Not required for systems without increased self-consumption

<sup>\*4</sup> Requirements for thermal fuse used: 1 A, nominal cold resistance of at least 0.2 Ω and melting integral max. 1A<sup>2</sup>s

<sup>\*5</sup> Voltage supply and measurement for external grid and PV system protection (see documentation from manufacturer)

Figure 5: Schematic diagram of the automatic transfer switch for a three-phase battery-backup system in Great Britain/Northern Ireland

## 5.2.2 Circuitry Overview of the Three-Phase Battery-Backup System




Figure 6: Circuitry overview of a three-phase battery-backup system in Great Britain/Northern Ireland

## 6 Extended Configuration of the Sunny Island

### Requirement:

- The extended configuration must be performed within the first ten operating hours of the Sunny Island, otherwise an SMA Grid Guard code is required in order to change grid-relevant parameters (application form for the SMA Grid Guard code available at [www.SMA-Solar.com](http://www.SMA-Solar.com)).

### Procedure:

1. Activate the user interface of the inverter (see the inverter operating manual).
2. Log in as "Installer".
3. Ensure that the parameter **Country standard set** is set to **AS4777.3** (for basic configuration of the Sunny Island, see either system description "SMA Flexible Storage System" or "SMA Flexible Storage System with Battery-Backup Function" of the Sunny Island).
4. Set the parameter **Voltage monitoring upper minimum threshold** to 172.5 V.

## 7 Changing the Configuration of the PV Inverters

In battery-backup systems, the active power of the PV inverters should be controllable depending on the frequency (see the Planning Guidelines "SMA Flexible Storage System with Battery-Backup Function"). If your grid operator prohibits the reduction of active power feed-in in case of overfrequency, you can also use the PV inverters without changing the configuration. SMA Solar Technology AG recommends activating the frequency-dependent control of the PV inverters.

### Requirements:

- The PV inverters are part of a battery-backup system and the automatic transfer switch can disconnect the PV inverters from the utility grid.
- The grid operator must be informed of the configuration change and have no objections to it.
- You must be authorized to change Grid Guard parameters. You can find the application form at [www.SMA-Solar.com](http://www.SMA-Solar.com) in the download area of the relevant PV inverter.
- The firmware version of the PV inverters must support the frequency-dependent control of active power (for "PV inverters", see the Planning Guidelines "SMA Flexible Storage System with Battery-Backup Function" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).

### Procedure:

1. With existing PV systems, make sure that the firmware of the installed PV inverters supports frequency-dependent active power reduction (see the Planning Guidelines "SMA Flexible Storage System with Battery-Backup Function" at [www.SMA-Solar.com](http://www.SMA-Solar.com)).
2. Set the following parameters of the PV inverters to the specified value (see the documentation of the communication product).

| Parameter  | Value               |
|--|---------------------|
| <b>P-WCtlHzMod</b>   | <b>On or WCtlHz</b> |
| Operating mode of active power reduction in case of overfrequency P(f)*                                      |                     |
| <b>P-WGra</b>  | <b>40</b>           |
| Active power gradient, linear instantaneous power gradient configuration*                                    |                     |
| <b>P-HzStr</b>   | <b>0.2</b>          |
| Difference between starting frequency and grid frequency, linear instantaneous power gradient configuration* |                     |
| <b>P-HzStop</b>  | <b>0.2</b>          |
| Difference between reset frequency and grid frequency, linear instantaneous power gradient configuration*    |                     |
| <b>P-HzStopWgra</b>  | <b>10</b>           |
| Active power gradient after reset frequency, linear instantaneous power gradient configuration*              |                     |

\* Menu **Equipment & device control system**



**SMA Solar Technology**

**www.SMA-Solar.com**

